

[Manuals.plus](#) /

› [BoxWave](#) /

› BoxWave ClearTouch ImpactShield Screen Protector User Manual

BoxWave ClearTouch ImpactShield

BoxWave ClearTouch ImpactShield Screen Protector User Manual

Model: ClearTouch ImpactShield (2-Pack)

INTRODUCTION

The BoxWave ClearTouch ImpactShield is a high-quality screen protector designed to provide superior protection for your Ancel FX5000 (9.8 in) device. This flexible film offers advanced defense against scratches, impacts, and daily wear, while maintaining crystal clear visibility and touch sensitivity. This manual provides essential information for installation, usage, and maintenance of your screen protector.



Image: The BoxWave ClearTouch ImpactShield screen protector shown alongside the Ancel FX5000 device it is designed to protect.

PACKAGE CONTENTS

- 2 x BoxWave ClearTouch ImpactShield Screen Protectors
- Installation Kit (typically includes cleaning cloth, dust removal sticker, squeegee card)



ClearTouch® IMPACTSHIELD



COLOR BRILLIANCE

High-quality optical film that optimizes color rendition.



CLARITY

Your vibrant screens don't deserve blur or bland. 99% transparency means perfect clarity. No loss of color. No loss of resolution.



PRECISION

Precision cut. Precision Accuracy. Cut exactly for your device for increased touchpad accuracy and recognition.



REUSABILITY

Cleartouch® comes equipped with installation forgiveness. Reuse and reinstall as needed.





Image: Packaging for the BoxWave ClearTouch ImpactShield, highlighting features such as color brilliance, clarity, precision, and reusability.

SETUP AND INSTALLATION

Proper installation is key to the performance and longevity of your screen protector. Follow these steps carefully:

1. **Prepare Your Workspace:** Choose a clean, dust-free environment. Wash your hands thoroughly to avoid transferring oils to the screen.
2. **Clean the Device Screen:**
 - Use the provided alcohol wipe (if included) to clean the screen surface.
 - Wipe dry with the microfiber cloth.
 - Use the dust removal sticker to lift any remaining dust particles from the screen. Ensure the screen is completely free of dust, smudges, and fingerprints.
3. **Align the Screen Protector:** Carefully peel back a small portion of the protective film (usually labeled "Step 1" or "Back"). Align the screen protector with the edges and cutouts of your Ancel FX5000 screen. Take your time to ensure precise alignment.
4. **Apply the Screen Protector:** Once aligned, slowly lower the screen protector onto the device screen, allowing it to adhere gradually. As you apply, use the squeegee card to gently push out any air bubbles towards the edges.
5. **Remove Top Film:** Once the screen protector is fully adhered and bubbles are removed, peel off the top protective film (usually labeled "Step 2" or "Front").
6. **Final Touches:** Use the microfiber cloth to gently wipe down the newly installed screen protector. Small bubbles may disappear over 24-48 hours.



Designed to Fit Your Device



Precisely Manufactured




*Image for reference only. The actual product is designed to fit the screen of your device

Image: An illustration demonstrating the precise manufacturing and design of the screen protector to ensure a perfect fit for your device.

OPERATING AND USAGE

The ClearTouch ImpactShield is designed to be virtually invisible and maintain the original touch sensitivity and display clarity of your Ancel FX5000.

- **Touch Sensitivity:** The screen protector will not interfere with the touch responsiveness of your device. You should experience the same smooth and accurate touch interactions as without the protector.
- **Display Clarity:** Enjoy 99% visibility and high-definition clarity, ensuring no loss of color or resolution.



Image: A visual representation of the screen protector's crystal clarity, ensuring the device's display remains vibrant and unobstructed.




Image: An illustration emphasizing the high definition clarity of the screen protector, boasting 99.9% color and transparency.

MAINTENANCE

To keep your screen protector in optimal condition and maintain its clarity:

- **Cleaning:** Use a soft, lint-free cloth (like the provided microfiber cloth) to gently wipe the screen protector. For stubborn smudges, slightly dampen the cloth with water or a screen cleaner specifically designed for electronics. Avoid harsh chemicals or abrasive materials.
- **Avoid Sharp Objects:** While the ImpactShield offers significant protection, extreme force or sharp objects can still damage it.

TROUBLESHOOTING

Here are solutions to common issues you might encounter:

Issue	Solution
Bubbles after installation	Small bubbles often disappear within 24-48 hours as the adhesive settles. For larger bubbles, gently lift the nearest edge of the protector and re-apply, using the squeegee card to push the air out. Ensure no dust is trapped underneath.
Dust particles trapped underneath	Carefully lift the screen protector near the dust particle. Use a dust removal sticker or a piece of tape to gently dab and lift the dust from both the screen and the adhesive side of the protector. Re-apply slowly.
Screen protector not adhering properly	Ensure the screen was thoroughly cleaned and free of oils or residue before application. If the issue persists, the protector may be damaged or misaligned. Use the second protector provided in the pack.




Image: An illustration depicting the 9H ultimate protection offered by the screen protector, safeguarding against chipping, liquid spills, and impacts from drops.



Image: A visual demonstrating the shatterproof capabilities of the screen protector, showing it remains intact even under significant impact.

SPECIFICATIONS

Feature	Detail
Hardness Rating	9H
Material	Flexible Film (with TPU layer for shock absorption)
Transparency	99% (Crystal Clear)
Compatibility	Ancel FX5000 (9.8 in)
Package Quantity	2-Pack
Item Weight	1.6 ounces



Flexible Material

ClearTouch protects your device without chipping and cracking.



*Image for reference only. The actual product is designed to fit the screen of your device

Image: A visual demonstrating the flexible nature of the ClearTouch ImpactShield, highlighting its ability to protect the device without chipping or cracking.

WARRANTY AND SUPPORT

BoxWave products are designed for durability and performance. While specific warranty details for this product are not provided in the general product information, BoxWave typically stands behind its products. For any inquiries regarding product defects, installation assistance, or general support, please contact BoxWave customer service directly. You may find contact information on the official BoxWave website or through the retailer where the product was purchased.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0CWBNH5L7>

More documents and user manuals: <https://manuals.plus/>