

Ayeway PD-S10K

Ayeway 10,000mAh Portable Power Bank User Manual

Model: PD-S10K

INTRODUCTION

Thank you for choosing the Ayeway 10,000mAh Portable Power Bank. This device is designed to provide reliable and fast charging for your electronic devices on the go. With its built-in cables and multiple output ports, it offers versatile charging solutions for various smartphones, tablets, and other USB-powered devices. Please read this manual carefully before use to ensure optimal performance and safety.

SAFETY INFORMATION

- Do not expose the power bank to extreme temperatures, direct sunlight, or fire.
- Do not immerse the power bank in water or other liquids.
- Avoid dropping, hitting, or disassembling the device.
- Keep out of reach of children.
- Use only certified charging cables and adapters.
- If the power bank swells, leaks, or emits an unusual odor, discontinue use immediately.
- Dispose of the power bank according to local regulations.

PRODUCT OVERVIEW

The Ayeway Portable Power Bank features a compact design with integrated charging solutions.



Figure 1: Front view of the Ayeway 10,000mAh Portable Power Bank, showing the digital display, USB-A output, USB-C input/output, and built-in Lightning and USB-C cables.

Key Features:

- **10,000mAh Capacity:** Provides multiple charges for most smartphones.
- **Built-in Cables:** Includes integrated USB-C and Lightning cables for convenience.
- **Multiple Outputs:** Features 2 built-in cables, 1 USB-C port (PD 20W), and 1 USB-A port (22.5W) for simultaneous charging of up to 4 devices.
- **Digital LED Display:** Shows the exact remaining battery percentage.
- **Compact and Lightweight:** Easy to carry for travel and daily use.

USB-C OUTPUT WITH BUILT-IN CHARGING CORDS FOR LATEST DEVICES

Designed for



New
Androids



New
iPhone



New
iPad



Figure 2: The power bank highlighting its USB-C output port and the two built-in charging cables (USB-C and Lightning) designed for compatibility with various modern devices.

4 DEVICES CHARGING SIMULTANEOUSLY

10,000mAh



Figure 3: Illustration of the power bank simultaneously charging a smartphone, tablet, wireless earbuds, and another smartphone, demonstrating its multi-device charging capability.

SETUP

Charging the Power Bank:

Before first use, fully charge the power bank. A wall adapter is NOT included.

1. Connect the included USB-A to USB-C recharging cord to the power bank's USB-C input port.
2. Connect the other end of the cable to a USB wall adapter (5V/2A or PD 20W recommended).
3. The LED digital display will show the charging progress. It will display "100%" when fully charged.

FASTER RECHARGING

Note: Wall Charger NOT included




Figure 4: The power bank connected to a wall charger via its USB-C port, illustrating the recharging process. A Type-C 20W PD charger can fully recharge it in approximately 4 hours, while a standard 5V 2.1A charger takes about 6 hours.

OPERATING INSTRUCTIONS

Charging Your Devices:

The power bank can charge devices using its built-in cables or its USB-A/USB-C output ports.

1. To begin charging, simply connect your device to one of the power bank's output options:
 - Use the built-in Lightning cable for Apple devices.
 - Use the built-in USB-C cable for USB-C compatible devices.
 - Connect your own USB-A cable to the USB-A output port.
 - Connect your own USB-C cable to the USB-C output port.
2. The power bank will automatically detect the connected device and begin charging. The LED display will illuminate to show the remaining battery percentage.
3. To check the battery level without a device connected, single-click the power button on the side of the item.



Figure 5: The power bank actively charging a laptop via its USB-C port and wireless earbuds, demonstrating its versatility for various devices in a typical use scenario.

Compatibility with 5V Heated Clothing:

This power bank is compatible with 5V USB heated vests and jackets. **NOTICE: NOT for 7.4V DC Jack.**

10000MAH POWER BANK FOR 5V USB HEATED CLOTHING

Keep you Warm around 3.5~7 Hours



5V/2A Output



Safety & Stability



High Speed Recharge



Light Weight



High

3.5 hours

Medium

3.5~5 hours

Low

5~7 hours

Notice: NOT for 7.4V DC Jack

Figure 6: The power bank connected to a heated vest, illustrating its use as a power source for 5V USB heated clothing, providing warmth for approximately 3.5 to 7 hours depending on the heat setting.

MAINTENANCE

- Clean the power bank with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- Store the power bank in a cool, dry place away from direct sunlight and moisture.

- If not used for extended periods, charge the power bank at least once every three months to maintain battery health.
- Avoid storing the power bank in a fully discharged state for long periods.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Power bank not charging	Cable not connected properly; Wall adapter not working; Power bank fully discharged.	Ensure cables are securely connected; Try a different wall adapter and cable; Allow power bank to charge for a few minutes before checking display.
Device not charging from power bank	Power bank battery low; Device cable faulty; Device not compatible; Power bank in standby mode.	Recharge the power bank; Try a different charging cable; Ensure device is compatible with 5V USB charging; Single-click power button to activate output.
LED display not turning on	Power bank is off; Battery completely drained.	Single-click the power button; Connect to a power source to charge.

SPECIFICATIONS

Model Number	PD-S10K
Battery Capacity	10,000 mAh
Product Dimensions	4.45 x 2.33 x 1.13 inches
Item Weight	6.8 ounces
Input (USB-C)	PD 20W (Max)
Output (USB-C)	PD 20W (Max)
Output (USB-A)	22.5W (Max)
Built-in Cables	USB-C, Lightning
Battery Type	Lithium Ion

WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the contact details provided with your purchase or visit the official Ayeway website. Please retain your proof of purchase for warranty claims.

© 2024 Ayeway. All rights reserved.