

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Aosom](#) /
- › [Aosom Kids Pedal Go Kart Instruction Manual \(Model 370-256V00GN\)](#)

## Aosom 370-256V00GN

# Aosom Kids Pedal Go Kart Instruction Manual

MODEL: 370-256V00GN

## 1. Introduction

---

Thank you for choosing the Aosom Kids Pedal Go Kart. This manual provides essential information for the safe assembly, operation, maintenance, and troubleshooting of your new pedal go-kart. Please read this manual thoroughly before use and retain it for future reference. This pedal go-kart is designed to provide an engaging and active riding experience for children aged 5 to 12 years.

# GO KART



Parent-child  
Interaction



Attractive  
Look



Suitable for  
5-12 Years



Authentic Driving  
Experience



Image: Overview of the Aosom Kids Pedal Go Kart highlighting its key features and age suitability.

## 2. Safety Information

**WARNING:** Adult supervision is required at all times. This product is not suitable for children under 5 years of age due to small parts and potential hazards. Always ensure the child wears appropriate safety gear, including a helmet, knee pads, and elbow pads, when operating the go-kart.

- Do not use on public roads, near motor vehicles, or on steep inclines.
- Ensure the go-kart is used on flat, even surfaces free from obstacles.
- Check all nuts, bolts, and connections are securely fastened before each use.
- The maximum weight capacity for this go-kart is 110 lbs (50 kg).
- Instruct the child on proper braking techniques and steering control.
- Keep hands and feet away from moving parts, especially the chain and wheels.
- No Warning Applicable.

## 3. Assembly Instructions

The Aosom Kids Pedal Go Kart requires assembly. While many components are pre-assembled, some parts will need to be attached by an adult. Please follow the detailed step-by-step instructions provided in the separate assembly guide included in the product packaging. Ensure all parts are present before beginning assembly.

**Key Assembly Steps (General Overview):**

1. Unpack all components and verify against the parts list.
2. Attach the front axle and steering column to the main frame.
3. Install the wheels, ensuring they are securely fastened.
4. Mount the seat onto the frame and adjust to the desired position.
5. Connect the pedal system and chain, ensuring the chain is properly tensioned and enclosed.
6. Attach the hand brake lever and connect it to the braking mechanism.



Image: The enclosed chain design ensures safety and a clean appearance.

## 4. Operating Instructions

Operating the Aosom Kids Pedal Go Kart is straightforward, designed for intuitive use by children. Familiarize your

child with the controls before their first ride.

- **Pedal Power:** The go-kart is propelled by foot pedals. Push the pedals forward to move forward and backward to engage reverse. This pedal-based operation eliminates the need for batteries and promotes physical activity.
- **Steering:** Use the steering wheel to control the direction of the front wheels. Encourage smooth and gradual turns.
- **Hand Brake:** The go-kart is equipped with a safety hand brake. To stop, pull the hand brake lever located near the seat. Practice braking in a safe, open area until the child is proficient.
- **Adjustable Seat:** The 3-position adjustable seat allows for comfortable driving posture as your child grows. To adjust, loosen the fasteners, slide the seat to the desired position, and re-secure the fasteners.



Image: Controls for the Aosom Kids Pedal Go Kart, including hand brake and pedal functions.

# 3-POSITION ADJUSTABLE SEAT

Flexibly adjusted forwards or backwards



Image: The ergonomic seat can be adjusted to three positions for optimal comfort and fit.

## 5. Maintenance

Regular maintenance ensures the longevity and safe operation of your Aosom Kids Pedal Go Kart.

- **Cleaning:** Wipe down the go-kart with a damp cloth after use. Avoid harsh chemicals that may damage the finish.
- **Tire Check:** The rubber wheels feature wear-resistant tread. Periodically inspect tires for wear, punctures, or damage. Ensure they are free of debris.
- **Fasteners:** Regularly check all nuts, bolts, and screws to ensure they are tight. Re-tighten as necessary to prevent parts from loosening during use.
- **Chain:** The enclosed chain requires minimal maintenance. If you notice any unusual noise or stiffness, consult the assembly guide for chain tension adjustment.
- **Storage:** Store the go-kart in a dry, covered area to protect it from weather elements when not in use.

# SUITABLE FOR DIFFERENT ROAD CONDITION

Rubber wheels with shock absorb allow for a smooth ride



Image: Durable rubber wheels with shock absorption for a smooth ride on different surfaces.

## 6. Troubleshooting

If you encounter issues with your Aosom Kids Pedal Go Kart, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Go-kart does not move when pedaling.	Chain is loose or disengaged.	Check chain tension and re-engage if necessary. Refer to assembly guide.
Difficulty steering or poor turning radius.	Steering components are loose or damaged.	Inspect steering rod and connections for damage or looseness. Ensure all fasteners are tight. Note that the go-kart is designed for general use and may have a wider turning radius than some other vehicles.

Problem	Possible Cause	Solution
Hand brake is ineffective.	Brake cable is loose or worn.	Adjust the brake cable tension. If the brake pads are worn, they may need replacement (contact customer support for parts).
Unusual noises during operation.	Loose parts, dry chain, or debris in moving components.	Check all fasteners. Clean and lubricate the chain if dry. Remove any debris from wheels or pedals.
Go-kart struggles on grass or uneven surfaces.	Designed primarily for hard, flat surfaces.	This pedal go-kart performs best on concrete, asphalt, or boardwalks. Avoid deep grass or very uneven terrain for optimal performance and to prevent strain on components.


If you experience issues not covered here, or if solutions do not resolve the problem, please contact Aosom customer support.

## 7. Specifications

---

Detailed specifications for the Aosom Kids Pedal Go Kart, Model 370-256V00GN:

- **Overall Dimensions:** 47.75" L x 22.75" W x 24" H
- **Seat Dimensions:** 13.75" W x 11" D x 13.75" H
- **Item Weight:** 29.7 pounds
- **Weight Capacity:** 110 lbs (50 kg)
- **Recommended Age:** 5 - 12 years
- **Model Number:** 370-256V00GN
- **Certifications:** ASTM F963, CPSIA, SOR
- **Material:** Steel frame, plastic components, rubber wheels



22.75"



47.75"

Image: Technical drawing showing the key dimensions of the go-kart.

## 8. Product Video

Watch the official product video for a visual guide to the Aosom Kids Pedal Go Kart's features and operation.

Your browser does not support the video tag.

Video: Official product video showcasing the Aosom 370-256V00GN Pedal Go Kart, demonstrating its features and how it operates.

## 9. Warranty and Support

Aosom stands behind the quality of its products. For warranty information, replacement parts, or further assistance, please refer to the warranty card included with your purchase or visit the official Aosom website. Please have your model number (370-256V00GN) and purchase date ready when contacting support.

**Contact Information:**

- **Website:** [www.aosom.com](http://www.aosom.com)
- **Customer Service:** Refer to the contact details on the Aosom website or your product packaging.