

[Manuals.plus](#) /

› [Honeywell](#) /

› Honeywell 6-Outlet Surge Protector (Model B0CWGXZ1YT) User Manual

Honeywell B0CWGXZ1YT

Honeywell 6-Outlet Surge Protector with USB-A and USB-C PD20W Ports

Model: B0CWGXZ1YT

INTRODUCTION

This user manual provides essential information for the safe and efficient operation of your Honeywell 6-Outlet Surge Protector. This device is designed to protect your electronic equipment from power surges and provide convenient charging options through its AC outlets, USB-A, and USB-C PD20W ports. Please read this manual thoroughly before use and retain it for future reference.



Image: Honeywell 6-Outlet Surge Protector, showing its layout with AC outlets, USB ports, and master switch.

IMPORTANT SAFETY INSTRUCTIONS

To reduce the risk of electric shock, fire, or injury, always follow these basic safety precautions:

- Do not exceed the electrical ratings of the surge protector. Refer to the specifications section for details.
- Do not use in wet environments or near water.
- Do not open or modify the surge protector. There are no user-serviceable parts inside.
- Keep children away from the surge protector. The child safety shutters help prevent accidental insertion of objects into outlets.
- Ensure the power cord is fully inserted into a grounded wall outlet.
- Avoid routing the power cord through doorways or under carpets where it could be damaged.
- If the surge protector becomes damaged, discontinue use immediately.

- The automatic overload protection will trip if the connected load exceeds the maximum capacity. Disconnect some devices and press the reset switch if this occurs.

8 SAFETY FEATURES



OVERLOAD
PROTECTION



AUTOMATIC
RESET SWITCH



CHILD SAFETY
SHUTTER



3-LINE AC
PROTECTION



FIRE RESISTANT
MATERIAL



LED
INDICATOR



METAL OXIDE
VARISTOR (MOV)



DEVICE SECURE
WARRANTY (DSW)

Image: Overview of the 8 advanced safety features integrated into the surge protector.

PRODUCT FEATURES AND COMPONENTS

Your Honeywell Surge Protector is equipped with multiple features for power distribution and protection:

- **6 Universal AC Outlets:** Accommodates various plug types.
- **2 USB-A Ports:** For standard USB charging.
- **2 USB-C PD20W Ports:** For fast charging compatible devices.
- **Master Switch:** Controls power to all connected outlets and USB ports.
- **Surge Protected LED Indicator:** Illuminates when surge protection is active.
- **Automatic Overload Protection:** Automatically cuts power to prevent damage from excessive current.

- **1.8 Meter Power Cord:** Provides flexible placement options.
- **Child Safety Shutters:** Integrated into AC outlets for protection.
- **Fire Resistant Material:** Enhances safety.
- **Metal Oxide Varistor (MOV) Technology:** Diverts excess voltage away from connected devices.

FEATURES



ON / OFF
SWITCH



100% PURE
COPPER



SURGE
PROTECTION



1.8 METER
POWER CORD



WALL
MOUNT



Image: Key features of the surge protector, including the master switch and cord length.

SETUP INSTRUCTIONS

Follow these steps to set up your surge protector:

1. **Unpack:** Carefully remove the surge protector from its packaging.
2. **Placement:** Place the surge protector on a stable, dry surface, away from heat sources or direct sunlight. Ensure the 1.8-meter cord can reach a wall outlet without tension.
3. **Connect to Power:** Plug the surge protector's power cord directly into a grounded 3-prong wall outlet. Do not plug it into

another extension cord or surge protector.

4. **Power On:** Press the master switch to the 'ON' position. The 'Surge Protected' LED indicator should illuminate, confirming active surge protection.
5. **Connect Devices:** Plug your electronic devices into the universal AC outlets, USB-A, or USB-C PD20W ports.

CONNECT 10 DEVICES SIMULTANEOUSLY



Image: Connecting multiple devices to the surge protector's AC outlets and USB ports.

OPERATING INSTRUCTIONS

- **Master Switch:** Use the red master switch to turn power on or off for all connected devices simultaneously. This is useful for conserving energy or when leaving devices unattended.
- **Surge Protected Indicator:** A green LED light indicates that the surge protection feature is active and functioning. If this light is off, the surge protection may have been compromised, and the unit should be replaced.
- **AC Outlets:** Insert your device's power plugs into any of the 6 universal AC outlets. The child safety shutters will open when a plug is inserted correctly.

- **USB Charging:** Connect your USB-powered devices to the USB-A or USB-C PD20W ports. The USB-C PD20W ports provide faster charging for compatible devices.
- **Overload Protection:** In case of an electrical overload (too many high-power devices connected), the automatic overload protection will trip, and the master switch may pop out. To reset, unplug some devices, then press the master switch back in.

ULTRA FAST CHARGING

20W PD



Image: Utilizing the Ultra Fast Charging 20W PD USB-C port for compatible devices.

MAINTENANCE

- **Cleaning:** Disconnect the surge protector from the wall outlet before cleaning. Use a soft, dry cloth to wipe the exterior. Do not use liquid cleaners or aerosols.
- **Inspection:** Periodically inspect the power cord and the surge protector for any signs of damage, such as frayed wires or cracks in the casing. If damage is found, discontinue use and replace the unit.
- **Storage:** When not in use for extended periods, store the surge protector in a cool, dry place, away from direct sunlight and

moisture.

TROUBLESHOOTING

Problem	Possible Cause	Solution
No power to connected devices.	Master switch is OFF. Surge protector not plugged in. Wall outlet has no power. Overload protection tripped.	Ensure master switch is ON. Verify surge protector is securely plugged into a live wall outlet. Test wall outlet with another device. Reduce connected load and press the master switch to reset.
Surge Protected LED is off.	Surge protection has been compromised due to a significant surge.	The unit may still function as an extension cord, but surge protection is no longer active. Replace the surge protector to ensure continued protection.
Devices not charging via USB ports.	Device cable faulty. Device not compatible with USB charging. Overload on USB ports.	Try a different USB cable. Ensure your device supports USB charging. Disconnect other USB devices to see if charging resumes.

SPECIFICATIONS

Model: B0CWGXZ1YT

Brand: Honeywell

Total Power Outlets: 6 Universal AC Sockets

USB Ports: 2 x USB-A, 2 x USB-C PD20W

Maximum Surge Protection: 1050 Joules / 36000 Amps / 6KV Max

Cord Length: 1.8 Meters

Special Features: Automatic Overload Protection, Master Reset Switch, Child Lock Shutters, Fire Resistant Material, Full 3-Line Surge Protection, MOV Technology, LED Indicator, Device Secure Warranty (DSW)

Product Dimensions (L x W): 28.7 cm x 10.9 cm

Item Weight: 0.66 Kilograms

Compatible Devices: Personal Computer, E-Reader, Speaker, Smartphone, Router, Laptop, Tablet, Monitor, Gaming Console, Smartwatch, Fan, Printer, Television, Lamp, and many more.

SURGE PROTECTION

Protects your electrical appliances from lightning, surge or spikes



6 KILOVOLTS MAX



AMP 36,000



1050 JOULES



Image: Detailed view of the surge protection specifications.

WARRANTY AND SUPPORT

Manufacturer Warranty: This Honeywell Surge Protector comes with a **3 Years Manufacturer Warranty** from the date of purchase, covering defects in materials and workmanship.

Device Secure Warranty (DSW): The product also includes Device Secure Warranty, providing additional protection for connected devices. Please refer to the warranty documentation included with your product for full terms and conditions.

DEVICE SECURE WARRANTY UPTO RS 60,000




Image: Device Secure Warranty information.

Customer Support

For technical assistance, warranty claims, or product inquiries, please contact Honeywell customer support:

Toll-Free Number: [1800-120-6838](tel:1800-120-6838) (Monday to Saturday, 10 AM to 7 PM)

Email: Support@honeywellconnection.com

Manufacturer: Secure Connection Limited, Flat C 61/F, Block A, LA Rossa, Coastal Skyline 12 Tung Chung, Water Front Road Tung Chung, N.T., Hong Kong

Importer: Creative Peripherals & Distribution Limited Jayem Warehousing Pvt. Ltd., Sumeet Logistics, Building No. C-3, Gala No. 1 to 6A, At Village Kikse-Borivili, Opp. Rajdhani Dhaba, Mumbai-Nasik Highway, District Thane, Bhiwandi-421302.

**690+ Service Centres
Nationwide, Offering
On-Site Support**

 Need assistance?
Contact our customer
support team at



 **TOLL- FREE NUMBER**

1800-120-6838

(Monday To Saturday, 10 Am To 7:00 Pm)

 Support@honeywellconnection.com

Image: Honeywell customer support information and service center network.

© 2024 Honeywell. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question