

## DELSEY 003845801

# DELSEY CLAVEL EXP Suitcase User Manual

Model: 003845801

Brand: DELSEY

## INTRODUCTION

Thank you for choosing the DELSEY CLAVEL EXP suitcase. This manual provides essential information for the proper use, care, and maintenance of your new luggage. The CLAVEL EXP series is designed for modern travelers, offering a blend of lightweight construction, robust impact resistance, and enhanced security features.

Key features include the innovative Zip Securitech double zipper system for superior theft deterrence, smooth 360-degree double-wheel casters for effortless maneuverability, an integrated TSA-approved lock for secure travel, and a convenient expander function to adapt to your packing needs.



Image: Front view of the DELSEY CLAVEL EXP suitcase, highlighting its sleek design and the product label detailing features like ultra-lightweight and ultra-resistant polypropylene material.

## SETUP

Your DELSEY CLAVEL EXP suitcase is designed for immediate use. Please follow these steps upon receiving your product:

1. **Unpacking:** Carefully remove the suitcase from its packaging. Inspect for any signs of damage during transit.
2. **Initial Inspection:** Check all zippers, handles, and wheels to ensure they operate smoothly.
3. **Lock Setup:** If your suitcase comes with a pre-set combination, follow the instructions in the 'Operating Instructions - TSA Lock' section to set your personal combination.
4. **Interior Preparation:** Open the suitcase and remove any internal packaging materials. The interior lining may have a slight odor initially; this will dissipate with ventilation.

## DETAIL

ディテール



「CLAVEL EXP 55cm／39L + 4L」

エレガントな丸みを帯びた形がおしゃれなスーツケース。

便利なエキスパンダー（拡張機能）を搭載。

荷物に合わせて容量をアップさせることができます。

Image: Detailed views of the suitcase, showing both the front and back profiles. This helps in understanding the overall design and structure of the luggage.

## OPERATING INSTRUCTIONS

## Zip Securitech Double Zipper System

The CLAVEL EXP features a double-layer zipper system, Zip Securitech, which offers significantly higher resistance to intrusion compared to standard zippers. This design enhances the security of your belongings.

- To open or close, simply pull the zipper tabs as you would with a regular zipper. The double-layer construction provides added strength.

## TSA Combination Lock

Your suitcase is equipped with a TSA-approved combination lock, allowing security authorities to inspect your luggage without damaging the lock. The initial combination is typically 0-0-0.

### 1. Setting Your Combination:

- a. Set the dials to the current opening combination (factory set to 0-0-0).
- b. Locate the reset button (a small, recessed button, usually on the side of the lock). Use a pen or pointed object to press and hold this button until you hear a click.
- c. While holding the reset button, set your desired 3-digit combination by rotating the dials.
- d. Release the reset button. Your new combination is now set. Remember your combination carefully.

2. **Locking/Unlocking:** Align your set combination with the indicators, then press the release button or slide the lever to open the zipper pulls. To lock, insert the zipper pulls into the lock and scramble the dials.



拡張機能があり、いつでもスーツケースの容量を増やすことが可能。

Image: A side view of the suitcase, clearly showing the integrated TSA combination lock and the secondary zipper for the expander function. The image also shows the suitcase in both its compact and expanded states.

## Double-Wheel Casters

The suitcase is equipped with large, silent double-wheel casters that allow for 360-degree rotation. This design ensures smooth and stable movement in any direction, reducing strain on your arm and dispersing impact during travel.

- To move the suitcase, simply push or pull it in the desired direction. The wheels will pivot automatically.
- For optimal maneuverability, utilize all four wheels when moving the suitcase upright.



Image: A close-up shot highlighting the DELSEY PARIS brand logo on the suitcase's surface and one of the durable double-wheel casters, emphasizing the quality of components.

## Expander Function

The CLAVEL EXP features a convenient expander zipper, allowing you to increase the suitcase's internal capacity by an additional 4 liters when needed.

- To expand the suitcase, locate the secondary zipper running along the perimeter of the suitcase.
- Unzip this secondary zipper completely to extend the depth of the suitcase.
- To return to the compact size, simply zip the expander zipper back up.





Image: Top view of the suitcase, showing the retractable handle in its lowered position and the main zipper line, indicating the robust construction around the opening.



Image: The interior of the suitcase, fully opened, revealing the spacious compartments, mesh divider pockets, and elastic cross-straps designed to secure belongings during travel.





Image: A close-up of an interior zipper pull with the DELSEY branding, alongside another view of the suitcase's organized interior, highlighting the quality of the internal components.

## MAINTENANCE

---

Proper care will extend the life of your DELSEY CLAVEL EXP suitcase.

- **Cleaning the Exterior:** Wipe the polypropylene exterior with a damp cloth and mild soap. Avoid abrasive cleaners or solvents.
- **Cleaning the Interior:** The polyester lining can be spot cleaned with a damp cloth and mild detergent. Allow to air dry completely before closing.
- **Wheel Maintenance:** Periodically check the wheels for debris (hair, lint, etc.) and remove them. If wheels become stiff, a small amount of silicone spray can be applied to the axle.

- **Zipper Care:** Keep zippers clean and free of debris. If a zipper becomes stiff, apply a small amount of zipper lubricant or wax.
- **Storage:** Store your suitcase in a cool, dry place, away from direct sunlight and extreme temperatures. Avoid placing heavy objects on top of the suitcase when stored.

## TROUBLESHOOTING

Here are some common issues and their solutions:

Problem	Possible Cause	Solution
Wheels not rolling smoothly	Debris caught in wheels; lack of lubrication	Remove debris. Apply silicone spray to axles if needed.
Zipper is stuck or difficult to move	Fabric caught; zipper needs lubrication	Carefully free any caught fabric. Apply zipper lubricant or wax.
TSA lock combination not working	Incorrect combination; lock reset incorrectly	Ensure correct combination is entered. Re-set the combination following instructions in 'Operating Instructions'.
Handle is stiff or not extending	Debris in mechanism; bent handle tube	Check for and remove any debris. Do not force a bent handle. Contact support if issue persists.

## SPECIFICATIONS

Feature	Detail
Model Name	CLAVEL EXP 55cm/39L+4L
Model Number	003845801
Dimensions (H x W x D)	Approx. 55cm x 35cm x 25cm (27cm when expanded)
Weight	Approx. 2.4 kg
Capacity	39L (expandable to +4L)
Exterior Material	Polypropylene
Interior Material	Polyester
Lock Type	Integrated TSA Combination Lock
Wheel Type	Double-Wheel Casters (360-degree rotation)
Origin	China

*Note: All dimensions and weights are approximate and may vary slightly due to manufacturing tolerances and measurement methods.*



Image: Close-up views of the suitcase's top handle and its robust double-wheel system at the bottom, showcasing the ergonomic design and durability of these critical components.





## WARRANTY AND SUPPORT

DELSEY products are known for their quality and durability. The CLAVEL EXP suitcase comes with **5-year worldwide warranty**, as indicated on the product label. This warranty covers manufacturing defects in materials and workmanship.


For warranty claims or technical support, please contact DELSEY customer service through their official website or the retailer from whom you purchased the product. Please retain your proof of purchase for warranty validation.

For more information about DELSEY products and support, please visit the official DELSEY website.

## Related Documents - 003845801

	<p><a href="#">Delsey Paris Luggage Care Guide: Cleaning &amp; Maintenance</a></p> <p>This comprehensive guide from Delsey Paris offers essential instructions for cleaning and maintaining your luggage. Discover effective methods for caring for your suitcase's key components, including wheels, handles, and trolley systems, as well as different materials like leather and fabric. Learn how to keep your Delsey suitcase in optimal condition, ensuring its longevity and hygiene through simple, effective maintenance steps.</p>
	<p><a href="#">DELSEY PARIS TSA Lock: Setting Your Combination</a></p> <p>Guide on how to set and change the combination for your DELSEY PARIS TSA-approved luggage lock, featuring TRAVEL SENTRY™ certification.</p>
	<p><a href="#">DELSEY TSA Lock Instructions: How to Set Your Combination</a></p> <p>Step-by-step guide on how to set and change the combination for your DELSEY luggage TSA-approved lock. Includes instructions in multiple languages.</p>
	<p><a href="#">DELSEY SECURITECH TSA Lock: How to Set and Use Your Luggage Lock</a></p> <p>Step-by-step instructions for setting and using your DELSEY SECURITECH TSA-approved combination luggage lock. Learn how to secure your travel bags with this Travel Sentry certified lock.</p>
	<p><a href="#">DELSEY PARIS TSA Combination Lock: Instructions for Use and Setting Code</a></p> <p>Learn how to set, change, and use your DELSEY PARIS luggage lock with TSA approval and TRAVEL SENTRY certification. Step-by-step guide for TSA combination locks.</p>






### [DELSEY TSA Combination Lock: Setting and Usage Instructions](#)

Comprehensive guide to setting and using your DELSEY TSA combination lock. Includes step-by-step instructions in English and a description of the lock mechanism and Travel Sentry® approval.

Documents - DELSEY – 003845801



[\[pdf\]](#) Catalog

CATALOGUE 2020 DELSEY B2B FR delsey on demandware static Library Sites DelseySharedLibrary default dwad0c96f4 images article page |||

CATALOGUE 2020 Paris De ses gares ses aéroports en passant par son architecture et... les Paris ... CLAVEL POLYPROPYLENE NOIR 00 BLUE JEAN 02 GRIS 11 ARMY 13 TANGERINE ORANGE 14 CITRON 15 BLANC 57 **003845801** 003845803 003845820 003845821 003845830 **003845801** VALISE TROLLEY CABINE EXTENSIBLE 4 ...

lang:fr **score:24** filesize: 40.25 M page\_count: 98 document date: 2020-01-22