

SHLUCE

Flush Mount Caged Ceiling Fan with Lights

Model: FLA001

Brand: SHLUCE

INTRODUCTION

This manual provides detailed instructions for the installation, operation, and maintenance of your new SHLUCE Flush Mount Caged Ceiling Fan with Lights. Please read this manual thoroughly before installation and retain it for future reference. Proper installation and use will ensure optimal performance and safety.

SAFETY INSTRUCTIONS

WARNING: To reduce the risk of fire, electric shock, or personal injury, always follow these basic precautions:

- Ensure the power is turned off at the circuit breaker or fuse box before beginning installation or performing any maintenance.
- All wiring must be in accordance with national and local electrical codes. If you are unfamiliar with wiring, consult a qualified electrician.
- The mounting structure must be capable of supporting the weight of the fan (approximately 4.22 kg / 9.3 lbs).
- Do not operate the fan with a damaged power cord or plug.
- Avoid placing fingers or objects into the fan cage while it is operating.
- Do not use this fan with any solid-state speed control device.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.

PACKAGE CONTENTS

Before beginning installation, ensure all components listed below are present and undamaged. If any parts are missing or damaged, contact customer support.

- Caged Ceiling Fan Unit (Pre-assembled)
- Remote Control
- Mounting Hardware Kit (screws, wire nuts, etc.)
- User Manual (this document)

SETUP AND INSTALLATION

The SHLUCE Flush Mount Caged Ceiling Fan is designed for easy installation, with the main unit already assembled. Follow these steps carefully.


1. Pre-Installation Checks

- Turn off power at the main circuit breaker.
- Verify that the electrical box is securely mounted and capable of supporting the fan's weight.
- Ensure you have all necessary tools (screwdriver, wire strippers, ladder, etc.).

2. Mounting the Fan

Attach the fan's mounting bracket to the electrical junction box using the provided screws. Ensure it is firmly secured.

Product Specifications



6 Speed + Natural Wind



4*E26 Base(More Brighter)



Reversible Motor



Timing 1/2/4H



Easy to Install(Already Assembled)



Remote Control

8 Blades

Figure 1: Product Dimensions and Key Features. This image illustrates the overall dimensions of the fan (approximately 18.1 inches wide, 9.5 inches high) and highlights features such as the 6-speed fan, E26 light bulb bases, reversible motor, and timing functions. It also shows the included remote control and the 8-blade design.

3. Wiring Connections

Connect the fan's electrical wires to your household wiring according to the wiring diagram provided in the full product manual (not included here). Typically, this involves connecting live, neutral, and ground wires. Use the provided wire nuts to secure connections.

4. Installing Light Bulbs

This fan requires four E26 base light bulbs (not included). Screw the bulbs into the ceramic lamp holders. Ensure bulbs are securely seated but do not overtighten.



Figure 2: E26 Ceramic Lamp Holder and Bulb Compatibility. This image demonstrates the fan with its lights off and on, emphasizing the E26 ceramic lamp holders. It also displays various types of E26 bulbs that are compatible with the fan, reminding users that bulbs are not included.

5. Final Assembly

Once wiring is complete and bulbs are installed, carefully push the fan unit up to the mounting bracket and secure it with the designated screws. Ensure all connections are tucked safely within the electrical box.

IMPORTANT: After installation, restore power at the circuit breaker and test the fan and lights.

OPERATING INSTRUCTIONS

Your SHLUCE ceiling fan is controlled by the included remote control. Ensure batteries are installed in the remote (batteries not included).

Remote Control Functions



Figure 3: Fan Operation with Remote Control. This image displays the ceiling fan in operation, with visible airflow, and highlights the remote control used to manage its functions.

- **ALL OFF:** Turns off both fan and lights.
- **LIGHT ON/OFF:** Toggles the light on or off.
- **FAN ON/OFF:** Toggles the fan on or off.
- **Fan Speed (1-6):** Adjusts the fan speed from 1 (lowest) to 6 (highest).
- **Timing (1H/2H/4H):** Sets the fan to turn off automatically after 1, 2, or 4 hours.
- **F/R (Forward/Reverse):** Changes the direction of the fan rotation for summer or winter mode.

Fan Speed Settings



Figure 4: Fan Speed and Timing Features. This image illustrates the fan's 6-speed capability, categorized into Gentle (speeds 1-2), Comfortable (speeds 3-4), and Strong (speeds 5-6) wind settings. It also highlights the ultra-quiet operation and timing functions.

The fan offers 6 distinct speeds, allowing you to customize airflow to your preference:

- **Speeds 1-2:** Gentle wind, ideal for light air circulation.
- **Speeds 3-4:** Comfortable wind, suitable for general use.
- **Speeds 5-6:** Strong wind, for maximum cooling effect.

Reversible Motor Function

Reversible Motor



Figure 5: Reversible Motor Modes. This image visually explains the two modes of the reversible motor: Downdraft Mode, which pushes cold air down for summer cooling, and Updraft Mode, which circulates warm air upwards for better heat distribution in winter.

The fan features a reversible motor, allowing for year-round comfort:

- **Downdraft Mode (Summer):** The fan blades rotate counter-clockwise, pushing cool air downwards to create a cooling effect.
- **Updraft Mode (Winter):** The fan blades rotate clockwise, drawing air up towards the ceiling to circulate warm air trapped near the ceiling, distributing it throughout the room.

To change direction, press the F/R button on the remote control while the fan is running.

MAINTENANCE

Regular maintenance will help prolong the life and performance of your ceiling fan.

- **Cleaning:** To clean the fan, wipe with a soft, damp cloth. Do not use abrasive cleaners or solvents, as these may damage the finish. Ensure power is off before cleaning.
- **Bulb Replacement:** When replacing light bulbs, ensure the power is off. Allow bulbs to cool before touching. Use only E26 base bulbs.

- **Tightening Screws:** Periodically check all screws on the fan and mounting bracket to ensure they are tight. Loose connections can cause noise or malfunction.

TROUBLESHOOTING

If you experience issues with your fan, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Fan does not start.	No power to the fan; Loose wire connections; Remote control battery low or dead.	Check circuit breaker; Verify all wire connections are secure; Replace remote control batteries.
Lights do not turn on.	Bulbs are loose or burnt out; Wiring issue; Remote control battery low.	Tighten or replace bulbs; Check light wiring connections; Replace remote control batteries.
Fan makes excessive noise.	Loose mounting screws; Fan blades unbalanced; Obstruction in the fan cage.	Tighten all mounting screws; Ensure blades are securely attached; Remove any obstructions.
Remote control not working.	Dead batteries; Remote not paired (if applicable); Obstruction between remote and receiver.	Replace batteries; Refer to pairing instructions (if applicable, not detailed here); Ensure clear line of sight.

If the problem persists after attempting these solutions, please contact customer support.

SPECIFICATIONS

Feature	Detail
Brand	SHLUCE
Model Number	FLA001
Dimensions (L x W x H)	45.97 x 45.97 x 24.13 cm (approx. 18.1 x 18.1 x 9.5 inches)
Weight	4.22 Kilograms (approx. 9.3 pounds)
Power	60 Watts
Voltage	110 Volts
Fan Design	Flush Mount Caged Ceiling Fan
Light Base	E26 (4 bulbs required, not included)
Fan Speeds	6 Speeds + Natural Wind
Motor Type	Reversible, Ultra-quiet
Timing Function	1H / 2H / 4H

WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the product packaging or contact the manufacturer directly. Keep your purchase receipt as proof of purchase.

For further assistance, you may also visit the product page on Amazon.com.be:[Product Link](#)