

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [aarke](#) /
- › [Aarke Stainless Steel Kettle Model A1244 User Manual](#)

## aarke A1244

# Aarke Stainless Steel Kettle Model A1244 User Manual

Model: A1244 | Brand: Aarke

## 1. INTRODUCTION

---

This manual provides essential information for the safe and efficient operation, maintenance, and care of your Aarke Stainless Steel Kettle Model A1244. Please read all instructions carefully before first use and retain this manual for future reference.



Image 1.1: Front view of the Aarke Stainless Steel Kettle.

The Aarke Kettle is designed for heating water with precision temperature control, featuring a double-wall construction for heat retention and a non-drip spout for controlled pouring. It includes safety features such as dry boil protection and a heat-safe handle.

## 2. SAFETY INSTRUCTIONS

### Important Safeguards:

- Read all instructions before using the kettle.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against fire, electric shock, and injury to persons, do not immerse cord, plugs, or the kettle base in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts, and before cleaning the appliance.
- Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions, or has been damaged in any manner. Contact Aarke customer support for examination, repair, or adjustment.

- The use of accessory attachments not recommended by the appliance manufacturer may result in fire, electric shock, or injury to persons.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to "off", then remove plug from wall outlet.
- Do not use appliance for other than intended use.
- Exercise extreme caution when moving an appliance containing hot water.
- The kettle is equipped with **dry boil protection**. If the kettle is accidentally switched on without water, it will automatically shut off. Allow it to cool down before refilling.

### 3. WHAT'S IN THE BOX

Upon unpacking, please ensure all components are present and in good condition:

- Aarke Kettle (Stainless Steel)
- 360° Swivel Base with Cord Winder
- Removable Limescale Filter (Stainless Steel)
- Instructions Manual (this document)
- Aarke Cleaning Cloth

## SPECIFICATIONS

### Material:

Stainless steel

### Weight:

~ 1.7 kg / 3.6 lbs


### Capacity:

1,2 L / 40.6 fl oz

### Included in the box:

- Temperature control kettle
- 360° swivel base with cord & cord winder
- Removable stainless steel limescale filter
- Manual & cleaning cloth

27 cm / 10.6 in



19 cm / 7.5 in

Image 3.1: Diagram illustrating the Aarke Kettle and its included accessories.

## 4. SETUP

---

1. **Placement:** Place the kettle base on a dry, flat, and stable surface away from the edge of the counter. Ensure it is not near heat sources or water.
2. **Cord Management:** Unwind the power cord from the cord winder located under the base to the desired length. Plug the power cord into a grounded electrical outlet.
3. **Initial Cleaning:** Before first use, fill the kettle with cold water to the MAX fill line. Boil the water (see Operating Instructions) and then discard it. Repeat this process twice to ensure the kettle is clean.

## 5. OPERATING INSTRUCTIONS

---

### 5.1 Filling the Kettle

1. Remove the kettle from its base.
2. Open the lid by pressing the lid release button.
3. Fill the kettle with fresh, cold water. Do not fill below the MIN mark or above the MAX mark indicated inside the kettle. Overfilling may cause boiling water to spill out.
4. Close the lid securely.
5. Place the kettle back onto its 360° swivel base.

An electric  
kettle crafted in  
stainless steel



Image 5.1: The Aarke Kettle positioned on a counter.

## 5.2 Selecting Temperature and Boiling

The Aarke Kettle offers multiple temperature settings for various beverages and uses.

1. With the kettle on its base and filled with water, press the power button to turn it on.
2. Rotate the temperature selection dial on the base to choose your desired temperature: 104°F (40°C), 167°F (75°C), 185°F (85°C), 203°F (95°C), or 212°F (100°C). An LED indicator will illuminate next to the selected temperature.
3. The kettle will begin heating the water. The LED indicator will flash during heating and remain solid once the target temperature is reached. The kettle will emit an audible signal when the heating cycle is complete.
4. The kettle features a **memory function**, which remembers your last selected temperature setting for convenience.

Multiple temperature settings with LED cool-down temperature indicator



Image 5.2: Temperature selection dial with LED cool-down indicator.

### 5.3 Pouring

The kettle's non-drip spout is designed for precise pouring.

1. Carefully lift the kettle from its base using the heat-safe handle.
2. Pour the hot water slowly and steadily. The precision spout minimizes drips and splashes.
3. After pouring, return the kettle to its base.

Non-drip spout for  
perfect pouring



Image 5.3: Demonstrating the non-drip spout for perfect pouring.

## 6. MAINTENANCE AND CLEANING

Regular cleaning and maintenance will ensure the longevity and optimal performance of your Aarke Kettle.

### 6.1 Exterior Cleaning

- Always unplug the kettle and allow it to cool completely before cleaning.
- Wipe the exterior of the kettle and the base with a soft, damp cloth. For stubborn marks, use the provided Aarke cleaning cloth or a mild, non-abrasive cleaner.
- Do not use harsh chemicals, abrasive cleaning pads, or metal brushes, as these can damage the stainless steel finish.
- Ensure all surfaces are thoroughly dried after cleaning.

### 6.2 Interior Cleaning and Descaling

The kettle's wide opening and hidden heating element make interior cleaning effortless. Regular descaling is important, especially in areas with hard water.

- **Hand Wash Only:** The kettle is not dishwasher safe.
- **General Cleaning:** For general cleaning, wipe the interior with a soft cloth and warm, soapy water.

Rinse thoroughly.

- **Descaling:** Limescale buildup can affect performance. To descale, fill the kettle with a solution of water and white vinegar (1:1 ratio) or a commercial descaling agent according to its instructions. Bring the solution to a boil and let it stand for at least 30 minutes, or longer for heavy buildup. Empty the kettle and rinse thoroughly several times with fresh water.
- **Removable Limescale Filter:** The stainless steel filter can be removed for cleaning. Rinse it under running water and gently brush away any limescale deposits. Ensure it is properly reinserted before use.



Image 6.1: Interior view showing the removable limescale filter.

## 7. TROUBLESHOOTING

If you encounter issues with your Aarke Kettle, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
---------	----------------	----------

<b>Problem</b>	<b>Possible Cause</b>	<b>Solution</b>
Kettle does not heat up.	Not plugged in; power outage; kettle not properly seated on base; dry boil protection activated.	Check power connection; ensure kettle is correctly placed on base; if dry boil protection activated, allow to cool before refilling.
Water takes too long to boil.	Limescale buildup; low power supply.	Descal the kettle (see Section 6.2); ensure kettle is plugged into a suitable power outlet.
Kettle leaks.	Overfilled; lid not properly closed.	Do not fill above the MAX line; ensure lid is securely closed. If leaking persists, contact support.
Water has an unusual taste.	New kettle residue; limescale buildup; water quality.	Perform initial cleaning steps again; descale the kettle; use filtered water.
LED indicators not working correctly.	Electrical malfunction.	Unplug and replug the kettle. If the issue persists, contact Aarke customer support.

If the problem persists after attempting these solutions, please contact Aarke customer support.

## 8. SPECIFICATIONS

<b>Feature</b>	<b>Detail</b>
Brand	Aarke
Model Name	Kettle
Item Model Number	A1244
Color	Steel
Material	Polypropylene (PP), Silicone, Stainless Steel
Capacity	1.2 Liters (40.6 fl oz)
Product Dimensions	5.5"L x 7.5"W x 10.6"H (14cm L x 19cm W x 27cm H)
Item Weight	3.66 pounds (1.66 kg)
Special Feature	Double Wall, Precision Temperature Control, Non-Drip Spout, Dry Boil Protection, LED Cool-Down Indicator, Memory Function
Finish Type	Polished
Recommended Uses	Boiling, Heating Water for Coffee and Tea

Feature	Detail
Product Care Instructions	Hand Wash
Manufacturer	Aarke AB

## 9. WARRANTY AND SUPPORT

---

Aarke products are designed and engineered in Sweden with a focus on quality and durability. For specific warranty information regarding your Aarke Stainless Steel Kettle Model A1244, please refer to the warranty card included with your product or visit the official Aarke website.

For technical support, troubleshooting assistance beyond this manual, or to inquire about replacement parts, please contact Aarke customer support through their official channels. Keep your purchase receipt and model number (A1244) handy when contacting support.

**Online Support:** [aarke.com/support](https://aarke.com/support)