

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [HOOBRO](#) /

› [HOOBRO Foldable C-Shaped End Table DM29SF01 Instruction Manual](#)

HOOBRO DM29SF01

HOOBRO Foldable C-Shaped End Table

Model: DM29SF01

Brand: HOOBRO

1. INTRODUCTION

Thank you for choosing the HOOBRO Foldable C-Shaped End Table. This versatile and compact table is designed to enhance your living space with its functional design, including a foldable tabletop and a convenient storage shelf. This manual provides essential information for safe assembly, proper usage, and maintenance to ensure long-lasting enjoyment of your product.



Image 1: HOOBRO Foldable C-Shaped End Table (Marble + Gold)

2. SAFETY INFORMATION

- Always follow the assembly instructions carefully.
- This table may be heavy when fully assembled, so ensure it is properly anchored to prevent tipping or collapse.
- Keep fingers and other body parts away from pinch points during assembly and when operating the foldable tabletop.
- Do not exceed the maximum weight recommendation of 50 pounds (22.7 kg).
- Place the table on a level surface to prevent instability.
- Keep away from open flames and direct heat sources.

3. PACKAGE CONTENTS


Please verify that all components are present before beginning assembly. If any parts are missing or damaged, please contact customer support.

Part	Description	Quantity
A	Main Tabletop (Foldable)	1
B	Storage Shelf	1
C	Left Frame Leg	1
D	Right Frame Leg	1
E	Bottom Support Bar	1
F	Adjustable Feet	4
G	Screws (various sizes)	Set
H	Allen Wrench / Screwdriver	1

4. ASSEMBLY INSTRUCTIONS

Assembly is designed to be straightforward. Please follow these steps carefully. A screwdriver (Part H) is recommended for assembly.

- 1. Prepare the Frame:** Attach the Left Frame Leg (C) and Right Frame Leg (D) to the Bottom Support Bar (E) using the appropriate screws (G). Ensure all connections are secure but do not overtighten yet.
- 2. Install Adjustable Feet:** Screw the Adjustable Feet (F) into the bottom of the assembled frame. These can be adjusted later to level the table on uneven surfaces.
- 3. Attach Storage Shelf:** Secure the Storage Shelf (B) between the Left Frame Leg (C) and Right Frame Leg (D) at the designated height using screws (G).
- 4. Mount the Tabletop:** Carefully align the Main Tabletop (A) with the top of the frame legs. Secure it in place using the remaining screws (G). Ensure the foldable section is oriented correctly.
- 5. Final Tightening:** Once all parts are assembled, gently tighten all screws to ensure stability. Avoid overtightening to prevent damage.



Strong Metal Hinges



Storage Rack



Adjustable Feet

Image 2: Key features including strong metal hinges, storage rack, and adjustable feet.




Image 3: Detail of the 360-degree adjustable feet for leveling.

5. OPERATING INSTRUCTIONS

5.1 Using the Foldable Tabletop

The main tabletop features a foldable extension to provide additional surface area when needed. To extend, gently lift the hinged section of the tabletop and unfold it until it lies flat. To fold, lift the extended section slightly and fold it back down onto the main tabletop. Ensure the hinges operate smoothly and do not force the mechanism.




Image 4: Table dimensions, illustrating the foldable tabletop in both compact and extended positions.



Image 5: Detail of the strong metal hinges for the foldable tabletop.

5.2 Adjusting for Uneven Floors

The table is equipped with adjustable feet to ensure stability on uneven surfaces. Rotate each foot clockwise or counter-clockwise to raise or lower the corresponding corner of the table until it is level and stable.

5.3 Placement and Usage

The C-shaped design allows the table to slide under sofas or beds, making it ideal for small spaces. Use it as a snack table, a laptop stand, or a convenient surface for remote controls and books. The integrated storage shelf provides additional space for small items.



Image 6: Table positioned next to a bed, holding a laptop.

For Tight Spaces

Slim and sleek enough to amplify small spaces like apartments or dorms.



Image 7: Table used in a living room, highlighting its suitability for tight spaces.

6. MAINTENANCE

- **Cleaning:** Wipe the table surfaces with a soft, damp cloth. Avoid abrasive cleaners or harsh chemicals that may damage the finish.
- **Spills:** Clean up spills immediately to prevent staining, especially on the engineered wood tabletop.
- **Hardware:** Periodically check all screws and connections to ensure they remain tight. Retighten as necessary.
- **Hinges:** Keep the foldable tabletop hinges clean and free of debris to ensure smooth operation.

7. TROUBLESHOOTING

- **Table is Wobbly:** Check if the adjustable feet are properly leveled. Adjust each foot until the table is stable. Ensure all assembly screws are tightened.
- **Difficulty Folding/Unfolding Tabletop:** Ensure no objects are obstructing the hinges. Check if the hinges are clean and free of debris. Do not force the mechanism.

- **Scratches on Floor:** The adjustable feet are designed to protect floors. If scratches occur, ensure the feet are clean and consider adding felt pads for extra protection.

8. SPECIFICATIONS

Feature	Detail
Brand	HOOBRO
Model Name	C Shaped End Table
Model Number	DM29SF01
Product Dimensions (D x W x H)	10.2" x 15.4" x 25.2" (25.9 cm x 39.1 cm x 64 cm)
Extended Length	20.5" (52.1 cm)
Item Weight	10.6 Pounds (4.8 kg)
Maximum Weight Recommendation	50 Pounds (22.7 kg)
Frame Material	Metal
Top Material Type	Engineered Wood
Color	Marble + Gold
Is Foldable	Yes
Required Assembly	Yes
Indoor Outdoor Usage	Indoor

9. WARRANTY AND SUPPORT

HOOBRO products are designed for quality and durability. For any questions, missing parts, or issues with your product, please contact HOOBRO customer support. Please retain your proof of purchase for warranty claims.

For further assistance, visit the [HOOBRO Store on Amazon](#).