

[Manuals.plus](#) /

> [oneinmil](#) /

> oneinmil 70-Inch Fireplace TV Stand Model 21032 User Manual

oneinmil 21032

oneinmil 70-Inch Fireplace TV Stand User Manual

Model: 21032 | Brand: oneinmil

1. INTRODUCTION

This manual provides detailed instructions for the assembly, operation, and maintenance of your oneinmil 70-Inch Fireplace TV Stand, Model 21032. Please read this manual thoroughly before assembly and use to ensure safe and correct operation of the product.



Image 1.1: The oneinmil 70-Inch Fireplace TV Stand, Model 21032, featuring a central electric fireplace and side storage cabinets.

2. SAFETY INFORMATION

WARNING: Assembly and usage instructions include safety precautions for the glass fireplace and proper handling of the product to prevent injuries. Always follow the provided instructions for safe use and maintenance.

- Ensure all components are securely fastened before use.
- Do not overload the tabletop or shelves beyond their specified weight capacities.
- Keep flammable materials away from the electric fireplace.
- Always unplug the fireplace unit before cleaning or maintenance.
- Supervise children and pets around the fireplace unit.

3. PACKAGE CONTENTS

Verify that all parts are present before beginning assembly. If any parts are missing or damaged, contact customer support immediately.

- Main TV Stand Panels (Top, Bottom, Sides, Shelves, Back Panels)
- Electric Fireplace Insert
- Glass Doors and Hinges
- Assembly Hardware (Screws, Dowels, Cam Locks, etc.)
- LED Light Strips
- Fireplace Remote Control
- Instruction Manual (this document)



Image 3.1: The product is shipped in two separate boxes, which may arrive on different days.

4. ASSEMBLY INSTRUCTIONS

Assembly of the oneinmil Fireplace TV Stand is designed to be straightforward. We recommend two people for assembly to ensure stability and ease of handling. All hardware and parts are clearly numbered for easy identification.

1. **Unpack and Identify Parts:** Carefully unpack all components and lay them out on a clean, soft surface to prevent scratches. Refer to the included parts list to identify each piece.
2. **Assemble the Main Frame:** Follow the step-by-step diagrams provided in the separate assembly guide. Secure the base, side panels, and central support structures using the designated hardware.
3. **Install Shelves:** Insert the adjustable shelves into the side cabinets as desired.
4. **Attach Glass Doors:** Mount the glass doors to the side cabinets using the provided hinges. Ensure they open and close smoothly.
5. **Insert Electric Fireplace:** Carefully slide the electric fireplace insert into the central opening. Secure it according to the fireplace unit's specific instructions.
6. **Install LED Light Strips:** Attach the LED light strips to the designated areas, typically inside the side cabinets, using their adhesive backing. Connect them to the power source as instructed.
7. **Final Checks:** Verify all connections are tight and the stand is stable.

70" Farmhouse Fireplace TV Stand



SOLID AND STABLE BASE

THE 3.3-INCH HIGH WOODEN BASE ENSURES STABILITY AND NO WOBBLING

HIGH-GRADE MDF

THE BOARD IS THICKENED AND UPGRADED, WITH WATERPROOF AND SCRATCH-RESISTANT FUNCTIONS




ADJUSTABLE SHELVES

ADJUSTABLE SHELVES FOR FLEXIBLE AND CUSTOMIZABLE STORAGE


Image 4.1: Key features for assembly and durability: solid base, high-grade MDF, and adjustable shelves.

36" ALL-GLASS FIREPLACE



 Adjustable timer settings from 0.5H-9H

 5-brightness of flame

 With back led lights



WITH THREE KINDS OF FLAME COLOR



Image 4.2: Components and features including particle board construction, glass doors, and cable management.

5. OPERATING INSTRUCTIONS

Your oneinmil Fireplace TV Stand includes an integrated electric fireplace with various settings and LED lighting.

5.1 Electric Fireplace Operation


The 24-inch electric fireplace can be controlled via the unit's panel or the included remote control.

- **Flame Brightness:** Choose from 5 settings (L1 to L5) to adjust the intensity of the flame effect.
- **Flame Colors:** Select from 12 different flame colors to match your ambiance.
- **Backlight Colors:** The fireplace features 12 colors for its backlight.
- **Temperature Control:** Adjust the heating temperature from 65°F to 95°F. The fireplace provides 5000 BTU auxiliary heating for areas up to 400 square feet.
- **Timer Function:** Set the operational timer from 0.5 to 9 hours for automatic shut-off.
- **Heat Modes:** Select between 1000W and 1500W heat output modes.
- **Safety Features:** Equipped with Thermal Overload Protection and CSA/UL certifications.

PANORAMIC FIREPLACE



5-LEVEL FLAME BRIGHTNESS



12 FLAME COLORS



Image 5.1: Fireplace flame brightness levels and color options.

36 INCH PANORAMIC FIREPLACE

5000 BTU CAN PROVIDE AUXILIARY HEATING
FOR A 400 SQUARE FEET SPACE



1000W/1500W
2 Heat Modes



60°F-99°F
Temperature



0.5H-9H Timer
Function



Thermal Overload
Protection



CSA/UL
Certificated



Image 5.2: Electric fireplace heating capabilities and safety certifications.

5.2 LED Light Strip Operation

The multi-color LED light strips can be customized to create various room atmospheres.

- Use the dedicated remote control or integrated buttons to cycle through different colors and lighting modes.
- Adjust brightness as desired.

MULTI-COLOR LED LIGHT STRIP

LED lights in multiple colors customize the various atmospheres of the room.



Image 5.3: Multi-color LED light strip customization options.

6. MAINTENANCE

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners. For the glass doors, use a glass cleaner.
- **Fireplace Unit:** Ensure the fireplace air inlets and outlets are clear of obstructions. Regularly check for dust accumulation. A user review suggests placing a filter media over the air inlet for the heater blower to prevent pet hair accumulation and extend motor life.
- **Hardware:** Periodically check and tighten any loose screws or connections.

7. TROUBLESHOOTING

- **Fireplace Not Turning On:**
 - Ensure the power cord is securely plugged into a functional outlet.
 - Check if the circuit breaker has tripped.

- Verify the power switch on the fireplace unit is in the "ON" position.

- **No Heat Output:**

- Confirm the heat function is activated and the temperature setting is above the ambient room temperature.
- Check for any obstructions around the heater's air vents.

- **Remote Control Not Working:**

- Replace the batteries in the remote control.
- Ensure there are no obstructions between the remote and the fireplace unit's sensor.

- **Wobbly Stand:**

- Re-tighten all assembly screws.
- Ensure the stand is placed on a level surface.

For issues not covered here, please contact oneinmil customer support.

8. SPECIFICATIONS

Feature	Detail
Model Number	21032
Brand	oneinmil
Material	Engineered Wood (PB+MDF)
Overall Dimensions (L x W x H)	70 x 13.7 x 31.5 inches
Item Weight	161 pounds
Tabletop Weight Capacity	150 lbs
Shelf Weight Capacity	30 lbs
Electric Fireplace Dimensions	36" L x 7.97" W x 18.3" H (approx. 24-inch visible area)
Heat Output	5000 BTU (1000W/1500W)
Heating Area	Up to 400 square feet
Temperature Range	65°F to 95°F
Timer Settings	0.5 to 9 hours
Flame Brightness Settings	5 levels
Flame Colors	12 colors
Backlight/LED Colors	12 colors
Certifications	CSA/UL
UPC	724156709074

70 Inch Fireplace TV Stand

Shipped in two boxes, may be shipped separately

- Tabletop weight capacity: **150 Lbs**
- Shelves weight capacity: **30 Lbs**
- Size: **70"W × 13.8"D × 31.4"H**



Image 8.1: Product dimensions and weight capacities.



Image 8.2: Visual guide for compatible TV sizes up to 80 inches.

9. WARRANTY AND SUPPORT

For any questions, missing parts, or assistance with assembly or operation, please contact oneinmil customer support. While specific warranty details are not provided in this manual, please retain your proof of purchase for any potential warranty claims.

Contact Information: Refer to your purchase documentation or the oneinmil official website for customer service contact details.