

ACHAZEL B0CWL2GPKP

ACHAZEL 4,129 CFM Evaporative Air Cooler User Manual

Model: B0CWL2GPKP

1. INTRODUCTION

Thank you for choosing the ACHAZEL 4,129 CFM Evaporative Air Cooler. This manual provides essential information for the safe operation, maintenance, and troubleshooting of your new appliance. Please read it thoroughly before use and retain it for future reference.



Image 1.1: The ACHAZEL 4,129 CFM Evaporative Air Cooler, demonstrating its powerful airflow and large 13.21-gallon water tank capacity.

2. SAFETY INSTRUCTIONS

To reduce the risk of fire, electric shock, or injury, always follow these basic safety precautions:

- Read all instructions before using this appliance.
- Ensure the power supply matches the voltage specified on the appliance's rating label.
- Do not operate the cooler with a damaged cord or plug. If the cord or plug is damaged, contact customer support.
- Always unplug the appliance before filling, cleaning, or performing any maintenance.
- Do not immerse the appliance, cord, or plug in water or other liquids.
- Keep the appliance away from heat sources, direct sunlight, and flammable materials.
- Ensure the appliance is placed on a stable, level surface to prevent tipping.
- Do not block air inlets or outlets. Maintain adequate clearance around the unit for proper airflow.
- Do not allow children or pets to play with or near the appliance.

- Use only clean water in the water tank. Do not add any chemicals or additives unless specified by the manufacturer.
- Do not operate the cooling function without water in the tank.

3. PRODUCT FEATURES

Your ACHAZEL Evaporative Air Cooler is designed with advanced features for optimal cooling and convenience:

- **Efficient Cooling & Customized Air:** Boasting a powerful 4,129 CFM rating, our swamp cooler can cool a room up to 1076 sq. ft., 3 wind speeds and 1200 oscillation ensure even distribution of cool air. With 3 wind speeds, you can customize the evaporative air cooler according to your preferences. The wind direction can be adjusted up and down manually and left and right automatically to cool every corner quickly and evenly.
- **3-in-1 Swamp Air Cooler:** Designed with three modes (Fan/Humidity/Cooling), the portable swamp air cooler not only can achieve ultra-rapid cooling with 4 ice packs but also serves as a regular fan and a humidifier to save you from hot and dry room.
- **Excellent Cooling System:** With 3-side honeycomb cooling pads, the portable evaporative cooler outdoor is able to moisturize and cool down the air quickly. Powerful fan motors with 8-inch blades attached work together to ensure optimal airflow.
- **Manual Water Fill:** Featuring a large 13.21-gallon water tank, this swamp cooler works for 12 hours in cooling mode. Conveniently add water or ice through the top tank.
- **Portable & User-Friendly:** This portable evaporative cooler features 4 wheels (2 x 3600 universal wheels), allowing for easy relocation to any area you desire – be it your garage, patio, poolside, or living room. No complicated setup is required.

Widespread Coverage



Image 3.1: Visual representation of the cooler's widespread coverage and oscillation capabilities.

4. COMPONENTS AND PARTS LIST

The package includes the following components:

- AHAZEL Evaporative Air Cooler Unit
- Power Cord
- User Manual (this document)
- 4 x Ice Packs

5. SETUP

1. **Unpacking:** Carefully remove the air cooler from its packaging. Retain the packaging for storage or future transport.
2. **Placement:** Place the cooler on a firm, level surface. Ensure there is adequate space around the unit for proper air circulation. The built-in 3600 universal wheels allow for easy movement.

3. Filling the Water Tank:

- Locate the top water inlet.
- Manually fill the 13.21-gallon water tank with clean, cool water. Do not exceed the 'MAX' fill line indicated on the water level indicator.
- For enhanced cooling, place the provided ice packs (after freezing) into the designated compartments in the top tank.



Image 5.1: The 13.21-gallon water tank and manual fill points for water and ice packs.

4. **Power Connection:** Plug the power cord into a grounded electrical outlet.

6. OPERATING INSTRUCTIONS

Your ACHAZEL Evaporative Air Cooler features simple knob controls for ease of use.

1. **Power On/Off:** Turn the 'COOL' knob to the 'COOL' position to activate the cooling function, or turn the 'SWING' knob to a speed setting to activate the fan. Turn both knobs to 'OFF' to power off the unit.
2. **Adjusting Fan Speed:** Use the 'SWING' knob to select one of the 3 available fan speeds (1, 2, or 3).
3. **Oscillation Control:**

- The 'SWING' knob also controls the 1200 automatic oscillation. Select a speed setting to enable automatic left-to-right swing.
- The vertical louvers can be adjusted manually to direct airflow up or down.

4. Selecting Operating Mode:

- **Fan Mode:** Turn the 'SWING' knob to a desired speed (1, 2, or 3) and ensure the 'COOL' knob is in the 'OFF' position.
- **Humidify Mode:** This mode is active when the unit is running with water in the tank, even if the 'COOL' function is off. The evaporative process naturally adds humidity to the air.
- **Cooling Mode:** Turn the 'COOL' knob to the 'COOL' position. Ensure the water tank is filled. For optimal cooling, use ice packs or add ice to the water tank.



Image 6.1: Close-up of the control panel with knobs for speed/swing and cooling mode.

Official Product Video

Video 6.1: An official product video demonstrating the features and operation of the ACHAZEL 4,129 CFM Evaporative Air Cooler, including its portability, water filling, and control functions.

7. MAINTENANCE

Regular maintenance ensures optimal performance and extends the lifespan of your air cooler.

1. Water Tank Cleaning:

- Unplug the unit before cleaning.
- Regularly drain the water tank using the drain plug located at the bottom rear of the unit.
- Clean the tank with a soft cloth and mild detergent. Rinse thoroughly to remove any residue.

2. Honeycomb Cooling Pads:

- The 3-side honeycomb cooling pads should be inspected periodically for mineral buildup or debris.
- Refer to the diagram in the manual for instructions on how to remove and clean the pads. Gently rinse them with water.
- Allow the pads to dry completely before reinserting them.



Image 7.1: The 3-side honeycomb cooling pads, essential for the evaporative cooling process.

3. **Exterior Cleaning:** Wipe the exterior of the unit with a soft, damp cloth. Do not use abrasive cleaners or solvents.
4. **Storage:** If storing the unit for an extended period, ensure the water tank is completely empty and dry.

Clean all components and store the unit in a cool, dry place.

8. TROUBLESHOOTING

If you encounter issues with your air cooler, please refer to the following common problems and solutions:

- **Unit does not turn on:**
 - Check if the power cord is securely plugged into a working outlet.
 - Ensure the power knobs are turned to an 'ON' position.
- **No cool air:**
 - Verify that the water tank is filled and the 'COOL' mode is activated.
 - Check if the honeycomb cooling pads are wet and properly installed.
 - Ensure the ice packs are frozen and placed in the tank if enhanced cooling is desired.
 - Evaporative coolers work best in dry climates. In high humidity, their cooling effect may be less noticeable.
- **Reduced airflow:**
 - Check for any obstructions in the air inlets or outlets.
 - Ensure the honeycomb cooling pads are clean and not clogged.
- **Unusual noise:**
 - Ensure the unit is on a stable, level surface.
 - Check if there are any foreign objects inside the unit or near the fan blades.
 - If the noise persists, contact customer support.

For issues not covered here, please contact ACHAZEL customer support.

9. SPECIFICATIONS

Feature	Specification
Brand	ACHAZEL
Model Number	B0CWL2GPKP
Mounting Type	Freestanding
Special Features	Adjustable Speed, Built-In Wheel
Color	White
Air Flow Capacity	4129 Cubic Feet Per Minute (CFM)
Controls Type	Knob
Reservoir Capacity	13.21 Gallons
Floor Area Coverage	1076 Square Feet

Feature	Specification
Recommended Uses	Commercial, Industrial, Residential
Product Dimensions	15.75"D x 22.83"W x 46.46"H
Voltage	120 Volts
Item Weight	51 pounds
Material Type	Plastic
First Available Date	February 27, 2024

DIMENSIONS




Image 9.1: Diagram illustrating the dimensions of the ACHAZEL Evaporative Air Cooler.

10. WARRANTY & SUPPORT

ACHAZEL is dedicated to providing high-quality products and stellar customer service. Your 4,129 CFM evaporative cooler comes with a **1-year warranty**, promising long-lasting performance.

If you have any questions, concerns, or require assistance with your product, please contact ACHAZEL Customer Support. We are committed to ensuring your satisfaction.

For further support, please visit the official ACHAZEL store or contact us through the platform where you purchased the product.