

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Indesit](#) /

› [Indesit UI6F2TWFR Upright Freezer User Manual](#)

## Indesit UI6F2TWFR

# Indesit UI6F2TWFR Upright Freezer User Manual

Model: UI6F2TWFR

## INTRODUCTION


This manual provides essential information for the safe and efficient operation of your Indesit UI6F2TWFR Upright Freezer. Please read these instructions carefully before installation and use, and keep them for future reference. The Indesit UI6F2TWFR is a 228-liter upright freezer featuring No Frost technology, designed for optimal food preservation and user convenience.

## SAFETY INFORMATION

- Ensure the appliance is unplugged before performing any maintenance or cleaning.
- Do not damage the refrigerant circuit.
- Do not use electrical appliances inside the food storage compartments, unless they are of the type recommended by the manufacturer.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Keep ventilation openings, in the appliance enclosure or in the built-in structure, clear of obstruction.
- Do not use mechanical devices or other means to accelerate the defrosting process, other than those recommended by the manufacturer.

## PRODUCT OVERVIEW

The Indesit UI6F2TWFR Upright Freezer offers a generous 228-liter capacity distributed across 4 drawers and 2 flaps, providing ample space for organized storage of frozen goods. Its No Frost system prevents ice build-up, eliminating the need for manual defrosting.



Front view of the Indesit UI6F2TWFR Upright Freezer with the door slightly open, revealing the transparent storage drawers inside.



Detailed interior view of the freezer, showcasing various food items neatly organized within the transparent drawers and flaps.



The Indesit UI6F2TWFR Upright Freezer with its door closed, highlighting its sleek white design and integrated handle.



The Indesit UI6F2TWFR Upright Freezer positioned in a contemporary kitchen, demonstrating its seamless integration into a home environment.

## SETUP AND INSTALLATION

---

### Placement

Place the freezer on a flat, stable surface away from direct sunlight, heat sources (like ovens or radiators), and areas with high humidity. Ensure adequate ventilation around the appliance. The 'zero déport' feature allows for installation flush against a wall.

### Leveling

Use the adjustable front feet to level the appliance. Proper leveling ensures efficient operation and prevents vibrations.

### Door Reversal

The door of the UI6F2TWFR is reversible, allowing you to change the opening direction to suit your kitchen layout. Refer to the detailed diagrams in the separate installation guide for specific instructions on reversing the door.

### Initial Power-On

After installation, wait at least 2-4 hours before plugging the appliance into the power outlet. This allows the refrigerant to settle. Once plugged in, the freezer will begin to cool. Allow it to run for several hours before loading with food.

## OPERATING INSTRUCTIONS

---

### Temperature Control

The freezer is equipped with a front display panel. Use this panel to adjust the temperature settings and activate special functions. Refer to the display icons for current temperature and active modes.

### No Frost Technology

The No Frost system circulates cold air throughout the freezer compartment, preventing the formation of ice and frost on food items and interior surfaces. This means manual defrosting is not required.

This video illustrates how No Frost technology works in a freezer, preventing ice build-up and eliminating the need for manual defrosting. It shows the internal air circulation that keeps the compartment frost-free.

### Quick Freeze Function

Activate the Quick Freeze function via the front display panel when adding a large quantity of fresh food to the freezer. This rapidly lowers the temperature to quickly freeze new items, preserving their quality. The function will automatically deactivate after a set period or can be manually turned off.

### Food Storage Tips

- Always store food in airtight containers or freezer bags to prevent freezer burn and odor transfer.
- Label and date all frozen items for easy identification and to ensure consumption within recommended storage times.
- Avoid overloading drawers to allow for proper air circulation.
- Distribute new items evenly to prevent temperature fluctuations.

## MAINTENANCE AND CLEANING

---

### Cleaning the Interior

Clean the interior of the freezer regularly with a solution of mild detergent and warm water. Avoid abrasive cleaners or solvents. Dry thoroughly after cleaning.

### Cleaning the Exterior

Wipe the exterior surfaces with a soft cloth dampened with water and a mild detergent. For stainless steel finishes, use a specialized cleaner and wipe in the direction of the grain. Do not use abrasive pads or cleaners.

### No Defrosting Required

Thanks to the No Frost technology, manual defrosting of the freezer compartment is not necessary. Any small amounts of frost that may appear will be automatically removed by the system.

## TROUBLESHOOTING

---

- **Freezer not cooling:** Check if the power cord is securely plugged in. Ensure the circuit breaker has not tripped. Verify the temperature setting is appropriate.

- **Excessive noise:** Ensure the freezer is level using the adjustable feet. Check if any items inside are vibrating against the walls or other items.
- **Door not closing properly:** Check for obstructions preventing the door from closing fully. Ensure door seals are clean and intact.
- **Temperature too high:** Avoid opening the door too frequently or for extended periods. Ensure the freezer is not overloaded. Check the ambient room temperature is within the recommended range.

For issues not resolved by these steps, please contact customer support.

## SPECIFICATIONS

Feature	Specification
Model Number	UI6F2TWFR
Dimensions (L x W x H)	59.5 x 64.5 x 167 cm
Weight	63 kg
Volume	228 liters
Energy Class	E
Noise Level	41 dB
Number of Drawers	4
Technology	No Frost
Door Reversibility	Yes

## WARRANTY INFORMATION

The Indesit UI6F2TWFR Upright Freezer comes with a **2-year manufacturer's warranty**. Additionally, a **30-day return policy** and standard legal guarantees apply. Please retain your proof of purchase for any warranty claims.

## CUSTOMER SUPPORT

For further assistance, technical support, or to inquire about spare parts, please refer to the contact information provided with your purchase documentation or visit the official Indesit website. When contacting support, please have your model number (UI6F2TWFR) and serial number ready.