

Manuals.plus /

› [Schecter](#) /

› [Schecter Stargazer 6 Electric Guitar - Gloss Black User Manual](#)

Schecter 675

Schecter Stargazer 6 Electric Guitar User Manual

MODEL: 675

[Introduction](#)

[Setup](#)

[Operating](#)

[Maintenance](#)

[Troubleshooting](#)

[Specifications](#)

[Warranty](#)

[Support](#)

1. Introduction

Welcome to the Schecter Stargazer 6 Electric Guitar user manual. This guide provides essential information for the setup, operation, maintenance, and troubleshooting of your new instrument. The Schecter Stargazer 6 is designed for versatile performance, featuring a mahogany body, maple neck, and two humbucking pickups, all finished in a sleek gloss black.



This image shows the front of the Schecter Stargazer 6 Electric Guitar, featuring its gloss black finish, white pickguard, two humbucking pickups, and maple fretboard with block inlays.

2. Setup

Proper setup ensures optimal playability and tone from your Schecter Stargazer 6.

- 1. Unpacking:** Carefully remove the guitar from its packaging. Inspect for any signs of damage during transit. Retain all packaging materials for future transport or storage.
- 2. Initial Inspection:** Check all hardware components, including tuners, bridge, pickups, and control knobs, to ensure they are secure. Verify that the strings are properly seated.
- 3. Tuning:** Use an electronic tuner to accurately tune your guitar to standard EADGBe tuning. Fine-tune each string until

the desired pitch is achieved.

4. **Connecting to an Amplifier:** Connect a standard 1/4-inch instrument cable from the guitar's output jack to your amplifier's input. Ensure your amplifier is powered on and set to a low volume before playing.

3. Operating Your Guitar

Familiarize yourself with the controls of your Stargazer 6 to explore its sonic capabilities.

- **Volume Knobs:** The guitar features individual volume controls for each humbucking pickup. Rotate clockwise to increase volume and counter-clockwise to decrease.
- **Tone Knobs:** Individual tone controls for each pickup allow you to shape the treble response. Turning clockwise brightens the tone, while counter-clockwise rolls off high frequencies for a warmer sound.
- **Pickup Selector Switch:** This 3-way toggle switch allows you to select different pickup configurations:
 - *Up Position:* Neck pickup only (for warmer, smoother tones).
 - *Middle Position:* Both neck and bridge pickups (for a fuller, balanced sound).
 - *Down Position:* Bridge pickup only (for brighter, more aggressive tones).

4. Maintenance

Regular maintenance will preserve the condition and playability of your instrument.

- **Cleaning the Body:** Use a soft, lint-free cloth to wipe down the gloss black finish after each use to remove fingerprints and sweat. For deeper cleaning, use a guitar-specific polish.
- **Fretboard Care:** The maple fretboard should be kept clean. Periodically wipe it with a clean, dry cloth. Avoid excessive moisture.
- **String Replacement:** Strings should be replaced regularly, depending on usage, to maintain optimal tone and intonation. Replace one string at a time to maintain neck tension.
- **Hardware:** Periodically check all screws and nuts for tightness. Do not overtighten.
- **Storage:** Store your guitar in a stable environment, away from extreme temperature changes and humidity fluctuations, preferably in a guitar case.

5. Troubleshooting

Here are solutions to common issues you might encounter.

- **No Sound:**
 - Ensure the instrument cable is securely connected at both the guitar and amplifier.
 - Check that the amplifier is powered on and its volume is not at zero.
 - Verify the guitar's volume knobs are turned up and the pickup selector is engaged.
 - Test with a different cable or amplifier if available.
- **Buzzing or Fret Noise:**
 - Check for proper finger placement when fretting notes.
 - Ensure strings are not too old or worn.
 - Excessive buzzing may indicate a need for a professional setup (truss rod adjustment, action adjustment).
- **Poor Tuning Stability:**
 - Ensure strings are properly stretched after installation.

- Check that tuning machine screws are snug.
- Verify the nut slots are not binding the strings.

6. Specifications

Brand	Schecter
Model Number	675
Color	Gloss Black
Body Material	Mahogany
Fretboard Material	Maple Wood
Pickup Configuration	H-H (2 Humbucking Pickups)
Bridge System	Fixed
String Material Type	Alloy Steel
Item Weight	10.4 Pounds
Item Dimensions	43.1 x 17.6 x 4 inches

7. Warranty Information

The Schecter Stargazer 6 Electric Guitar comes with a 2-year warranty. Please retain your proof of purchase for any warranty claims. For detailed terms and conditions, refer to the official Schecter website or contact customer support.

8. Customer Support

If you require further assistance or have questions not covered in this manual, please visit the official Schecter website for support resources, FAQs, and contact information. You may also reach out to your authorized Schecter dealer for technical support and service.