

[Manuals.plus](#) /

› [Electro-Voice](#) /

› Electro-Voice ZLX-15P-G2 15-inch Powered Loudspeaker User Manual

Electro-Voice ZLX-15P-G2

Electro-Voice ZLX-15P-G2 15-inch Powered Loudspeaker User Manual

Model: ZLX-15P-G2 | Brand: Electro-Voice

1. INTRODUCTION

The Electro-Voice ZLX-15P-G2 is a 15-inch 2-way powered loudspeaker with integrated Bluetooth connectivity. This second-generation ZLX series loudspeaker offers enhanced features and functionality, delivering high sound pressure level (SPL) output and an extended frequency response for clear, room-filling audio. Designed for durability and portability, it is suitable for various professional audio applications.

2. WHAT'S IN THE BOX

- ZLX-15P-G2 Powered Loudspeaker
- Power Cable
- User Manual (this document)

3. SETUP

3.1 Unpacking and Inspection

Carefully remove the loudspeaker from its packaging. Inspect the unit for any signs of damage that may have occurred during transit. Retain the packaging for future transport or storage.

3.2 Placement and Mounting

The ZLX-15P-G2 can be used as a floor-standing speaker or mounted on a pole. Ensure stable placement on a flat surface or a compatible speaker pole stand. The robust design includes handles for easy transport and positioning.



Figure 1: Front view of the ZLX-15P-G2 loudspeaker.



Figure 2: ZLX-15P-G2 loudspeaker configured for monitor use.

3.3 Power Connection

Connect the provided power cable to the AC inlet on the rear panel of the loudspeaker and then to a suitable power outlet. Ensure the power switch is in the OFF position before connecting to power.

4. OPERATING INSTRUCTIONS

4.1 Control Panel Overview

The rear panel of the ZLX-15P-G2 features a digital mixer powered by DYNACORD, offering various inputs, outputs, and controls for sound management.





Figure 3: Rear control panel of the ZLX-15P-G2.



Figure 4: Detailed view of the QuickSmartDSP interface.

4.2 Bluetooth Connectivity

The ZLX-15P-G2 supports Bluetooth wireless stereo streaming. To connect:

1. Ensure Bluetooth is enabled on your smartphone or compatible device.
2. Turn on the ZLX-15P-G2 loudspeaker.
3. Navigate to the Bluetooth settings on your device and select the ZLX-15P-G2 from the list of available devices.
4. Once paired, you can stream audio wirelessly to the loudspeaker.

4.3 QuickSmart Mobile App Control

For advanced control and customization, download the QuickSmart Mobile app on your smartphone. The app allows you to adjust settings such as FX, AFS (Automatic Feedback Suppression), ducker, and parametric EQ (PEQ).




Figure 5: QuickSmart Mobile app interface for adjusting speaker settings.

4.4 Input and Output Connections

The loudspeaker features multiple input options for various audio sources and an output for linking to other speakers.

- **Inputs:** Connect microphones, mixers, or other audio devices using the available input jacks.
- **Output:** Use the output jack to send the audio signal to additional ZLX-15P-G2 loudspeakers or other compatible audio equipment.

4.5 Video Demonstration: Big Sound, Smart Control

Video 1: This video demonstrates how to achieve big sound and smart control with the ZLX-15P-G2, highlighting its features and ease of use.

5. MAINTENANCE

5.1 Cleaning

Regularly clean the exterior of the loudspeaker with a soft, dry cloth. Avoid using abrasive cleaners or solvents that could damage the finish. Ensure no liquids enter the speaker grille or control panel.

5.2 Storage

When not in use, store the loudspeaker in a dry, temperature-controlled environment. If storing for extended periods, it is recommended to use the original packaging or a protective cover to prevent dust accumulation and physical damage.

6. TROUBLESHOOTING

6.1 No Sound Output

- Check if the loudspeaker is powered on and the power cable is securely connected.
- Verify that the master volume and input levels are not set to minimum or muted.
- Ensure audio sources are properly connected and functioning.
- If using Bluetooth, confirm the device is correctly paired and streaming audio.

6.2 Bluetooth Connection Issues

- Ensure the loudspeaker is within the Bluetooth range of your device.
- Try unpairing and re-pairing the device with the loudspeaker.
- Restart both the loudspeaker and your Bluetooth device.

6.3 Distorted Audio

- Reduce the input gain or master volume to prevent clipping.
- Check the audio source for distortion.
- Inspect cables for damage or improper connection.

7. SPECIFICATIONS

Feature	Specification
Brand	Electro-Voice
Model Number	ZLX-15P-G2
Speaker Type	Powered 2-Way Loudspeaker, Monitor
Woofer Diameter	15 Inches
Tweeter Diameter	1 Inches
Connectivity Technology	Bluetooth

Control Method	App Control
Power Source	Corded Electric
Speaker Maximum Output Power	60 Watts
Frequency Response	Up to 20000 Hz
Item Dimensions (D x W x H)	30"D x 19"W x 19"H
Item Weight	19.8 Kilograms
Enclosure Material	Composite
Is Waterproof	False
Compatible Devices	Smartphone

8. WARRANTY AND SUPPORT

8.1 Warranty Information

The Electro-Voice ZLX-15P-G2 is covered by a **3-Year Limited Warranty**. This warranty covers defects in materials and workmanship under normal use. Please retain your proof of purchase for warranty claims.

8.2 Customer Support

For technical assistance, troubleshooting, or warranty inquiries, please contact Electro-Voice customer support through their official website or the contact information provided with your product documentation.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question