Manuals+

Q & A | Deep Search | Upload

Google GG1STBUN1C

Google Nest Mini 1st Generation Bluetooth Speaker User Manual

Brand: Google | Model: GG1STBUN1C

1. Introduction

This manual provides detailed instructions for the setup, operation, maintenance, and troubleshooting of your Google Nest Mini 1st Generation Bluetooth Speaker. The Google Nest Mini is a compact smart speaker designed to blend seamlessly into your home environment, offering enhanced audio experience and voice control capabilities.



Figure 1.1: Google Nest Mini 1st Generation Bluetooth Speaker (Charcoal)

This image displays the Google Nest Mini 1st Generation Bluetooth Speaker in charcoal color, showcasing its compact, circular design with a fabric top and four indicator lights. A white power cable extends from the bottom.

The device features improved sound quality with more power and bass compared to previous models. It is designed for global compatibility, supporting multiple languages and working with universal power adapters.

2. WHAT'S IN THE BOX

Your Google Nest Mini 1st Generation Bluetooth Speaker bundle includes the following components:

- Google Nest Mini 1st Generation Bluetooth Speaker (Charcoal)
- GO! Deluxe Protective Carry Pouch
- · Quick Start Guide
- · Universal Power Adapter with Global Compatibility



Figure 2.1: Bundle Contents

This image shows the Google Nest Mini speaker, its power adapter with cable, and the black GO! Deluxe Protective Carry Pouch, illustrating all items included in the bundle.

3. SETUP GUIDE

3.1 Initial Power On

- 1. Unpack the Google Nest Mini and its universal power adapter.
- 2. Connect the power adapter cable to the Google Nest Mini's power port.
- 3. Plug the universal power adapter into a compatible electrical outlet. The device will power on automatically.



Figure 3.1: Connecting Power

This image shows the Google Nest Mini speaker with its white power cable connected, illustrating how the device is powered.

3.2 Language Settings

Upon initial connection to your device, the speaker will automatically start up in English. Language settings can be

changed at any time to your preferred language, including Spanish, French, and Portuguese, for international use or travel.

3.3 Device Pairing (Bluetooth)

To pair your Google Nest Mini with a Bluetooth-enabled device (e.g., smartphone, tablet):

- 1. Ensure your Google Nest Mini is powered on.
- 2. Open the Google Home app on your mobile device and follow the on-screen instructions to set up your Nest Mini.
- 3. Once set up, you can enable Bluetooth pairing mode through voice command (e.g., "Hey Google, pair Bluetooth") or via the Google Home app.
- 4. On your mobile device, go to Bluetooth settings and select your Google Nest Mini from the list of available devices to complete pairing.

4. OPERATING INSTRUCTIONS

4.1 Voice Control

The Google Nest Mini is primarily controlled by voice. To activate the voice assistant, say "Hey Google" or "Ok Google" followed by your command. Examples include:

- "Hey Google, play some music."
- · "Ok Google, what's the weather like?"
- "Hey Google, set a timer for 10 minutes."

4.2 Audio Playback

Once connected via Bluetooth or Wi-Fi (through the Google Home app), you can stream audio from various services. Use voice commands to control playback (e.g., "Hey Google, pause," "Hey Google, next song," "Hey Google, turn up the volume").

4.3 Placement

The Google Nest Mini is designed to blend into any room. For optimal sound and voice recognition, place the speaker on a nightstand, shelf, countertop, or even mount it on a wall. Ensure it is not obstructed by other objects.



Figure 4.1: Speaker Top Surface

This close-up image shows the fabric top surface of the Google Nest Mini speaker, highlighting the four LED indicator lights that provide visual feedback during operation.

5. MAINTENANCE

5.1 Cleaning

To clean your Google Nest Mini, gently wipe the exterior with a soft, dry, lint-free cloth. Do not use abrasive cleaners, solvents, or harsh chemicals, as these may damage the device. Avoid getting moisture into any openings.

5.2 Storage

When not in use for extended periods, store the Google Nest Mini in a cool, dry place, away from direct sunlight and extreme temperatures. The included GO! Deluxe Protective Carry Pouch can be used for safe storage and transport.

6. TROUBLESHOOTING

If you encounter issues with your Google Nest Mini, refer to the table below for common problems and their solutions.

Problem	Possible Cause	Solution
Device does not power on.	Power adapter not connected or faulty outlet.	Ensure the power adapter is securely connected to the device and a working electrical outlet. Try a different outlet.
No sound from the speaker.	Volume is too low, device is muted, or not properly connected.	Increase volume using voice commands or the Google Home app. Check if the device is muted. Verify Bluetooth or Wi-Fi connection.
Voice commands not recognized.	Microphone is off, background noise, or device too far.	Ensure the microphone is not muted (check the switch on the back). Reduce background noise. Speak clearly and closer to the device.
Bluetooth pairing issues.	Device not in pairing mode, or interference.	Ensure the Nest Mini is in Bluetooth pairing mode. Turn off and on Bluetooth on your mobile device. Move closer to the speaker.
Incorrect power plug for region.	Despite being a universal adapter, regional variations may occur.	Verify that the provided universal power adapter is compatible with your region's electrical outlets. If necessary, use a suitable travel adapter or contact support for clarification on adapter compatibility.

7. TECHNICAL SPECIFICATIONS

Below are the technical specifications for the Google Nest Mini 1st Generation Bluetooth Speaker:

Feature	Specification
Speaker Type	Compact Google Mini Speaker
Model Name	GG1STBUN1C
Connectivity Technology	Bluetooth
Wireless Communication Technology	Bluetooth

Feature	Specification
Control Method	Voice
Power Source	Corded Electric
Speaker Size	6.25 Inches
Color	Grey
Item Weight	1 pounds
Package Dimensions	6.75 x 6.25 x 4.5 inches
Manufacturer	Google
UPC	659680633260
First Available Date	November 1, 2023

8. WARRANTY AND SUPPORT

8.1 Warranty Information

The Google Nest Mini 1st Generation Bluetooth Speaker comes with a One-Year Warranty. This warranty covers defects in materials and workmanship under normal use. Please retain your proof of purchase for warranty claims.

8.2 Customer Support

For further assistance, technical support, or warranty inquiries, please visit the official Google support website or contact their customer service. Refer to the Quick Start Guide included in your bundle for specific contact details or support links.

Related Documents

\$ Google Home Mini Quick Start Guide & Safety Information Concise guide to setting up your Google Home Mini, along with essential safety, regulatory, and environmental information for Google devices.
Google Nest Wifi: Setup, Safety, Warranty, and Regulatory Guide Comprehensive guide for Google Nest Wifi, covering setup instructions, safety precautions, regulatory compliance, and the limited warranty for the USA and Canada. Includes model details and support information.



How to Set Up Your Google Nest Wifi Router

A step-by-step guide to setting up your Google Nest Wifi router for a seamless home Wi-Fi experience. Learn about connecting the router, using the Google Home app, and optimizing your network.



Google Nest Cam Setup Guide

A concise guide to setting up your Google Nest Cam, including what's in the box and where to find support.