

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Hoover](#) /

› **Hoover Power Scrub Deluxe Carpet Cleaner Machine Instruction Manual**

Hoover Power Scrub Deluxe

Hoover Power Scrub Deluxe Carpet Cleaner Machine Instruction Manual

Model: Power Scrub Deluxe

[Setup](#)

[Operating](#)

[Maintenance](#)

[Troubleshooting](#)

[Specifications](#)

[Warranty & Support](#)

1. SETUP

Before first use, ensure all components are present and assembled correctly. Refer to the included manual for detailed assembly instructions.

1.1 Filling the Clean Water and Solution Tanks

1. Remove the clean water tank from the top of the unit.
2. Unscrew the cap for the clean water compartment and fill with hot tap water (do not use boiling water).
3. Unscrew the cap for the solution compartment and fill with Hoover cleaning solution. Ensure the correct fill lines are observed for both water and solution.
4. Securely replace both caps and reattach the tank to the unit.

Your browser does not support the video tag.

Video: Demonstrates filling the clean water and solution tanks on the Hoover Power Scrub Deluxe. The video shows the separate compartments for water and cleaning solution, highlighting the ease of filling and reattaching the tank to the main unit.




Image: The Hoover Power Scrub Deluxe Carpet Cleaner Machine, showcasing its design and dual tank system. This animated image provides a general overview of the product's appearance.

1.2 Attaching Accessories

The unit comes with various attachments for specialized cleaning tasks. To use them:

1. Locate the hose port on the front of the unit.
2. Lift the port cover and firmly insert the accessory hose until it clicks into place.
3. Attach the desired cleaning tool (e.g., upholstery tool, stair tool) to the end of the hose.

2. OPERATING INSTRUCTIONS

Follow these steps for effective carpet cleaning:

2.1 Powering On and Basic Cleaning

1. Plug the power cord into a grounded outlet.
2. Press the power button located at the base of the unit to turn it on.
3. Release the handle by pressing the foot pedal.
4. For washing, push the unit forward while pressing the solution trigger. Release the trigger and pull the unit backward to extract the dirty water. Repeat this process for thorough cleaning.
5. For rinsing, switch the dial on the clean water tank from 'Wash' to 'Rinse'. Push the unit forward without pressing the trigger to apply clean water, then pull backward to extract.

Your browser does not support the video tag.

Video: Shows the Hoover Power Scrub Deluxe in action, demonstrating the forward and backward passes for washing and extracting. The video highlights the effectiveness of the SpinScrub brushes on various carpet types.

2.2 Using Handheld Attachments

For upholstery, stairs, or hard-to-reach areas:

1. Ensure the accessory hose and desired tool are securely attached (as per Section 1.2).
2. Turn on the unit.
3. Press the trigger on the handheld tool to dispense solution and scrub the area. Release the trigger and apply pressure to extract the dirty solution.

3. MAINTENANCE

Regular maintenance ensures optimal performance and longevity of your carpet cleaner.

3.1 Emptying and Cleaning the Dirty Water Tank

1. Once cleaning is complete or the dirty water tank is full, remove it from the unit.
2. Unlatch the tank cover and carefully pour out the dirty water.
3. Rinse the tank thoroughly with clean water to remove any residue.
4. Allow the tank to air dry completely before reassembling.

3.2 Cleaning Brushes and Nozzle

1. Detach the clear nozzle cover from the front of the unit.
2. Remove the SpinScrub brushes by pressing the release buttons and pulling them out.
3. Rinse the brushes and nozzle cover under running water to remove dirt and debris. Use a brush or cloth if necessary.
4. Ensure all parts are dry before reassembling them into the unit.

4. TROUBLESHOOTING

- **No Suction:** Check if the dirty water tank is properly seated and latched. Ensure the nozzle cover is securely attached. The dirty water tank might be full, requiring emptying.
- **No Solution Dispensing:** Verify that the clean water and solution tanks are filled and correctly installed. Check if the solution trigger is being pressed during forward passes. Ensure the 'Wash' setting is selected on the tank dial.
- **Machine Not Turning On:** Confirm the power cord is securely plugged into a working outlet. Check for tripped circuit breakers.
- **Poor Cleaning Performance:** Ensure brushes are clean and free of debris. Use the recommended Hoover cleaning solution. Perform multiple passes over heavily soiled areas.

5. SPECIFICATIONS

Feature	Detail
Brand	Hoover
Model	Power Scrub Deluxe
Cleaning Technology	SpinScrub Brush System
Tank System	Dual Tank (Clean Water & Dirty Water)

Cleaning Modes	Wash, Rinse
Included Accessories	Hose, Upholstery Tool, Stair Tool, Sample Cleaning Solution

6. WARRANTY & SUPPORT

For warranty information, product registration, or technical support, please refer to the official Hoover website or contact their customer service. Keep your purchase receipt as proof of purchase for warranty claims.

Visit the [Hoover Store](#) for more products and support.

© 2026 Hoover. All rights reserved.