Manuals+

Q & A | Deep Search | Upload

manuals.plus /

- Google /
- > Google Nest Mini 1st Generation Bluetooth Speaker Instruction Manual

Google GG1STAPG1

Google Nest Mini 1st Generation Bluetooth Speaker

Instruction Manual

Model: GG1STAPG1 | Brand: Google

1. Product Overview

The Google Nest Mini 1st Generation is a compact and powerful Bluetooth speaker designed to integrate seamlessly into your home environment. It offers rich sound quality and is powered by Google Assistant, allowing for voice control of music, smart home devices, and access to information. This international version includes global compatibility for power adapters and supports multiple languages.




Image: The Google Nest Mini 1st Generation, a compact smart speaker with a light gray fabric top and white base, shown with its power cable connected.

2. What's in the Box

Verify that all components are present in your package:

- Google Nest Mini 1st Generation Bluetooth Speaker (International Version)
- Quick Start Guide Manual
- Universal Power Adapter
- Go Deluxe US Adapter Plug



Image: The Google Nest Mini speaker displayed alongside its included universal power adapter and a separate US adapter plug, illustrating the complete bundle contents.

3. Setup Guide

Follow these steps to set up your Google Nest Mini:

1. **Power Connection:** Connect the universal power adapter to the Google Nest Mini's power port located on the side of the device. Plug the adapter into a suitable electrical outlet. Use the appropriate adapter plug for your region.



Image: A close-up side view of the Google Nest Mini, highlighting the power input port and the connected power cable.

- 2. **Initial Boot-up:** Once powered, the device will begin its startup sequence. It is designed to automatically start in English when connecting to your device for the first time.
- 3. **Download Google Home App:** On your smartphone or tablet, download the Google Home app from your device's app store (Google Play Store for Android, Apple App Store for iOS).

- 4. **Connect to Wi-Fi:** Open the Google Home app and follow the on-screen instructions to set up your Nest Mini. This will involve connecting the device to your home Wi-Fi network.
- 5. **Link Google Account:** Link your Google account to the Nest Mini through the app to enable personalized features and voice commands.
- 6. **Language Settings:** While the device defaults to English, you can change its language settings at any time through the Google Home app to your preferred language for international use.

4. Operating Instructions

The Google Nest Mini is primarily operated using voice commands through Google Assistant. Ensure the device is powered on and connected to Wi-Fi.

 Voice Commands: To activate Google Assistant, say "Hey Google" or "Ok Google" followed by your command or question. The four LED lights on top of the device will illuminate to indicate it is listening.



Image: A dual view of the Google Nest Mini, showing the top surface with its four illuminated LED indicators and the bottom surface revealing the power port and a microphone mute switch.

- **Playing Music:** Request specific songs, artists, genres, or playlists from linked music services (e.g., "Hey Google, play jazz music").
- Controlling Smart Devices: If you have compatible smart home devices linked to your Google Home app, you can control them with voice commands (e.g., "Hey Google, turn off the living room lights").
- **Getting Information:** Ask for weather updates, news briefings, traffic information, definitions, calculations, and more (e.g., "Hey Google, what's the weather like today?").
- **Adjusting Volume:** You can adjust the volume by saying "Hey Google, turn up the volume" or "Hey Google, set volume to 5." Alternatively, you can tap the sides of the device to adjust volume.
- **Microphone Mute:** There is a physical switch on the side/bottom of the device to mute the microphone for privacy. When muted, the LED lights will typically show an orange indicator.

5. Maintenance

To ensure the longevity and optimal performance of your Google Nest Mini, follow these maintenance guidelines:

- Cleaning: Use a soft, dry, lint-free cloth to clean the exterior of the device. Do not use abrasive cleaners, solvents, or harsh chemicals.
- Avoid Liquids: The Google Nest Mini is not water resistant. Keep it away from water, moisture, and excessive humidity. Do not submerge it in any liquid.
- **Placement:** Place the device on a stable, flat surface. Avoid placing it in direct sunlight or near heat sources. Ensure adequate ventilation around the device.
- Power Cord Care: Handle the power cord carefully. Do not bend, crimp, or place heavy objects on it. Always
 unplug the device by pulling the plug, not the cord.

6. Troubleshooting

If you encounter issues with your Google Nest Mini, try the following troubleshooting steps:

• Device Not Responding:

- Ensure the device is properly plugged into a working power outlet.
- Check if the microphone mute switch is engaged. If it is, disengage it.
- Try unplugging the device from the power outlet, waiting 10 seconds, and plugging it back in to restart it.

· Cannot Connect to Wi-Fi:

- Ensure your Wi-Fi router is on and functioning correctly.
- · Move the Nest Mini closer to your Wi-Fi router.
- · Restart your Wi-Fi router.
- Verify your Wi-Fi password is correct when setting up via the Google Home app.

• Poor Sound Quality:

- Ensure the device is not placed in an enclosed space that might muffle sound.
- Check the volume level.
- If streaming, check your internet connection speed.

Voice Commands Not Understood:

- Speak clearly and at a normal volume.
- Ensure there isn't excessive background noise.
- Verify the device's language setting in the Google Home app matches the language you are speaking.

• Bluetooth Connectivity Issues:

- Ensure Bluetooth is enabled on your smartphone or tablet.
- Make sure the Nest Mini is in pairing mode (if applicable, or follow app instructions).
- Move your device closer to the Nest Mini (Bluetooth range is 10 meters).
- Forget the device in your phone's Bluetooth settings and try pairing again.

7. Specifications


Feature	Detail
Model Name	GG1STAPG1
Brand	Google
Speaker Type	Bookshelf
Connectivity Technology	Bluetooth
Wireless Communication Technology	Bluetooth
Bluetooth Range	10 Meters
Control Method	Voice
Power Source	Corded Electric
Product Dimensions	3"D x 5"W x 5"H
Item Weight	12 ounces
Color	Gray (Chalk)
Water Resistance Level	Not Water Resistant
Recommended Uses	For Smartphones or Tablets
Compatible Devices	Smartphone, Tablet
Audio Output Mode	Stereo
Mounting Type	Tabletop Mount
UPC	659680633949
Date First Available	November 1, 2023

8. Warranty and Support

Your Google Nest Mini 1st Generation comes with a **Limited Warranty**. For specific details regarding the warranty period, coverage, and terms, please refer to the warranty information provided with your product packaging or visit the official Google support website.

For further assistance, technical support, or to access detailed user guides and FAQs, please visit the official Google Support website. You can typically find support resources by searching for "Google Nest Mini support" on Google's official website.

© 2024 Google. All rights reserved. Google and Nest Mini are trademarks of Google LLC.



A concise guide to setting up your Google Nest Cam, including what's in the box and where to find

support.