

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [BoxWave](#) /

› [BoxWave FineTouch Capacitive Stylus User Manual for iQOO Neo 6](#)

## BoxWave FineTouch Capacitive Stylus

# BoxWave FineTouch Capacitive Stylus User Manual

For iQOO Neo 6 and other capacitive touchscreens

## INTRODUCTION

---

### About Your FineTouch Capacitive Stylus

The BoxWave FineTouch Capacitive Stylus is designed for precise interaction with your iQOO Neo 6 and other capacitive touchscreen devices. It offers a natural writing and drawing experience without the need for Bluetooth pairing or batteries.

Key features include a clear disc tip for enhanced visibility, a lightweight and compact design for portability, and a durable metal clip for secure attachment.



Image: The FineTouch Capacitive Stylus highlighting its clear disc tip, accurate and responsive performance, and sleek, lightweight design.



Image: A display of the FineTouch Capacitive Stylus available in multiple colors, showcasing its aesthetic versatility.

## SETUP

---

### Getting Started

The BoxWave FineTouch Capacitive Stylus is designed for immediate use. No Bluetooth pairing, software installation, or battery charging is required. Simply remove the stylus from its packaging and it is ready to interact with your device's screen.



Image: The stylus with its protective cap removed, revealing the clear disc tip ready for use.

## OPERATING INSTRUCTIONS

---

### Using Your Stylus

To use the stylus, gently touch the clear disc tip to your device's capacitive touchscreen. The clear disc is designed to provide precise contact and allow you to see exactly where your input is being registered on the screen. This enhances accuracy for tasks such as writing, drawing, and selecting small icons.

The stylus functions by simulating the electrical conductivity of your finger, making it compatible with any capacitive touchscreen device without special settings.

**BOXWAVE**

# Clear Disc Tip

See every detail unobscured  
and with full clarity.



Image: A close-up view of the clear disc tip interacting with a digital drawing on a tablet, demonstrating its precision.



Image: A user holding and operating the FineTouch Capacitive Stylus on a tablet, illustrating its ergonomic design and ease of use.

## MAINTENANCE

### Care and Storage

- **Cleaning the Tip:** To ensure optimal performance and responsiveness, keep the clear disc tip clean. Gently wipe it with a soft, dry, lint-free cloth if you notice any smudges, dust, or debris. Avoid using abrasive materials or harsh chemicals.
- **Protecting the Tip:** Always replace the threaded cap when the stylus is not in use. This protects the delicate clear disc tip from accidental damage, scratches, or accumulation of dirt.
- **Storage:** Store the stylus in a safe place, away from extreme temperatures, direct sunlight, and environments with excessive dust or moisture. The built-in metal clip can be used to secure the stylus to a pocket or case.



Image: The stylus with its threaded cap detached, demonstrating how the cap protects the clear disc tip.

## TROUBLESHOOTING

### Common Issues and Solutions

- **Stylus is unresponsive or inaccurate:**
  - Ensure the clear disc tip is clean and free of any debris or smudges.
  - Verify that the disc tip is securely attached to the stylus.
  - Confirm your device's screen is clean and free of fingerprints or dirt.
  - Note: The FineTouch Capacitive Stylus does not support palm rejection or pressure sensitivity. If these features are expected, please check your device's compatibility or consider a different stylus type.
- **Tip appears loose or damaged:**
  - The clear disc tip is designed to pivot slightly for optimal screen contact. This slight movement is normal.
  - If the tip appears excessively loose, detached, or physically damaged, please contact BoxWave customer support for assistance.

## SPECIFICATIONS

---

<b>Brand</b>	BoxWave
<b>Model Name</b>	FineTouch Capacitive Stylus
<b>Compatibility</b>	Universal Capacitive Touchscreens (e.g., iQOO Neo 6)
<b>Item Weight</b>	1 ounce
<b>Material</b>	Aluminum construction
<b>Special Features</b>	Clear Disc Tip, Integrated Metal Clip, No Bluetooth/Battery Required
<b>ASIN</b>	B0CWMT7P5L

## WARRANTY AND SUPPORT

---

### Customer Assistance

For technical assistance or product-related inquiries, BoxWave offers limited 3rd party tech support for your device (up to 3 inquiries via messaging). Please refer to your purchase documentation or the official BoxWave website for specific contact details and support options.

Information regarding the product warranty, including terms and conditions, can typically be found on the product packaging or by visiting the official BoxWave website.