

Bestier L102120A-BLKG

Bestier 80-Inch Black Rattan TV Stand (Model L102120A-BLKG) Instruction Manual

Model: L102120A-BLKG

INTRODUCTION

Thank you for choosing the Bestier 80-Inch Black Rattan TV Stand. This manual provides essential information for the safe assembly, operation, maintenance, and troubleshooting of your new entertainment center. Please read these instructions carefully before beginning assembly and retain them for future reference.

SAFETY INFORMATION

To ensure safe use of this product, please observe the following guidelines:

- **Weight Capacity:** Do not exceed the maximum weight capacity of 160 pounds for the top surface. Ensure the weight is evenly distributed.
- **Anti-Tipping:** Always use the included anti-tipping hardware to secure the TV stand to a wall. This prevents serious injury from tipping furniture.
- **Assembly:** Assemble the unit on a soft, clean surface to prevent scratches. Ensure all fasteners are securely tightened before use. Periodically check and re-tighten fasteners as needed.
- **Electrical Safety:** When installing LED lights, ensure all connections are secure and follow the provided LED light instructions. Do not expose electrical components to moisture.
- **Children and Pets:** Keep small parts and packaging materials away from children and pets during assembly. Do not allow children to climb on or play with the TV stand.
- **Placement:** Place the TV stand on a level, stable surface. Avoid placing it near heat sources or in direct sunlight to prevent material damage.

INCLUDED COMPONENTS

Before assembly, verify that all parts listed below are present and undamaged. If any parts are missing or damaged, please contact customer support.

- P2 Grade Particle Board Panels

- Glass Shelves (Adjustable)
- Metal Legs
- Rattan Doors with Magnetic Closures
- LED Lights
- Remote Control for LED Lights
- Metal Accessories (Hardware for assembly)
- User Manual (This document)

SETUP & ASSEMBLY

Assembly of the Bestier TV Stand requires careful attention to detail. Please follow the step-by-step instructions provided in the separate assembly guide included in your package. An installation video is also available for visual guidance.

Assembly Overview

The TV stand is designed for straightforward assembly. Ensure you have a Phillips head screwdriver and a hammer (not included) ready. All panels and hardware are typically labeled for easy identification.



Official installation video for the Bestier 80-Inch Rattan TV Stand. This video provides a visual guide to the assembly process.

Versatile Configuration

This TV stand offers 4-in-1 versatility, allowing it to be configured as a long TV stand, an L-shaped corner console, or a square coffee table. Refer to the assembly guide for specific instructions on each configuration.



Long TV Stand

Square
Coffee Table



L-shaped
Corner Console

Long TV Stand



The Bestier TV stand can be configured in multiple ways to suit your space.

Adjustable Glass Shelves

The glass shelves within the open compartments are adjustable. During assembly, or at any time after, you can reposition these shelves to accommodate items of various heights. Ensure the shelf supports are securely placed in the desired holes before resting the glass shelf.



Adjustable Glass Shelves for Customized Storage

Adjustable glass shelves provide flexible storage options.

OPERATING INSTRUCTIONS

LED Illumination

The integrated LED light strips offer customizable lighting for your entertainment area. Use the included remote control to manage the lighting features.

- **Power On/Off:** Press the power button on the remote to turn the lights on or off.
- **Color Selection:** Choose from 7 primary colors using the color buttons on the remote.
- **Dynamic Modes:** Select from 22 dynamic modes to create various lighting effects.
- **Brightness/Speed Adjustment:** Use the brightness and speed control buttons to adjust the intensity of the lights or the pace of dynamic modes.

Dynamic RGB LED Lights



22 Modes



7 Colors



Control the LED lights with the provided remote for various colors and dynamic modes.

Magnetic Doors

The cabinet doors feature a magnetic design for secure closure. Simply push the door gently to engage the magnetic latch and keep the contents enclosed.

MAINTENANCE

Proper care will extend the life and appearance of your Bestier TV Stand.

- **Cleaning:** Wipe the surfaces with a damp cloth, then immediately dry with a clean, dry cloth. Avoid abrasive cleaners or harsh chemicals that may damage the finish. The tabletop is waterproof for easy cleaning of spills.
- **Rattan Care:** The natural rattan weaving can be gently dusted with a soft brush or vacuum cleaner with a brush attachment.
- **Legs:** The elevated leg design allows for easy access for cleaning robots underneath the unit.
- **Hardware:** Periodically check all screws and fasteners to ensure they remain tight. Re-tighten as necessary to maintain stability.



The waterproof tabletop allows for easy cleaning with a damp cloth.

TROUBLESHOOTING

If you encounter any issues with your TV stand, refer to the following common problems and solutions:


Problem	Possible Cause	Solution
Missing parts or damaged components upon arrival.	Shipping damage or packaging error.	Contact Bestier customer support with your order details and a list of missing/damaged parts for replacement.
TV stand feels unstable or wobbly.	Loose fasteners or uneven floor.	Ensure all screws and bolts are tightened. Adjust the leveling feet (if present) or place shims under the legs to stabilize on uneven floors. Always use anti-tipping hardware.
LED lights are not working.	Loose connection, remote battery dead, or power issue.	Check all LED strip connections to the power source and controller. Replace the remote control battery. Ensure the power adapter is securely plugged into a working outlet.
TV feet do not fit on the stand.	TV base is wider than the stand's depth.	While the 80-inch stand accommodates TVs up to 85 inches in width, some TV models, especially larger ones, may have feet that extend beyond the stand's depth (13.8 inches). Consider using a universal TV stand mount or wall-mounting your TV if this is the case.

SPECIFICATIONS

Feature	Detail
Brand	Bestier
Model Number	L102120A-BLKG
Color	Black
Material	Engineered Wood, Glass
Product Dimensions (D x W x H)	13.8" x 80" x 20"

Feature	Detail
Item Weight	69.2 pounds
Maximum Weight Capacity	160 pounds
Number of Shelves	4 (Adjustable Glass)
Number of Doors	2 (Rattan, Magnetic)
LED Lights	7 Primary Colors, 22 Dynamic Modes
Room Type	Bedroom, Living Room
Installation Type	Freestanding

Product Size



Detailed product dimensions and TV size compatibility.

WARRANTY & SUPPORT

Bestier is committed to providing quality products and customer satisfaction.

- **Returns:** This product is eligible for 30-day easy returns. Please refer to your purchase platform's return policy for detailed instructions.
- **Customer Support:** For any questions, concerns, or assistance with missing/damaged parts, please contact Bestier USA customer support. Contact information can typically be found on the Bestier official website or through your purchase platform.
- **Protection Plans:** Extended protection plans may be available for purchase separately. These plans offer additional coverage beyond the standard return period.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question