

Manuals.plus /

› Vente-unique /

› Vente-unique Nereto Swing Gate Post - 15cm x 15cm x 190cm - Anthracite Grey - Instruction Manual

Vente-unique Nereto

Vente-unique Nereto Swing Gate Post Instruction Manual

Model: Nereto

1. PRODUCT OVERVIEW

The Vente-unique Nereto Swing Gate Post is designed to provide a sturdy and aesthetically pleasing support for your gate entrance. Constructed from durable aluminum, this post offers resistance to various weather conditions, ensuring longevity and minimal maintenance. It is compatible with gates under 188 cm in height and is designed for direct ground installation.

Key Features:

- Material: Aluminum
- Color: Anthracite Grey
- Dimensions: 15 cm (Length) x 15 cm (Depth) x 190 cm (Height)
- Metal Thickness: 1.2 mm
- Installation: Direct ground fixation
- Compatibility: Gates under 188 cm in height
- Maintenance: Low



Image 1.1: The Vente-unique Nereto Swing Gate Post, a tall, square, anthracite grey aluminum post, shown in isolation.

2. SAFETY INFORMATION

Please read all safety instructions before installation and use. Failure to follow these instructions may result in injury or damage to the product.

- Always wear appropriate personal protective equipment (PPE) such as gloves and safety glasses during installation.
- Ensure the installation area is clear of obstructions and hazards.
- Verify that the ground where the post will be installed is stable and capable of supporting the post and the attached gate.

- If drilling into concrete or masonry, use appropriate tools and ensure no hidden electrical wires or pipes are present.
- Do not attempt to install the post alone if it is heavy or cumbersome. Seek assistance.
- Keep children and pets away from the installation area.

3. PACKAGE CONTENTS

Carefully unpack the box and ensure all components are present and undamaged. If any parts are missing or damaged, contact your retailer immediately.

- 1 x Nereto Aluminum Swing Gate Post (15 cm x 15 cm x 190 cm)
- Visserie (Screws and fasteners for installation)

Note: The gate itself is not included with this gate post.

4. INSTALLATION INSTRUCTIONS

This section provides general guidelines for installing the Nereto Swing Gate Post. Specific installation requirements may vary based on your gate type and ground conditions. Professional installation is recommended for optimal safety and performance.

1. Prepare the Installation Site:

- Identify the exact location for the gate post. Ensure it is level and provides adequate clearance for the gate to swing open and close.
- Clear any debris, vegetation, or uneven surfaces from the installation area.

2. Mark Drilling Points:

- Position the gate post in its intended location.
- Using the base plate of the post as a template, mark the drilling points on the ground surface. Ensure the post is plumb (vertically straight) before marking.

3. Drill Holes:

- Drill holes at the marked points using an appropriate drill bit for your ground material (e.g., concrete drill bit for concrete). The depth and diameter of the holes should match the provided screws/anchors.
- Clean out any dust or debris from the drilled holes.

4. Secure the Post:

- Place the gate post over the drilled holes.
- Insert the provided screws/anchors into the holes and tighten them securely. Ensure the post remains plumb during this process.
- Do not overtighten, as this may damage the fasteners or the post base.

5. Attach the Gate (if applicable):

- Once the post is firmly secured, you can proceed with attaching your gate according to the gate manufacturer's instructions.
- Ensure the gate hinges are properly aligned and secured to the post.

6. Final Check:

- Verify that the post is stable, plumb, and securely fastened.

- Test the gate's operation to ensure it swings freely and closes properly without obstruction.



Image 4.1: The Nereto gate post installed, supporting a modern swing gate.

5. OPERATING INSTRUCTIONS

The Nereto Swing Gate Post itself does not have operational components. Its function is to provide structural support for a swing gate. The operation of your gate will depend on the specific gate mechanism you have installed.

This post is designed to support gates with a manual opening mechanism. Ensure that any gate attached to this post operates smoothly and without excessive force.

6. CARE AND MAINTENANCE

The Vente-unique Nereto Swing Gate Post is designed for low maintenance. Regular care will help preserve its appearance and structural integrity.

- **Cleaning:** Clean the post periodically with a soft cloth and mild soapy water. Avoid abrasive cleaners or harsh chemicals, as these can damage the aluminum finish. Rinse thoroughly with clean water.
- **Inspection:** Annually inspect the post for any signs of damage, corrosion, or loose fasteners. Check the stability of the post and the integrity of its connection to the ground.
- **Fasteners:** If any fasteners appear loose, gently tighten them. Do not overtighten.
- **Gate Hinges:** If a gate is attached, regularly inspect and lubricate its hinges according to the gate manufacturer's recommendations to ensure smooth operation and prevent undue stress on the post.

7. TROUBLESHOOTING

Most issues related to a gate post are typically due to improper installation or external factors.

- **Post is Wobbly:**
 - Check if the ground anchors/screws are securely tightened.
 - Ensure the ground foundation is stable. If the ground is soft or unstable, additional reinforcement may be required (e.g., concrete footing).
- **Gate Does Not Swing Freely:**
 - Verify that the gate hinges are properly aligned and lubricated.
 - Check for any obstructions in the gate's swing path.
 - Ensure the gate post is plumb and not leaning, which could affect gate alignment.
- **Corrosion or Damage:**
 - While aluminum is resistant to corrosion, inspect for any surface damage that could compromise the finish. Touch up minor scratches with appropriate paint if necessary.
 - For significant damage, consider replacing the affected component or consulting a professional.

8. SPECIFICATIONS

Manufacturer	VENTE-UNIQUE.COM
Model Number	Nereto
Material	Aluminum
Color	Anthracite Grey
Dimensions (L x W x H)	15 cm x 15 cm x 190 cm
Weight	9 Kilograms
Metal Thickness	1.2 mm
Included Components	Aluminum gate post, Screws
Compatibility	Gates under 188 cm in height
ASIN	B0CWPCXHX8

9. WARRANTY AND SUPPORT

Specific warranty information for the Vente-unique Nereto Swing Gate Post is not provided in the product details. For warranty claims or technical support, please contact Vente-unique customer service directly or refer to your purchase documentation.

Contact Information: Please refer to the Vente-unique official website or your retailer's contact details for customer support.

