

[Manuals.plus](#) /

› [ZURU](#) /

› MAX-Dino Adventure US-Series 1-Egg Capsule (238 pcs) Instruction Manual

ZURU 83158-V2

MAX-Dino Adventure US-Series 1-Egg Capsule (238 pcs)

Brand: ZURU | Model: 83158-V2

1. SAFETY INFORMATION

WARNING: Choking hazard - Small pieces - Not for children under 3 years.

Always supervise young children during play. Ensure all small pieces are kept away from infants and toddlers to prevent accidental ingestion.

2. WHAT'S IN THE BOX

- MAX-Dino Adventure US-Series 1-Egg Capsule (238 pcs)
- Instruction Manual (this document)



Image of the MAX-Dino Adventure US-Series 1-Egg Capsule, showing the egg-shaped packaging with a green and blue design featuring a dinosaur, a brick-built vehicle, and the ZURU MAX logo. The packaging indicates 'DINO ADVENTURE' and '238 Pieces'.

3. SETUP AND ASSEMBLY

The MAX-Dino Adventure US-Series 1-Egg Capsule contains 238 building pieces. Follow the detailed step-by-step instructions provided within the capsule to assemble your dinosaur and vehicle models.

1. Carefully open the egg capsule and remove all contents.
2. Locate the separate instruction booklet for assembly.
3. Sort the building pieces by color or shape as indicated in the instructions to facilitate assembly.
4. Follow the diagrams and written steps precisely to construct the dinosaur and vehicle models.
5. Ensure all connections are secure to prevent parts from detaching during play.

Keep the instruction booklet for future reference, especially if disassembling and reassembling the models.

4. OPERATING INSTRUCTIONS

Once assembled, the MAX-Dino Adventure set is ready for imaginative play. This set encourages creativity and storytelling.

- **Imaginative Play:** Use the assembled dinosaur and vehicle to create your own prehistoric adventures.
- **Combine with Other Sets:** This set is designed to be compatible with major brick brands, allowing for expanded building possibilities and integrated play with other building toy collections.
- **Display:** The completed models can also be displayed as decorative items.

No batteries or electronic components are required for operation.

5. MAINTENANCE

Proper care will ensure the longevity of your MAX-Dino Adventure set.

- **Cleaning:** To clean the building pieces, gently wipe them with a soft, damp cloth. Avoid using harsh chemicals or abrasive cleaners, as these may damage the plastic. Do not submerge the pieces in water.
- **Storage:** Store the pieces and assembled models in a cool, dry place away from direct sunlight and extreme temperatures. Keeping them in the original egg capsule or a dedicated storage container can help prevent loss of pieces.
- **Handling:** Handle the assembled models with care to avoid accidental breakage of connections.

6. TROUBLESHOOTING

If you encounter any issues with your MAX-Dino Adventure set, consider the following common solutions:

- **Missing Pieces:** Double-check the packaging and surrounding area thoroughly. If a piece is genuinely missing, refer to the Warranty and Support section for assistance.
- **Difficulty Assembling:** Review the instruction booklet carefully, paying close attention to the diagrams. Ensure you are using the correct pieces for each step. Sometimes, a small piece may be mistaken for another.
- **Loose Connections:** Ensure pieces are firmly pressed together until they click into place. If a connection remains loose, check if the pieces are correctly oriented or if there is any debris preventing a secure fit.

7. SPECIFICATIONS

Feature	Detail
Product Dimensions	6.77 x 5.67 x 9.72 inches
Item Weight	11.1 ounces
Item Model Number	83158-V2
Manufacturer Recommended Age	3 years and up
Manufacturer	ZURU
Number of Pieces	238
Release Date	January 1, 2024

8. WARRANTY AND SUPPORT

For warranty information, missing parts, or further assistance, please contact ZURU customer support directly. You may find contact details on the product packaging or by visiting the official ZURU website.

You can also visit the [ZURU Store on Amazon](#) for more product information and support resources.

© 2024 ZURU. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question