

[Manuals.plus](#) /

> [BoxWave](#) /

> BoxWave FineTouch Capacitive Stylus for Camecho A3081 - Instruction Manual

BoxWave FineTouch Capacitive Stylus

BoxWave FineTouch Capacitive Stylus Instruction Manual

Model: FineTouch Capacitive Stylus

INTRODUCTION

Thank you for choosing the BoxWave FineTouch Capacitive Stylus. This stylus is designed to provide precise and responsive interaction with your capacitive touchscreen devices, including the Camecho A3081. Its innovative clear tip allows for enhanced visibility and accuracy during use. This manual provides essential information for setting up, operating, and maintaining your stylus.



Image: The BoxWave FineTouch Capacitive Stylus, highlighting its clear disc tip for precise interaction.

SETUP

The BoxWave FineTouch Capacitive Stylus requires no complex setup or pairing. It is ready for use directly out of the packaging.

1. **Unpack:** Carefully remove the stylus from its packaging.
2. **Inspect:** Ensure the clear disc tip is clean and securely attached.
3. **No Pairing Required:** This stylus operates without Bluetooth or any other wireless connection. Simply touch the tip to your device's screen to begin use.



Image: The stylus with its protective cap removed, revealing the clear disc tip.

OPERATING INSTRUCTIONS

Using your FineTouch Capacitive Stylus is intuitive and straightforward.

- **General Use:** Hold the stylus like a regular pen. Gently touch the clear disc tip to your device's capacitive touchscreen to navigate, tap, swipe, or write.
- **Precision:** The clear disc tip is designed to allow you to see exactly where your input is being registered on the screen, providing enhanced precision for detailed tasks like drawing or fine text selection.
- **Clip Design:** Utilize the integrated metal clip to secure the stylus to your pocket, notebook, or device case for convenient portability.

Important Note: The FineTouch Capacitive Stylus does not support palm rejection or pressure sensitivity features. These functions are typically found in active styluses that require Bluetooth pairing.




Image: A user interacting with a tablet using the BoxWave FineTouch Capacitive Stylus.



Precise Clear Disc Tip

FineTouch features a clear conductive disc tip that is highly accurate and see through. Know exactly where you are tapping!

BoxWave FineTouch Capacitive Stylus

Image: A detailed view of the clear disc tip, emphasizing its transparency for accurate tapping.

MAINTENANCE

Proper care will ensure the longevity and optimal performance of your stylus.

- **Cleaning the Tip:** If the stylus tip becomes dirty or less responsive, gently wipe it with a soft, lint-free cloth. Do not use abrasive materials or harsh chemicals.
- **Protecting the Tip:** Always replace the threaded cap when the stylus is not in use. This protects the delicate clear disc tip from damage and debris.
- **Storage:** Store the stylus in a clean, dry place, away from extreme temperatures and direct sunlight.



Image: The stylus with its threaded cap, demonstrating how it protects the clear disc tip.

TROUBLESHOOTING

If you encounter issues with your stylus, consider the following:

- **Stylus Not Responding:**
 - Ensure your device's screen is clean and free of smudges or debris.
 - Check that the clear disc tip of the stylus is clean and intact.
 - Verify that your device's touchscreen is functioning correctly with finger input.
- **Inaccurate Input:**
 - Clean the clear disc tip thoroughly. Any dirt or oil can affect accuracy.
 - Ensure the clear disc is flat against the screen when making contact.

- **Tip Damage:** If the clear disc tip is damaged or lost, contact BoxWave support for assistance.

SPECIFICATIONS

Feature	Detail
Model Name	FineTouch Capacitive Stylus
Compatibility	All capacitive touchscreens, including Camecho A3081
Tip Type	Clear Disc Tip
Connectivity	No Bluetooth / No Pairing Required
Special Features	Integrated Metal Clip, Threaded Cap for Tip Protection
Item Weight	1 ounce
Manufacturer	BoxWave

WARRANTY INFORMATION

BoxWave products are manufactured to high-quality standards. For specific warranty details regarding your FineTouch Capacitive Stylus, please refer to the warranty documentation included with your purchase or visit the official BoxWave website. Keep your proof of purchase for any warranty claims.

SUPPORT

For further assistance, technical support, or inquiries about your BoxWave FineTouch Capacitive Stylus, please contact BoxWave customer service. Contact information can typically be found on the BoxWave official website or on the product packaging.