

KiwiCo B0CWPZWRQ7

KiwiCo Water and Sand Sensory Table

Instruction Manual

PRODUCT OVERVIEW

The KiwiCo Water and Sand Sensory Table is designed to provide engaging, hands-on play experiences for toddlers aged 3 and up. This versatile table supports both water and sand activities, encouraging creative exploration and the development of real-world skills through interactive components.


It features a customizable pipe set, paint crayons, an acrylic panel for drawing, and a sensory bin, all designed to grow with your child.

WHAT'S INCLUDED

Your KiwiCo Water and Sand Sensory Table package includes the following components:

- 1 frame
- 1 bin
- 1 plug
- 4 inner legs
- 4 outer legs
- 2 panel supports
- 1 clear panel
- 8 screws
- 12 bolts
- 1 hex key
- 2 reservoirs
- 2 cross pipes
- 3 curved pipes
- 3 spinners
- 5 valves
- 1 water wheel
- 2 pitchers
- 1 sponge
- 1 squeegee
- 1 spray bottle
- 3 washable paint crayons

- 1 illustrated instruction booklet



Water resistant

Wood is coated for durability. Store indoors or under a cover for harsh weather.

Image: All components of the sensory table, including the wooden frame parts, plastic bin, clear panel, various water play accessories (pipes, spinners, valves, reservoirs), and art supplies (crayons, sponge, squeegee, spray bottle).

SETUP AND ASSEMBLY

Assembly of the KiwiCo Water and Sand Sensory Table is designed to be straightforward and typically takes 15-20 minutes with no additional tools required beyond what is provided. Follow the detailed instructions in the included illustrated instruction booklet.

- **Adjustable Height:** The table features adjustable legs, allowing it to grow with your child. Simply adjust the leg height using the green knobs to suit your child's reach and comfort.
- **Panel Orientation:** The clear acrylic panel can be positioned to face either the water/sand bin or the outside, depending on the activity.




Image: The sensory table with key dimensions highlighted, showing its adjustable height feature.




Image: A detailed view of the adjustable leg mechanism, highlighting the green knobs used for height adjustment.

OPERATING INSTRUCTIONS

Water Play

Fill the removable bin with water. Attach the various pipes, reservoirs, spinners, and valves to the clear acrylic panel using their suction cups. Experiment with different configurations to observe water flow, cause and effect, and basic hydraulic engineering principles. Use the included pitchers to pour water into the reservoirs and activate the system.

Endless water play

Create custom water features with the stick-on pipe set, shower head, and spinners.



Image: A child engaging with the water play setup, demonstrating how water flows through the pipes and activates the spinners.

Your browser does not support the video tag.

Video: Official product video showcasing the water and sand sensory table in use, highlighting its features and interactive play possibilities.

Sand Play

The removable bin can also be used for sand play or other sensory materials. Encourage dumping, digging, and scooping activities. This setup helps contain mess and provides a dedicated space for imaginative play with sand, dirt, or other sensory items.



Image: The complete sensory table with all its components, ready for both water and sand play.

Creative Drawing

Utilize the clear acrylic panel as a canvas for drawing. The included washable paint crayons allow children to doodle masterpieces directly on the panel. Drawings can be easily wiped away with the provided sponge and squeegee, or rinsed with water, allowing for endless creative expression.

Get creative

Included paint crayons wash away easily with water.



Image: A child using the clear panel as a drawing surface with washable crayons.

MAINTENANCE AND CARE

To ensure the longevity of your KiwiCo Water and Sand Sensory Table, follow these maintenance guidelines:

- **Cleaning:** After water play, use the integrated drain hole at the bottom of the bin to empty water. The tapered edge ensures complete drainage. The table and accessories can be easily rinsed with a hose or wiped clean with the provided sponge and squeegee.
- **Wood Care:** The wooden components are coated for durability and water resistance. However, to prevent damage from harsh weather and prolong the product's life, it is recommended to store the table indoors or under a protective cover when not in use.
- **Storage:** All accessories can be stored neatly within the bin when not in use. The clear panel can be removed and flipped over for compact storage.



Includes

- 1 frame
- 1 bin
- 1 plug
- 4 inner legs
- 4 outer legs
- 2 panel supports
- 1 clear panel
- 8 screws
- 12 bolts
- 1 hex key
- 2 reservoirs
- 2 cross pipes
- 3 curved pipes
- 3 spinners
- 5 valves
- 1 water wheel
- 1 shower head
- 2 pitchers
- 1 sponge
- 1 squeegee
- 1 spray bottle
- 3 washable paint crayons
- 1 illustrated instruction booklet

Image: The sensory table in an outdoor setting, showcasing its water-resistant design during active play.

TROUBLESHOOTING

While the KiwiCo Water and Sand Sensory Table is designed for durability, occasional issues may arise. Here are some common concerns and potential solutions:

- **Loose or Warped Wooden Parts:** In rare instances, wooden components may show signs of warping or separation at seams, particularly if exposed to prolonged moisture or extreme weather conditions. Ensure the table is stored indoors or covered when not in use to minimize this risk. If significant damage occurs, contact KiwiCo customer support for assistance.
- **Water Flow Issues:** If water is not flowing correctly through the pipe system, check that all pipe connections are secure and that valves are properly opened or closed as desired. Ensure no debris is obstructing the flow.
- **Accessories Not Sticking:** If suction cup accessories are not adhering well to the clear panel, ensure both the suction cups and the panel surface are clean and free of dust or residue. A slightly damp surface can sometimes improve suction.

SPECIFICATIONS

| Feature | Detail |
|------------------------------|-----------------------|
| Product Dimensions | 22 x 21.6 x 37 inches |
| Item Weight | 19.18 pounds |
| Country of Origin | China |
| ASIN | B0CWPZWRQ7 |
| Manufacturer Recommended Age | 36 months - 6 years |
| Manufacturer | KiwiCo |

SAFETY INFORMATION

Important: Use this product with adult supervision at all times. Ensure all components are securely assembled before use. Regularly inspect the table for any signs of wear or damage that could pose a safety risk. Keep small parts away from children under 3 years of age to prevent choking hazards.

WARRANTY AND SUPPORT

For information regarding product warranty, returns, or customer support, please refer to the contact details provided in your product packaging or visit the official KiwiCo website. Specific warranty terms may vary.

© 2025 KiwiCo. All rights reserved.

Related Documents

| | |
|---|---|
|  | <p>KiwiCo Delivery Bot: Build and Operation Guide</p> <p>A comprehensive guide to building and operating the KiwiCo Delivery Bot, including assembly instructions, troubleshooting tips, and creative delivery ideas.</p> |
|  | <p>Build Your Own Speaker: Assembly Guide and FCC Compliance</p> <p>A step-by-step guide to assembling a KiwiCo speaker, including all necessary instructions and FCC compliance information.</p> |
|  | <p>Silly Speaker: Build and Understand Sound</p> <p>A guide to building the KiwiCo Silly Speaker, explaining the science of sound and troubleshooting common issues. Learn how sound travels from a device to your ear.</p> |
|  | <p>KiwiCo Delivery Bot Assembly and Operation Manual</p> <p>A comprehensive guide to assembling and operating the KiwiCo Delivery Bot, including step-by-step instructions, troubleshooting tips, and FCC compliance information.</p> |