

[manuals.plus](#) /

› [GAOMON](#) /

› [GAOMON 38.6" Large Dog Crate Furniture Instruction Manual](#)

## **GAOMON PHO\_137TXNTY**

# **GAOMON 38.6" Large Dog Crate Furniture Instruction Manual**

Model: PHO\_137TXNTY

Brand: GAOMON

## **1. INTRODUCTION**

---

Thank you for choosing the GAOMON 38.6" Large Dog Crate Furniture. This manual provides essential information for the safe assembly, operation, and maintenance of your new dog crate. Please read these instructions carefully before use and retain them for future reference.



Image: The GAOMON 38.6" Large Dog Crate Furniture, designed to blend into home decor while providing a secure space for your dog.

## 2. SAFETY INFORMATION

- Always ensure all parts are securely fastened before allowing your pet to use the crate.
- Do not exceed the maximum weight capacity of 70 lbs on the top panel.
- Regularly inspect the crate for any signs of damage, loose parts, or wear. Discontinue use if damage is found.
- While the crate is designed to be chew-resistant, supervise pets, especially puppies or aggressive chewers, to

prevent damage to the crate or injury to the pet.

- Ensure the wheels are locked when the crate is in a stationary position to prevent accidental movement.
- Keep small children away from the crate during assembly and ensure they do not play inside or around the crate unsupervised.
- This product is intended for indoor use only.

### 3. INCLUDED COMPONENTS

---

Before assembly, verify that all components listed below are present and undamaged. If any parts are missing or damaged, please contact customer support.



Image: An exploded view of the crate components, showing the metal frame panels, wooden top and back panels, removable tray, and wheels.

#### Parts List:

- Metal Frame Panels (various sizes for sides, front, back, and bottom)
- Wooden Top Panel
- Wooden Back Panel
- Removable Tray
- Casters (wheels, some with brakes)
- Assembly Hardware (screws, bolts, nuts)
- S-Hooks (for hanging accessories)
- Assembly Tools (screwdriver, wrench, gloves)

### 4. SETUP INSTRUCTIONS

---

Follow these steps to assemble your GAOMON dog crate furniture. It is recommended to have a second person assist with assembly.

#### Assembly Video Guide:

Your browser does not support the video tag.

Video: This video provides a visual guide to the assembly process of the GAOMON dog crate furniture, demonstrating each step for easy setup.

#### Step-by-Step Assembly:

- 1. Unpack Components:** Carefully remove all parts from the packaging. Lay them out on a clean, flat surface. Refer to the parts list to ensure everything is present.
- 2. Assemble Base Frame:** Connect the bottom metal frame panels using the provided hardware. Ensure all connections are snug but do not overtighten.
- 3. Attach Side Panels:** Secure the side metal panels to the base frame. Pay attention to the orientation of the panels, especially those with door mechanisms.
- 4. Install Back Panel:** Attach the wooden back panel to the rear of the metal frame using the designated screws.
- 5. Secure Top Panel:** Place the wooden top panel onto the assembled frame and secure it with the appropriate hardware.
- 6. Attach Wheels:** Screw the casters into the designated holes on the bottom of the frame. Ensure the two casters with locking mechanisms are placed on the same side for easy access.
- 7. Insert Removable Tray:** Slide the removable tray into the bottom of the crate.
- 8. Attach S-Hooks:** Hang the S-hooks on the interior bars of the crate for accessory storage.
- 9. Final Check:** Double-check all screws and connections to ensure they are tight and secure.

## 5. OPERATING INSTRUCTIONS

---

### Door Operation:

- The crate features double doors: one on the front and one on the side.
- To open, lift the door latch mechanism upwards and then slide it horizontally to disengage.
- To close, align the door with the frame, slide the latch mechanism into place, and push it downwards to secure. Ensure the latch is fully engaged to prevent accidental opening.

### Removable Tray:

- The bottom tray slides out for easy cleaning. Simply pull the tray forward until it detaches from the frame.
- After cleaning, slide the tray back into its designated slot until it is fully seated.

### Mobility and Stability:

- The crate is equipped with 360-degree universal wheels for easy relocation.
- To move the crate, unlock the two casters with brakes by flipping the lever upwards.
- To secure the crate in place, push the levers on the two braking casters downwards until they click, locking the wheels.



Image: A visual overview of the crate's features, including its double doors, universal wheels, and removable tray.

## 6. MAINTENANCE AND CLEANING

- **Removable Tray:** The plastic tray can be easily removed and washed with soap and water. For larger messes, it can be hosed down outdoors. Ensure it is completely dry before placing it back in the crate.
- **Metal Frame:** Wipe down the metal bars with a damp cloth and mild detergent. Dry thoroughly to prevent rust.
- **Wooden Panels:** Clean the wooden top and back panels with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners that could damage the finish.

- **Regular Inspection:** Periodically check all screws and connections for tightness. Tighten as needed to maintain the crate's structural integrity.

## 7. TROUBLESHOOTING

---


- **Crate feels unstable:** Ensure all assembly screws are tightened. Check that the casters are securely attached and that the braking casters are locked when the crate is stationary.
- **Dog is chewing on the crate:** While the crate is designed to be durable, persistent chewers may cause damage. Consider using chew deterrents or providing alternative chew toys. Regular supervision is recommended.
- **Door mechanism is stiff:** Apply a small amount of silicone-based lubricant to the moving parts of the latch mechanism if it becomes stiff.
- **Difficulty moving the crate:** Ensure all caster brakes are disengaged. Check for any obstructions under the wheels.

## 8. SPECIFICATIONS

---

Feature	Detail
Model Number	PHO_137TXNTY
Overall Dimensions (L x W x H)	38.6" x 25.6" x 26.8"
Item Weight	48.1 pounds
Material	Metal, Wood (Particleboard)
Color	Rustic Brown
Top Panel Weight Capacity	Up to 70 lbs
Special Features	Double-Doors, Durable, Easy to Clean, Removable Tray, Wheels
Target Audience	Large Dogs

### Dog Size Guide:



## HOW to Measure Your Dog for a Crate?

**Length:** While standing, measure from the tip of its nose to the base of its tail.

**Height:** While sitting, measure from the head to the floor.

Add 4 inches to both final measurements for extra wiggle room.

Crate	Crate Size	Dog Weight	Dog Breeds
<b>S</b> 	<b>Overall Size (For Your Home):</b> <b>27.2" L x 20.1" W x 23.6" H</b> <b>internal Size (For Your pet):</b> <b>24.4" x 16.5" x 19.7"</b> <b>Door Size: 13" x 14.2"</b> <b>Side door size: 9.5" x 14.2"</b>	Up to 30 lb	Chihuahua Yorkshire Toy Poodle Jack Russell
<b>M</b> 	<b>Overall Size (For Your Home):</b> <b>32.5" L x 21.9" W x 25.2" H</b> <b>internal Size (For Your pet):</b> <b>29.9" x 18.5" x 21.3"</b> <b>Door Size: 12.4" x 15.2"</b> <b>Side door size: 10.8" x 15.2"</b>	Up to 45 lb	French Bulldog Pembroke Welsh Corgi Pit Bull
<b>L</b> 	<b>Overall Size (For Your Home):</b> <b>38.6" L x 25.6" W x 26.8" H</b> <b>internal Size (For Your pet):</b> <b>35.8" x 21.7" x 23.2"</b> <b>Door Size: 13" x 17"</b> <b>Side door size: 12.6" x 17"</b>	Up to 70 lb	Border Collie Shiba Inu Bulldog Husky

Image: A visual guide and table for selecting the correct crate size based on your dog's measurements, weight, and breed.

Crate Size	Overall Size (L x W x H)	Dog Weight	Recommended Dog Breeds
Small	27.2" L x 20.1" W x 23.6" H	Up to 30 lb	Chihuahua, Yorkshire, Toy Poodle, Jack Russell
Medium	32.5" L x 21.9" W x 25.2" H	Up to 45 lb	French Bulldog, Pembroke Welsh Corgi, Pit Bull
Large	38.6" L x 25.6" W x 26.8" H	Up to 70 lb	Border Collie, Shiba Inu, Bulldog, Husky

## 9. WARRANTY AND SUPPORT

## **Warranty Information:**

This GAOMON dog crate furniture comes with a **2-year manufacturer's warranty**. This warranty covers defects in materials and workmanship under normal use. It does not cover damage caused by misuse, accidents, unauthorized modifications, or normal wear and tear.

## **Customer Support:**

For any questions, concerns, or warranty claims, please contact GAOMON customer support. Refer to your purchase documentation for specific contact details or visit the official GAOMON website.