Manuals+

Q & A | Deep Search | Upload

Generic N35

N35 LED Display Low Latency Wireless Earphone TWS 5.3 User Manual

Model: N35

1. Introduction

This manual provides detailed instructions for the safe and effective use of your N35 LED Display Low Latency Wireless Earphone TWS 5.3. Please read this manual thoroughly before using the product and retain it for future reference. The N35 earbuds are designed to deliver a seamless and immersive audio experience with features such as low latency technology, intuitive touch controls, and an LED display for battery status and connectivity.

2. SAFETY INFORMATION

- Do not expose the earbuds or charging case to extreme temperatures, humidity, or liquids.
- · Avoid dropping, impacting, or disassembling the device.
- Use only the provided charging cable and a compatible power adapter.
- Prolonged exposure to high volume levels may cause hearing damage. Adjust volume to a safe level.
- Keep out of reach of children and pets.
- Clean the earbuds and charging case with a soft, dry cloth.

3. PACKAGE CONTENTS

Please check the package for the following items:

- N35 Wireless Earbuds (Left and Right)
- Charging Case
- USB Charging Cable
- User Manual

4. Product Overview

Familiarize yourself with the components of your N35 earbuds and charging case.



Figure 4.1: N35 Earbuds and Charging Case. The earbuds feature a sleek design with green accents, housed within a transparent-lidded charging case that displays battery status.

4.1 Earbuds

- Touch Control Area: For managing playback, calls, and modes.
- LED Indicator: Shows pairing status and battery level.
- Microphone: For voice calls.
- Charging Contacts: Connects with the charging case.

4.2 Charging Case

- LED Display: Indicates charging status and battery level of the case and individual earbuds.
- Charging Port: USB port for charging the case.
- Earbud Slots: Securely holds and charges the earbuds.

5. SETUP

5.1 Initial Charging

Before first use, fully charge the earbuds and the charging case.

- 1. Place both earbuds into the charging case.
- 2. Connect the USB charging cable to the charging port on the case and to a power source (e.g., computer USB port, wall adapter).
- 3. The LED display on the case will show the charging progress. A full charge typically takes 1-2 hours.
- 4. Once fully charged, the LED display will indicate a full battery.




Figure 5.1: Charging the N35 Earbuds. The image suggests the earbuds' long battery life, suitable for extended use with devices like laptops and smartphones.

5.2 Pairing with a Device

The earbuds will automatically enter pairing mode when taken out of the case.

- 1. Open the charging case and remove both earbuds. They will automatically power on and attempt to pair with each other.
- 2. On your device (smartphone, tablet, computer), enable Bluetooth.
- 3. Search for available Bluetooth devices. You should see "N35" or a similar name in the list.
- 4. Select "N35" to connect. Once connected, the earbud LED indicators will turn off or flash slowly, and you may hear a confirmation tone.
- 5. If pairing fails, place the earbuds back into the case, close the lid, wait a few seconds, and then repeat the steps.



Figure 5.2: Synchronous Transmission. The closed case indicates the earbuds are ready for seamless connection and audio transmission.

6. OPERATING INSTRUCTIONS

6.1 Touch Controls

The N35 earbuds feature intuitive touch controls on each earbud. The functions may vary slightly depending on the specific model variant.

Action	Function
Single Tap (L/R)	Play/Pause Music, Answer/End Call
Double Tap (L)	Previous Track
Double Tap (R)	Next Track
Triple Tap (L/R)	Activate Voice Assistant
Long Press (2s) (L/R)	Reject Call
Long Press (3s) (L/R)	Toggle Gaming/Music Mode

6.2 Music/Game Dual Mode

The N35 earbuds support a dual mode for optimized audio experience, switching between music and gaming modes.



Figure 6.1: Music/Game Dual Mode. This image emphasizes the low latency and high sound quality for both music listening and gaming.

- Music Mode: Provides balanced audio for general listening.
- Gaming Mode: Reduces audio latency for a more synchronized gaming experience.
- To switch modes, perform a long press (3 seconds) on either earbud's touch control area. You will hear an audible prompt indicating the mode change.



Figure 6.2: Bluetooth 5.2 Chip. This image showcases the advanced Bluetooth technology within the earbud, contributing to its low latency performance.

7. MAINTENANCE

7.1 Cleaning

- Regularly clean the earbuds and charging case to ensure optimal performance and hygiene.
- Use a soft, dry, lint-free cloth to wipe the surfaces of the earbuds and case.
- For earwax or debris in the earbud tips, use a small, soft brush or cotton swab. Do not use sharp objects.
- Do not use abrasive cleaners, alcohol, or chemical solvents.

7.2 Storage

- When not in use, store the earbuds in their charging case to protect them and keep them charged.
- Store the device in a cool, dry place, away from direct sunlight and extreme temperatures.

8. TROUBLESHOOTING

Problem	Possible Solution
Earbuds not pairing with device	Ensure Bluetooth is enabled on your device. Place earbuds back in case, close lid, then reopen and try pairing again. Forget "N35" from your device's Bluetooth list and re-pair.

Problem	Possible Solution
Only one earbud working	Ensure both earbuds are charged. Place both earbuds back in the case, close the lid, then reopen. This often re-syncs them.
No sound or low volume	Check volume levels on both the earbuds and your connected device. Ensure earbuds are properly seated in your ears. Clean earbud tips if necessary.
Charging case not charging	Check the USB cable and power adapter. Ensure the charging cable is securely connected to both the case and the power source.
Touch controls not responding	Ensure your fingers are clean and dry. Try restarting the earbuds by placing them in the case and taking them out again.




Figure 8.1: Clear Call Performance. The image highlights the earbuds' capability for clear communication, even in potentially noisy environments.

9. SPECIFICATIONS

Feature	Detail
Model Name	N35
Connectivity Technology	Wireless (Bluetooth 5.3)

Feature	Detail
Noise Control	Active Noise Cancellation
Ear Placement	In Ear
Control Method	Touch
Material	Plastic
Water Resistance Level	Waterproof
Impedance	8 Ohm
Color	Black

10. WARRANTY AND SUPPORT

For warranty information and technical support, please refer to the contact details provided with your purchase or visit the manufacturer's official website.

Please retain your proof of purchase for warranty claims.

