

Minetom BMSL6

Minetom Color Changing String Lights Outdoor - 33FT 100 LED Fairy Lights with Remote

Model: BMSL6

1. INTRODUCTION

Thank you for choosing Minetom Color Changing String Lights. These 33-foot long string lights feature 100 LED bulbs capable of displaying 22 vibrant colors and 12 distinct lighting modes. Designed for both indoor and outdoor use, they come with a multifunction remote control for convenient operation. This manual provides essential information for safe and effective use of your new lighting product.

2. IMPORTANT SAFETY INSTRUCTIONS

- Read all instructions before use.
- Do not immerse the power adapter in water. The string lights are IP44 waterproof, but the adapter is not.
- Ensure the power source matches the voltage requirements specified on the adapter.
- Do not connect the string lights to another power source while plugged in.
- Avoid damaging the insulation of the wires. Do not cut or modify the string lights.
- Keep away from open flames or heat sources.
- Unplug the lights when not in use for extended periods.

3. PACKAGE CONTENTS

- 1 x Minetom 33FT 100 LED Color Changing String Lights
- 1 x Power Adapter
- 1 x Multifunction Remote Control

- 1 x User Manual



Image: Minetom Color Changing String Lights, coiled, showing the remote control and power adapter.

4. SETUP

1. **Unpack:** Carefully remove the string lights, power adapter, and remote control from the packaging.
2. **Unwind:** Gently uncoil the string lights, ensuring not to tangle or damage the wires.
3. **Connect Power:** Connect the string lights to the power adapter. Ensure a secure connection.
4. **Plug In:** Plug the power adapter into a standard electrical outlet.
5. **Remote Preparation:** Remove the insulation sheet from the remote control's battery compartment before first use.

Video: Demonstrates the full measurements and length of the Minetom Color Changing Lights, including the lead wire and spacing between bulbs, which is useful for planning installation.

5. OPERATING INSTRUCTIONS

5.1 Using the Multifunction Remote Control

The remote control allows for comprehensive management of your string lights from up to 16 feet away.

Multifunction Remote , Handy Operation

Turn On

Turn Off

4/6/8H Timer Function

Brightness+/-

4 Multicolor Dynamic Modes

16 Single Color & 6 Holiday Color

Speed+/-

Cycle All Lighting Modes

8 Lighting Modes for 22 Colors

Press Button to Select Lights Modes

Please remove the insulation sheet before using

22 Colors Changing

8 Lighting Modes

IP44 Waterproof

Smart Remote Control

Timer Function

Image: Detailed layout of the multifunction remote control, showing buttons for power, timer, colors, dynamic modes, speed, and brightness adjustments.

- **Power On/Off:** Press the **ON** or **OFF** buttons.
- **Color Selection:** Choose from 22 vibrant colors using the dedicated color buttons.
- **Lighting Modes:** Select from 12 lighting modes, including Steady, Fade, Flash White, Chase, Twinkle, In Wave, Fill, and Stream. The **AUTO** mode cycles through all available modes.

- **Brightness Adjustment:** Adjust the light intensity with 5 adjustable levels using the brightness +/- buttons.
- **Speed Adjustment:** Modify the speed of dynamic modes with 5 adjustable levels using the speed +/- buttons.
- **Timer Function:** Set the lights to automatically turn off after 4, 6, or 8 hours.

5.2 Using the Control Button on the Power Adapter

A physical button on the power adapter allows for basic control if the remote is unavailable.

- Press the button to cycle through the available lighting modes.
- Hold the button to turn the lights off.

Video: Demonstration of the app and remote control functionalities, including music synchronization, for the Minetom Color Changing String Lights.

6. FEATURES IN DETAIL

6.1 22 Colors Changing String Lights

These lights offer a wide spectrum of 22 colors, including 16 single colors and 6 holiday-specific color combinations. Easily switch between themes like orange and purple for Halloween, red and green for Christmas, or red, white, and blue for the 4th of July.



Image: A visual grid displaying 22 distinct color options available for the string lights, including single colors and holiday combinations.

6.2 12 Lighting Modes

Beyond static colors, the lights feature 12 dynamic lighting modes to create various atmospheres. These modes include: Steady, Fade, Flash White, Chase, Twinkle, In Wave, Fill, and Stream. Four modes are dedicated to classic 7-color cycling, while 8 modes are available for single-color selections.

6.3 IP44 Waterproof Rating

With an IP44 waterproof rating, the string lights are protected against splashing water from any direction, making them suitable for both indoor and outdoor environments. The power adapter should

be protected from direct water exposure.

6.4 Versatile Application

The flexible design allows the lights to be easily shaped and wrapped around various objects such as garlands, railings, Christmas trees, or used to decorate bedrooms, gardens, patios, and for holiday parties.




Image: Examples of Minetom string lights used in various holiday settings, including St. Patrick's Day, Christmas, Easter, and 4th of July.

Brightness Adjustment



Image: Visual representation of the 5 adjustable brightness levels (100%, 75%, 50%, 25%, 10%) for the string lights.

Video: A demonstration showcasing the color-changing capabilities and various holiday themes of the Minetom Fairy Lights.

7. SPECIFICATIONS

Attribute	Value
-----------	-------

Brand	Minetom
Model Number	BMSL6
Light Source Type	LED
Number of Light Sources	100
Item Length	33 Feet
Power Source	Corded Electric
Light Color	Multicolor (22 colors)
Special Features	12 Lighting Modes, Adjustable Brightness/Speed, Color Changing, Timer
Indoor/Outdoor Usage	Outdoor
Ingress Protection Code Rating	IP44
Control Method	Remote Control
Material	Plastic
Item Weight	10.2 ounces
Package Dimensions	6.3 x 3.39 x 2.48 inches

8. TROUBLESHOOTING

- **Lights not turning on:**
 - Ensure the power adapter is securely connected to the lights and plugged into a working outlet.
 - Check if the remote control's insulation sheet has been removed.
 - Verify the remote control battery is functional.
- **Remote not responding:**
 - Ensure you are within the 16 ft effective range and pointing the remote towards the receiver on the power adapter.
 - Replace the remote control battery if necessary.
- **Lights are dim or flickering:**
 - Adjust the brightness settings using the remote control.
 - Ensure the power supply is stable.


9. CARE AND MAINTENANCE

- **Cleaning:** Wipe the lights gently with a soft, dry cloth. Do not use harsh chemicals or abrasive cleaners.
- **Storage:** When not in use, carefully coil the lights and store them in a cool, dry place away from direct sunlight and moisture.
- **Inspection:** Periodically inspect the wires and bulbs for any signs of damage. Discontinue use if damage is found.

10. WARRANTY AND SUPPORT

Minetom products are designed for quality and durability. For any questions, technical support, or warranty claims, please refer to the contact information provided with your purchase or visit the official Minetom website.

Related Documents - BMSL6

	<p>Minetom S14 Solar String Lights User Manual and Safety Guide</p> <p>Comprehensive guide for Minetom S14 Solar String Lights, covering installation, operation, safety precautions, troubleshooting, and warranty information. Learn how to set up and maintain your solar-powered string lights.</p>
--	---