

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [GoorDik](#) /

› [GoorDik Mini USB C Wireless Lavalier Microphone User Manual](#)

## GoorDik J3

# GoorDik Mini USB C Wireless Lavalier Microphone

Model: J3

## INTRODUCTION

---

The GoorDik Mini USB C Wireless Lavalier Microphone (Model J3) is designed to provide superior audio quality for content creators, vloggers, podcasters, and anyone needing clear sound recording on the go. Featuring advanced Active Denoise technology, this microphone ensures crystal-clear audio even in noisy environments. Its plug-and-play design, long battery life, and wide compatibility with USB-C and USB devices make it an ideal tool for various recording scenarios.

# Sound Better, Instantly

**Before**

**After**



**Distant & Muffled  
Phone Sound**

**Clear & Crisp  
Wireless Audio**



**Image: Sound Quality Comparison.** This image illustrates the significant improvement in audio clarity when using the GoorDik wireless microphone compared to a phone's built-in microphone. The "Before" image shows a person holding a phone with "Distant & Muffled Phone Sound" indicated, while the "After" image shows a person wearing the GoorDik microphone with "Clear & Crisp Wireless Audio" indicated.

# Superior USB-C Mic

Equipped with an upgraded DSP noise cancellation chip, provides excellent audio



**Image: Superior USB-C Microphone.** This image highlights the GoorDik USB-C microphone, emphasizing its upgraded DSP noise cancellation chip for excellent audio. It shows sound waves being processed, indicating noise reduction capabilities.

## WHAT'S IN THE BOX

Your GoorDik Mini USB C Wireless Lavalier Microphone kit includes the following components:

- 2 x Wireless Microphone Transmitters

- 1 x Wireless Microphone Receiver
- 1 x USB Charging Cable
- 4 x Foam Microphone Covers
- 2 x Furry Outdoor Microphone Windscreens
- 1 x USB Adapter (USB-C to USB-A)
- 1 x User Manual



**Image: Kit Contents.** This image displays all the items included in the GoorDik wireless microphone package: two transmitters with furry windscreens, one receiver, a USB-C to USB-A adapter, a Lightning adapter, a charging cable, and additional foam microphone covers.

## SETUP

Setting up your GoorDik wireless microphone is a straightforward plug-and-play process:

1. **Connect the Receiver:** Plug the wireless microphone receiver directly into the USB-C port of your recording device (iPhone 15, Android phone, tablet, or PC). If your device uses a standard USB-A port, use the included USB-C to USB-A adapter.
2. **Power On Transmitters:** Press and hold the power button on each wireless microphone transmitter until the indicator light illuminates. The transmitters will automatically pair with the receiver.
3. **Attach Microphone:** Clip the microphone transmitter securely to your clothing, ensuring the microphone capsule is

facing towards your mouth for optimal sound capture. The rotatable clip allows for easy adjustment of direction.

4. **Android OTG Activation (if needed):** For some Android phones, you may need to enable the OTG (On-The-Go) function in your phone's settings to allow external audio devices. Refer to your phone's manual for specific instructions.
5. **PC/Laptop Settings (if needed):** When connecting to a computer, ensure the GoorDik microphone is selected as the default input device in your sound settings.

# Long Battery Recording

Two transmitters, 6 hrs recording for each, 12 hrs max when alternating



Note: 1.5 hours are needed to fully charge the transmitter, the receiver doesn't need to be charged.

Type-C phones (Samsung Galaxy, Google Pixel, iPhone 15/16), iPhones via a Lightning adapter (iPhone 14/13/12/11/XR/X/8/6), and laptops/PCs via a USB-A adapter.

## OPERATING INSTRUCTIONS

---

The GoorDik microphone features an intuitive interface with clear indicators for easy operation:

- **Power On/Off:** Press and hold the power button (marked with a power symbol) on the transmitter to turn it on or off.
- **Mute Function:** Briefly press the mute button (marked with a microphone symbol) on the transmitter to mute or unmute the microphone. The mute indicator light will change accordingly.
- **Noise Reduction Mode:** The microphone offers two noise reduction modes. Press the noise reduction button (marked with a waveform) to cycle between active noise reduction and original sound mode.
- **Indicator Lights:**
  - **Connection Status:** Indicates if the transmitter is successfully paired with the receiver.
  - **Mute Indicator:** Shows whether the microphone is currently muted.
  - **Noise Reduction:** Indicates when noise reduction is active.
  - **Power Indicator:** Displays the battery level of the transmitter.

# Fit For All Recording Devices



**Type-C**



For Samsung Galaxy /Google Pixel/ iPhone 15 /16



**Lightning Adapter**



For iPhone 14/ 13/ 12/ 11/ XR/ X/ 8/ 6




**USB A Adapter**



For Laptop/ PC

**Image: At-a-glance Status.** This image details the various LED indicators on the GoorDik microphone transmitter, including Connection Status, Mute Indicator, Noise Reduction status, and Power Indicator, providing instant feedback on the microphone's operational state. The GoorDik microphone offers a wireless range of up to 20 meters (65 feet), providing ample freedom for movement during recording.



# Thousands of Content Creators Love to Work with GoorDik Mic



**Image: Freedom to Create.** This image illustrates the wireless range of the GoorDik microphone, showing two individuals recording outdoors with the microphones clipped to their shirts, emphasizing stable and clear audio from up to 65 feet (20 meters) away.

## MAINTENANCE

### Charging the Transmitters

Each GoorDik microphone transmitter is equipped with a 60 mAh battery, providing 6 to 12 hours of use on a single charge. A full charge takes approximately 1.5 hours. The receiver does not require charging as it draws power from the



connected device.

- Use the included 1-to-2 USB charging cable to charge both transmitters simultaneously.
- Connect the USB charging cable to a standard USB power adapter (not included) or a computer USB port.
- The power indicator light on the transmitter will show charging status.

# Freedom to Create

## Stable & Clear Audio from 65ft (20m) Away



65 FT

**Image: Long Battery Recording.** This image visually represents the extended battery life of the GoorDik microphone transmitters, showing two transmitters and a clock indicating up to 6 hours of recording per transmitter, or 12 hours maximum when alternating. A note specifies

that 1.5 hours are needed to fully charge the transmitter.

## Cleaning and Storage

- **Cleaning:** Gently wipe the microphone and receiver with a soft, dry cloth. Do not use liquid cleaners or abrasive materials.
- **Windscreens:** Regularly clean or replace the foam microphone covers and furry windscreens to maintain optimal sound quality and hygiene.
- **Storage:** Store the microphone kit in a cool, dry place away from direct sunlight and extreme temperatures. When not in use for extended periods, ensure the transmitters are fully charged before storage.

## TROUBLESHOOTING

---

If you encounter issues with your GoorDik wireless microphone, please refer to the following common troubleshooting steps:

Problem	Possible Cause / Solution
No Sound Output	<p>Ensure the receiver is fully plugged into your device's USB-C port.</p> <p>Verify that the microphone transmitters are powered on and paired (check connection indicator).</p> <p>Check if the microphone is muted (check mute indicator and press mute button).</p> <p>For Android devices, ensure OTG function is enabled in settings.</p> <p>For PCs/laptops, confirm the GoorDik microphone is selected as the default input device in your sound settings.</p> <p>Test with another recording application or device.</p>
Poor Sound Quality / Background Noise	<p>Ensure the microphone is positioned correctly, facing the sound source.</p> <p>Activate the noise reduction mode (press the noise reduction button).</p> <p>Check if the foam covers or furry windscreens are properly installed, especially in windy environments.</p> <p>Ensure you are within the effective wireless range (up to 20 meters).</p> <p>Avoid strong electromagnetic interference sources.</p>
Microphone Not Charging	<p>Ensure the charging cable is securely connected to both the transmitter and the power source.</p> <p>Try a different USB power adapter or USB port.</p> <p>Check the charging cable for any damage.</p>
Intermittent Connection	<p>Ensure there are no significant obstructions between the transmitter and receiver.</p> <p>Stay within the recommended 20-meter wireless range.</p> <p>Avoid environments with high wireless interference (e.g., many Wi-Fi networks, other wireless devices).</p>

## SPECIFICATIONS

---

Feature	Detail
Brand	GoorDik

Feature	Detail
Model Number	J3
Microphone Form Factor	Lavalier Microphone
Connectivity Technology	Wireless
Connector Type	USB Type-C, Micro-USB (for charging cable)
Polar Pattern	Omnidirectional
Frequency Response	20 Hz - 20 KHz
Signal-to-Noise Ratio	65 dB
Power Source	Battery Powered
Battery Type	Lithium-ion (2 included)
Battery Capacity (each transmitter)	60 mAh
Battery Life	6-12 hours (per transmitter)
Charging Time (transmitters)	Approx. 1.5 hours
Wireless Range	Up to 20 meters (65 feet)
Material	Stainless Steel, Plastic
Item Weight	70 Grams
Dimensions (L x W x H)	13.2 x 9.7 x 1.7 cm
Compatible Devices	Personal Computer, Laptop, Smartphone, Tablet
Special Features	Clip, Mute Function, Noise Reduction, Battery Indicator Light

## WARRANTY AND SUPPORT

GoorDik is committed to providing high-quality products and excellent customer service. While specific warranty details are not provided in this manual, our dedicated customer service team is always available to assist you with any questions, concerns, or technical support needs regarding your GoorDik Mini USB C Wireless Lavalier Microphone. Please refer to the product packaging or the retailer's website for any specific warranty information or return policies. For assistance, please contact GoorDik customer support through the platform where you purchased the product.