

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Xtrike-Me](#) /

› [Xtrike-Me GC 907 Gaming Chair with RGB Light User Manual](#)

Xtrike-Me GC-907

Xtrike-Me GC 907 Gaming Chair with RGB Light User Manual

Model: GC-907

INTRODUCTION

This manual provides essential instructions for the assembly, operation, maintenance, and troubleshooting of your Xtrike-Me GC 907 Gaming Chair. Please read this manual thoroughly before assembly and use to ensure safe and correct operation and to maximize the lifespan of your product.

SAFETY INFORMATION

Important: Always adhere to these safety guidelines to prevent injury or damage to the product.

- The maximum weight capacity for this chair is 150 kg (approximately 330 lbs). Do not exceed this limit.
- Ensure the chair is properly assembled according to the instructions before use.
- Use the chair on a hard, level floor to ensure stability and prevent tipping.
- Avoid standing on the chair or using it as a step stool.
- Keep children and pets away from the chair during assembly.
- Regularly check all bolts and screws to ensure they are tight. Retighten if necessary.

SETUP AND ASSEMBLY

The Xtrike-Me GC 907 Gaming Chair requires assembly. All necessary components and instructions are provided in the packaging. Please follow the included assembly guide carefully. Below are general steps and key components:

1. **Unpack Components:** Carefully remove all parts from the packaging and verify against the parts list in the separate assembly guide.
2. **Attach Casters to Base:** Insert the casters into the holes on the 350 mm nylon base.
3. **Install Gas Lift:** Place the 100 mm hydraulic lifting system (gas lift) into the center hole of the base.
4. **Assemble Seat and Backrest:** Follow the specific instructions to attach the backrest to the seat mechanism.
5. **Attach Armrests:** Secure the 3D armrests to the seat base.
6. **Connect Seat to Gas Lift:** Place the assembled seat onto the gas lift.



Image: Front view of the Xtrike-Me GC 907 Gaming Chair, showcasing the ergonomic design, headrest, lumbar support, and integrated RGB lighting along the edges.

OPERATING INSTRUCTIONS

Your Xtrike-Me GC 907 Gaming Chair offers several adjustable features for personalized comfort.

- **Height Adjustment:** Use the lever located under the seat on the right side to adjust the chair's height. Pull the lever up while seated to lower the chair, or pull it up while standing to raise it. Release the lever to lock the height. The 100 mm hydraulic lifting system allows for smooth adjustments.
- **Backrest Recline:** The backrest can be adjusted up to 180 degrees. Locate the recline lever on the side of the chair (typically on the right). Pull the lever up and lean back to your desired angle, then release the lever to lock the backrest in place.
- **3D Armrests:** The armrests are multi-directional. They can typically be adjusted for height, forward/backward position, and rotation. Experiment with the buttons or levers on the armrests to find your preferred position.
- **RGB Backlighting:** The chair is equipped with RGB backlighting. Connect the USB cable from the chair to a power source (e.g., a USB port on your computer or a USB wall adapter) to activate the lights. A controller, usually integrated or inline with the cable, allows you to change lighting modes, colors, and brightness.



Image: Side profile of the Xtrike-Me GC 907 Gaming Chair, highlighting the contoured backrest, adjustable armrest, and the vibrant RGB light strip running along the chair's side.



Image: The Xtrike-Me GC 907 Gaming Chair shown in a fully reclined position, demonstrating its 180-degree recline capability, suitable for resting or napping.

MAINTENANCE

Proper maintenance will extend the life and appearance of your gaming chair.

- **Cleaning:** Wipe clean with a soft, damp cloth. For stubborn stains on the PU and PVC materials, use a mild soap solution and then wipe with a clean, damp cloth. Avoid harsh chemicals or abrasive cleaners.
- **Hardware Check:** Periodically check all screws, bolts, and connections to ensure they are tight. Retighten as necessary to maintain stability and safety.
- **Caster Care:** Keep the casters free of hair, dust, and debris to ensure smooth movement.
- **Avoid Direct Sunlight:** Prolonged exposure to direct sunlight can cause the material to fade or crack.



Image: Rear view of the Xtrike-Me GC 907 Gaming Chair, showing the sturdy construction of the backrest, the Xtrike-Me logo, and the attachment points for the headrest and lumbar cushions.

TROUBLESHOOTING

If you encounter issues with your gaming chair, refer to the following common solutions:

Problem	Possible Cause	Solution
Chair wobbles or feels unstable.	Loose screws or uneven floor.	Check and tighten all assembly screws. Ensure the chair is on a flat, level surface.
Height adjustment not working.	Gas lift malfunction or lever obstruction.	Ensure the lever is fully engaged. Check for any obstructions around the gas lift mechanism. If the issue persists, the gas lift may need replacement.
Backrest does not recline or lock.	Recline mechanism obstruction or damage.	Check for any objects blocking the recline mechanism. Ensure the lever is fully pulled/released.
RGB lights are not working.	Power connection issue or controller malfunction.	Verify the USB cable is securely connected to a working power source. Check the inline controller for damage or ensure it's turned on. Try a different USB port or power adapter.
Casters not rolling smoothly.	Debris caught in casters.	Turn the chair over and carefully remove any hair, dust, or debris from the caster wheels.

SPECIFICATIONS

Key technical specifications for the Xtrike-Me GC 907 Gaming Chair:

Feature	Detail
Model Number	XTRIKE ME GC-907
Color	Black
Primary Material	PU and PVC (Chair), Nylon (Base, Frame)
Product Dimensions (D x W x H)	48 x 57 x 136 cm (18.9 x 22.4 x 53.5 inches)
Item Weight	5.3 kg (11.7 lbs)
Maximum Load Capacity	150 kg (330 lbs)
Hydraulic Lift System	100 mm
Armrests	3D Adjustable
Base Type	350 mm Nylon Base
Backrest Recline Angle	Up to 180 degrees
Special Features	RGB Backlighting, Adjustable Height, Arm Rest, Recliner
Assembly Required	Yes, instructions provided
Care Instructions	Wipe Clean

WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the documentation included with your purchase or contact Xtrike-Me customer service through their official website. Keep your proof of purchase for warranty claims.