

- Manuals.plus /
- > [Armocity](#) /
 - > Armocity L-Shaped Computer Desk with Power Outlets and LED Lights User Manual

Armocity L-Shaped Desk 47-inch

Armocity L-Shaped Computer Desk with Power Outlets and LED Lights User Manual

Model: L-Shaped Desk 47-inch | Brand: Armocity

1. INTRODUCTION

This manual provides detailed instructions for the assembly, operation, and maintenance of your Armocity L-Shaped Computer Desk. Designed for versatility, this desk features integrated power outlets, USB ports, LED lighting, and ample storage solutions, making it suitable for various uses including gaming, work, and study in home office or bedroom environments. Please read this manual thoroughly before assembly and use to ensure proper function and safety.




Image: Armocity L-Shaped Computer Desk. This image displays the overall design of the desk, highlighting its L-shape, integrated monitor stand, LED lighting, and various accessories like the storage bag and hooks.

2. SAFETY INFORMATION

To ensure safe operation and prevent injury or damage, please adhere to the following safety guidelines:

- **Proper Assembly:** Ensure all components are correctly assembled and tightened according to the instructions. Incorrect assembly can lead to instability.
- **Anchoring:** If applicable, anchor the desk to a wall to prevent tipping, especially in households with children or pets.
- **Electrical Components:** Exercise caution when using the integrated power outlets and USB ports. Do not overload the outlets. Avoid spilling liquids near electrical components to prevent electrical shock or fire hazards.
- **Weight Capacity:** Do not exceed the desk's stated weight capacity for any surface or shelf. Distribute weight evenly.
- **Placement:** Place the desk on a level, stable surface. Avoid placing it in areas with excessive moisture or direct sunlight.
- **Cleaning:** Disconnect power before cleaning electrical components. Use a dry or slightly damp cloth for cleaning.

surfaces.

3. PACKAGE CONTENTS

Before beginning assembly, verify that all parts are present and undamaged. If any parts are missing or damaged, please contact customer service.

- Desk Panels (Main desktop, monitor stand, side panels)
- Metal Frame Components (Legs, crossbars)
- Integrated Power Outlet Unit (with AC outlets and USB ports)
- LED Light Strip and Controller
- Fabric Storage Bag
- Side Hooks
- Assembly Hardware (Screws, bolts, nuts, Allen wrench)
- Instruction Manual

4. SETUP AND ASSEMBLY


Assembly of the Armocity L-Shaped Computer Desk is designed to be straightforward. It is recommended to have a second person assist with assembly for ease and safety. Clear a spacious area for assembly and keep all parts organized.

4.1 Assembly Steps

1. **Unpack and Identify:** Carefully unpack all components and compare them against the package contents list. Identify each part using the provided diagrams.
2. **Assemble Frame:** Begin by assembling the metal frame components. Attach the legs to the main support beams using the provided hardware. Ensure all connections are secure but do not fully tighten screws until the entire frame is assembled.
3. **Attach Crossbars:** Install the X-shaped crossbars to enhance stability. These are crucial for the desk's structural integrity.
4. **Install Desktop Panels:** Carefully place the desktop panels onto the assembled frame. Secure them using the designated screws.
5. **Mount Monitor Stand:** Attach the elevated monitor stand to the main desktop surface.
6. **Integrate Power Outlet Unit:** Install the power outlet unit into its designated slot on the desktop. Ensure it is flush and securely fastened.
7. **Attach LED Lights:** Adhere the LED light strip to the underside of the monitor stand or desktop as indicated in the specific assembly guide. Connect the LED controller.
8. **Add Accessories:** Attach the fabric storage bag and side hooks to your preferred side of the desk.
9. **Final Tightening:** Once all components are in place, systematically tighten all screws and bolts to ensure maximum stability.

4.2 Reversible Configuration

The desk can be configured in two ways: as an L-shaped corner desk (47 inches on each side) or as a long straight desk (75.6 inches). The assembly process allows for this flexibility. Refer to the specific assembly diagrams to choose your desired configuration before attaching the desktop panels.



Create Your Home Office Space with Reversible Desks



Image: Reversible Desk Configurations. This image illustrates how the desk can be assembled as an L-shaped corner unit or as a long, straight desk, providing flexibility for different room layouts.

5. OPERATION

5.1 Power Outlets and USB Ports

The desk is equipped with an integrated power strip featuring 3 AC outlets (120V/12A) and 2 USB ports (5V/2A) for convenient charging and powering of your devices. Connect the desk's main power cord (6.5 ft) to a wall outlet.

- **AC Outlets:** Use these for standard electronic devices such as monitors, laptops, or lamps.
- **USB Ports:** Ideal for charging smartphones, tablets, and other USB-powered accessories.




Image: Integrated Power Outlets. This image shows the built-in 3 AC outlets and 2 USB ports, along with the 6.5 ft power cord, providing convenient access to power for electronic devices.

5.2 LED Lighting System

The desk features hidden smart LED lights with various modes to enhance your environment. The LED lights are controlled via a remote control or a dedicated app (if supported, check product documentation for app details).

- **Static Mode:** Select a single color to maintain a consistent ambience.
- **Dynamic Modes:** Choose from 20 pre-programmed dynamic modes that cycle through colors and effects.
- **Brightness Adjustment:** Adjust the intensity of the LED lights.
- **Speed Adjustment:** Control the speed of dynamic lighting effects.
- **Music Modes:** Some models may feature music synchronization modes (refer to specific LED controller instructions).



🌈 Enjoy your gaming time with this L-shaped Gaming Desk

Image: LED Lighting in Use. This image demonstrates the vibrant LED lighting system integrated into the L-shaped desk, creating an immersive atmosphere for gaming or work.



Image: LED Control Features. This image provides key dimensions of the desk and highlights the control options for the LED lighting, including dynamic modes, Bluetooth function, memory function, and music modes.

5.3 Storage Features

- **Monitor Stand:** The elevated monitor stand provides ergonomic viewing and additional storage space underneath for small items.
- **Side Hooks:** Two side hooks are provided for hanging headphones, bags, or other accessories. These can be attached to either the left or right side of the desk.
- **Fabric Storage Bag:** A large fiber storage bag can be attached to the side of the desk, offering convenient storage for notebooks, pens, tablets, and other office supplies. This bag is also reversible.



Image: Desk Feature Overview. This diagram points out key features such as the full-size monitor stand, smart LED lights, strengthened X-bar design for support, large fiber storage bag, and two side hooks.

6. MAINTENANCE

- **Cleaning Surfaces:** Wipe desk surfaces with a soft, damp cloth. Avoid abrasive cleaners or harsh chemicals that could damage the finish.
- **Electrical Components:** Ensure the power cord is unplugged before cleaning near the power outlets or LED lights. Use a dry cloth to wipe these areas.
- **Hardware Check:** Periodically check all screws and bolts to ensure they remain tight. Re-tighten if necessary to maintain stability.
- **LED Lights:** If LED lights become dusty, gently wipe them with a dry, soft cloth.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Desk is wobbly.	Loose screws or uneven floor.	Ensure all assembly screws are fully tightened. Adjust leveling feet if present, or place shims under legs on uneven surfaces.
Power outlets/USB ports not working.	Desk not plugged in, wall outlet not functioning, or circuit overload.	Verify the desk's power cord is securely plugged into a working wall outlet. Test the wall outlet with another device. Reduce the number of devices plugged into the desk's outlets.
LED lights not turning on or functioning incorrectly.	LED strip not properly connected, power issue, or remote control battery dead.	Check all LED light connections. Ensure the desk's power is on. Replace the remote control battery. Refer to the LED controller's specific instructions.
Missing or damaged parts during assembly.	Shipping damage or packaging error.	Do not proceed with assembly. Contact Armocity customer service immediately for replacement parts.

8. SPECIFICATIONS

Feature	Detail
Brand	Armocity
Model	L-Shaped Desk 47-inch
Configuration Options	L-Shape (approx. 47.2" x 47.2" x 29.1" H) or Long Straight (approx. 75.6" L x 18.9" D x 29.1" H)
Product Dimensions (L-Shape)	119.9 cm (47.2 in) L x 119.9 cm (47.2 in) W x 73.9 cm (29.1 in) H
Product Dimensions (Long Straight)	192 cm (75.6 in) L x 48 cm (18.9 in) D x 73.9 cm (29.1 in) H
Material	Engineered Wood (Top), Metal (Base)
Color	Black Walnut
Item Weight	20.2 kg (approx. 44.5 lbs)
Power Outlets	3 AC Outlets (120V/12A)
USB Ports	2 USB Ports (5V/2A)
Power Cord Length	6.5 ft
LED Lights	Smart LED lights with Static & 20 Dynamic Modes, Brightness/Speed Adjustment
Special Features	Full-size Monitor Stand, Reversible Design, X-shaped Cross Bars, Side Hooks, Fabric Storage Bag



Image: Desk Dimensions. This image provides a visual representation of the desk's dimensions in both its L-shaped and extended straight configurations, including height, width, and depth measurements.

9. WARRANTY AND CUSTOMER SUPPORT

Armocity is committed to providing high-quality products and customer satisfaction. While specific warranty details are not provided in this manual, please retain your proof of purchase for any warranty claims.

For any questions, missing parts, assembly assistance, or issues with your desk, please contact Armocity customer service. Our support team is available to assist you with any defects or concerns.

Contact Information: Refer to the product packaging or the retailer's website for the most current customer service contact details.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0CWRXPQ8P>

More documents and user manuals: <https://manuals.plus/>