

FoxVilla T13

FoxVilla T13 Titan 13 Action Figure Instruction Manual

Model: T13

Brand: FoxVilla

IMPORTANT SAFETY INFORMATION

CHOKING HAZARD - Small parts. Not for children under 3 years.

Always supervise children during play to prevent accidental ingestion of small components.

PRODUCT OVERVIEW

The FoxVilla T13 Titan 13 Action Figure is a highly articulated, 3D printed collectible designed by Soozafone. Crafted from high-quality PETG and PLA materials, this figure offers durability and vibrant colors. It features a full range of movable joints, allowing for extensive posing and dynamic display options. The figure comes with versatile accessories for customization.

Key Features:

- **Designed by Soozafone:** Meticulously crafted with advanced 3D printing technology.
- **Pre-Assembled:** Ready for immediate display or play, with no initial assembly required for the base figure.
- **Versatile Accessories:** Includes different hand options and weapon accessories for enhanced playability and customization.
- **Full Range of Joints:** Each joint is fully movable, enabling a wide variety of postures and actions.
- **Durable Materials:** Made from high-quality PETG and PLA for lasting performance.

PACKAGE CONTENTS

Your FoxVilla T13 Titan 13 Action Figure package includes:

- 1 x FoxVilla T13 Titan 13 Action Figure (Red, 8 inch)
- Multiple interchangeable hand options (e.g., fists, open hands for weapons)
- Various weapon accessories (e.g., swords, guns, knives, axe)



Image: The FoxVilla T13 Titan 13 Action Figure in red, displayed with its various weapon and hand accessories.

ASSEMBLY AND CUSTOMIZATION

Your FoxVilla T13 Titan 13 Action Figure comes pre-assembled. However, its modular design allows for extensive customization by interchanging hands and attaching various weapon accessories. Follow these general guidelines for customization:

Attaching and Removing Accessories:

1. **Interchangeable Hands:** Gently pull the existing hand from the wrist joint. Align the desired new hand (e.g., a fist or a hand designed to hold a weapon) with the wrist joint and push firmly until it clicks into place.
2. **Weapon Attachment:** For weapons like swords or guns, ensure the figure's hand is the appropriate type (e.g., an open grip hand). Carefully slide the weapon into the figure's grip.
3. **Back-Mounted Accessories:** Some figures may include back-mounted accessories like sheaths for swords. Align these with the designated slots on the figure's back and press gently.

Always apply gentle pressure when attaching or removing parts to avoid damage. If a part feels too tight, do not force it.

Detailed Assembly Video:

Your browser does not support the video tag.

Video: A comprehensive guide demonstrating the assembly process for the T13 action figure, including attaching various components and accessories. This video is provided by FoxVilla.

POSING AND ARTICULATION

The T13 action figure boasts a full range of articulation, allowing for dynamic and expressive poses. Each joint is designed to move smoothly. To pose your figure:

- **Joint Movement:** Gently manipulate the joints at the neck, shoulders, elbows, wrists, torso, hips, knees, and ankles to achieve desired positions.
- **Stability:** For complex or action-oriented poses, ensure the figure's balance. You may need to adjust the feet and leg positions to maintain stability.
- **Experimentation:** Explore the full range of motion to discover unique poses for display or play.



Image: The FoxVilla T13 Titan 13 Action Figure showcasing its articulation in a dynamic standing pose.



Image: A collection of FoxVilla T13 Titan 13 Action Figures in different colors and action poses, demonstrating their versatility.

CARE AND MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to gently wipe dust from the figure. For stubborn dirt, a slightly damp cloth with mild soap can be used, followed by immediate drying. Avoid harsh chemicals or abrasive materials.
- **Storage:** Store the figure away from direct sunlight, extreme temperatures, and high humidity to prevent material degradation or discoloration.
- **Joint Care:** If joints become stiff, gently work them back and forth. Avoid excessive force, which can lead to breakage.
- **Small Parts:** Keep all small accessories and interchangeable parts in a safe, designated container to prevent loss and ensure they are out of reach of small children.

TROUBLESHOOTING

Problem	Solution
Parts are difficult to attach/detach.	Ensure proper alignment. Apply gentle, steady pressure. Avoid twisting or excessive force. If parts are very stiff, a small amount of lubricant (e.g., silicone-based) can be applied to the joint, but test on an inconspicuous area first.
Figure does not stand stably.	Adjust the leg and foot articulation to find a balanced center of gravity. Experiment with different foot angles and leg stances.
Joints feel loose.	Over time, joints may loosen with frequent posing. This is normal wear. For minor looseness, a small amount of clear nail polish or a similar non-permanent adhesive applied to the ball joint and allowed to dry can add friction.

SPECIFICATIONS

- **Product Dimensions:** 4 x 2 x 8 inches
- **Item Weight:** 0.16 ounces
- **Model Number:** T13
- **Manufacturer:** FoxVilla
- **Recommended Age:** 7 years and up
- **Materials:** PETG and PLA (3D Printed)

PRODUCT SHOWCASE VIDEOS

Your browser does not support the video tag.

Video: A promotional video from FoxVilla showcasing the T13 action figure's features and articulation.

Your browser does not support the video tag.

Video: Another video from FoxVilla demonstrating the versatility and posing capabilities of the Dummy 13 Action Figure.

WARRANTY AND SUPPORT

For warranty information, product support, or to inquire about replacement parts, please contact FoxVilla customer service through the retailer where the product was purchased. Please retain your proof of purchase for all warranty claims.

You can also visit the official FoxVilla brand page for additional resources:[FoxVilla Brand Page](#)