

BlitzWolf BW-V3Mini

BlitzWolf BW-V3 Mini LED Projector User Manual

Model: BW-V3Mini

INTRODUCTION

Welcome to the user manual for your new BlitzWolf BW-V3 Mini LED Projector. This manual provides comprehensive instructions on how to set up, operate, maintain, and troubleshoot your device. Please read this manual carefully before using the projector to ensure optimal performance and safety.

IMPORTANT SAFETY INSTRUCTIONS

- Always place the projector on a stable, level surface to prevent it from falling.
- Do not block the ventilation openings. Ensure adequate airflow around the projector to prevent overheating.
- Do not look directly into the projector lens when the lamp is on, as the bright light can damage your eyes.
- Keep the projector away from water or other liquids. Do not operate in wet environments.
- Use only the power adapter supplied with the projector.
- Unplug the projector during lightning storms or when unused for long periods.
- Do not attempt to repair the projector yourself. Refer all servicing to qualified service personnel.

PACKAGE CONTENTS

Please check the package contents upon unboxing to ensure all items are present:

- BlitzWolf BW-V3 Mini LED Projector
- Power Adapter
- Remote Control
- HDMI Cable
- User Manual (this document)

PRODUCT OVERVIEW

Familiarize yourself with the various parts of your BlitzWolf BW-V3 Mini LED Projector.



Image 1: Front view of the BlitzWolf BW-V3 Mini LED Projector, showing the lens, control buttons, and a smartphone resting on its top surface, demonstrating its compact design and connectivity.



Image 2: Side view of the BlitzWolf BW-V3 Mini LED Projector, highlighting its compact size and the textured surface, with a smartphone

positioned vertically beside it, illustrating its multimedia capabilities.

Key Components:

- **Projection Lens:** Emits the image.
- **Focus Ring:** Adjusts image clarity.
- **Control Panel:** Buttons for navigation and settings.
- **Input Ports:** HDMI, USB, Audio Out.
- **Ventilation Grilles:** For heat dissipation.
- **Speaker:** Built-in audio output.

SETUP

1. **Power Connection:** Connect the power adapter to the projector's DC IN port and then plug it into a power outlet.
2. **Power On:** Press the power button on the projector or remote control to turn on the device.
3. **Positioning:** Place the projector on a flat surface, perpendicular to the projection screen or wall. Adjust the distance to achieve the desired screen size.
4. **Focus Adjustment:** Rotate the focus ring near the lens until the projected image appears clear and sharp.
5. **Keystone Correction:** If the image appears trapezoidal, use the keystone correction setting in the projector's menu to adjust it to a rectangular shape.

OPERATING INSTRUCTIONS

Connecting to Wi-Fi:

1. Navigate to the "Settings" menu on the projector.
2. Select "Network Settings" or "Wi-Fi".
3. Turn on Wi-Fi and select your desired network from the list.
4. Enter the Wi-Fi password using the on-screen keyboard and confirm.
5. Once connected, you can access online content or screen mirroring features.

Connecting via Bluetooth:

1. Go to the "Settings" menu and select "Bluetooth".
2. Turn on Bluetooth. The projector will start searching for nearby devices.
3. Select your Bluetooth speaker or headphones from the list of available devices to pair.
4. Once paired, audio will be routed through the connected Bluetooth device.

Input Sources:

- **HDMI:** Connect a laptop, gaming console, or media player using an HDMI cable. Select "HDMI" as the input source.
- **USB:** Insert a USB drive to play media files (videos, photos, music). Select "USB" as the input source and browse files.
- **Screen Mirroring:** Use the built-in screen mirroring function (e.g., AirPlay, Miracast) to project content from your smartphone or tablet.

MAINTENANCE

- **Lens Cleaning:** Use a soft, lint-free cloth specifically designed for optical lenses to gently wipe the projector lens. Do not use abrasive cleaners or excessive force.
- **Ventilation Cleaning:** Periodically clean the ventilation grilles with a soft brush or a vacuum cleaner to prevent dust buildup, which can lead to overheating.
- **Storage:** When not in use for extended periods, store the projector in a cool, dry place, away from direct sunlight and extreme temperatures. Use the original packaging or a protective case.
- **Power Off Properly:** Always turn off the projector using the power button and allow it to cool down before unplugging or moving it.

TROUBLESHOOTING

Problem	Possible Cause	Solution
No Power	Power cable not connected; Power outlet faulty.	Ensure power cable is securely connected. Try a different power outlet.
No Image	Incorrect input source; Cable not connected properly.	Select the correct input source (HDMI, USB). Check cable connections.
Blurry Image	Focus not adjusted; Projector too far/close.	Adjust the focus ring. Reposition the projector.
No Sound	Volume too low; Incorrect audio output; Muted.	Increase volume. Check audio settings. Unmute the projector or source device.
Wi-Fi/Bluetooth Connection Issues	Incorrect password; Device out of range; Interference.	Re-enter password. Move devices closer. Reduce interference from other electronics.

SPECIFICATIONS






Feature	Detail
Brand	BlitzWolf
Model Number	BW-V3Mini
Color	Black
Hardware Interface	Bluetooth
Included Components	1 package
Manufacturer	BlitzWolf

WARRANTY AND SUPPORT

Your BlitzWolf BW-V3 Mini LED Projector comes with a **2-year manufacturer's warranty**. For technical support, warranty claims, or any other inquiries, please contact BlitzWolf customer service through their official website or the retailer from whom you purchased the product. Please have your model number (BW-V3Mini) and purchase details ready when contacting support.



Related Documents - BW-V3Mini

	<p>BlitzWolf Selfie Stick User Manual and Product Guide</p> <p>Comprehensive guide to BlitzWolf selfie sticks, covering features, usage, and troubleshooting for models like BW-BS3, BW-BS8, and BW-BS5. Learn about Bluetooth connectivity, tripod functionality, and remote shutter operation.</p>
	<p>BlitzWolf BW-IS20 User Manual and Quick Start Guide</p> <p>Comprehensive user manual and quick start guide for the BlitzWolf BW-IS20 smart device, covering product features, installation, setup, operation, and troubleshooting.</p>
	<p>BlitzWolf BW-V3 Mini LED Projector User Manual</p> <p>User manual for the BlitzWolf BW-V3 Mini LED projector, featuring Wi-Fi and Bluetooth connectivity. Includes product description, specifications, setup, and troubleshooting.</p>
	<p>BlitzWolf BW-WD3 Wireless Charger User Manual</p> <p>Comprehensive user manual for the BlitzWolf BW-WD3 wireless charger, detailing features, specifications, operation, safety, and troubleshooting. Learn how to use your BW-WD3 effectively.</p>
	<p>BlitzWolf BW-VP13 1080p WiFi Projector User Manual</p> <p>User manual for the BlitzWolf BW-VP13 1080p WiFi Projector, covering function overview, quick start, wired and wireless projection methods, input sources, projection distance and screen size, product specifications, and troubleshooting.</p>



[BlitzWolf BW-VC3 Robot Vacuum Cleaner User Manual](#)

Comprehensive user manual for the BlitzWolf BW-VC3 Robot Vacuum Cleaner, covering setup, operation, maintenance, and troubleshooting. Learn how to get the most out of your automated cleaning device.