

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Thunderobot](#) /
- › [Thunderobot KG3089C Wired Mechanical Keyboard User Manual](#)

Thunderobot KG3089C

Thunderobot KG3089C Wired Mechanical Keyboard User Manual

Model: KG3089C (Product ID: JG080G004)

1. INTRODUCTION

Thank you for choosing the Thunderobot KG3089C Wired Mechanical Keyboard. This manual provides essential information for the proper setup, operation, and maintenance of your new keyboard. Please read these instructions carefully before use to ensure optimal performance and longevity of the product.



Image 1.1: Top-down view of the Thunderobot KG3089C Wired Mechanical Keyboard, showcasing its compact layout and vibrant RGB backlighting on the keys.

2. PACKAGE CONTENTS

Please verify that all items are present in the package:

- 1 x Thunderobot KG3089C Wired Mechanical Keyboard
- 1 x User Manual (this document)

3. SETUP INSTRUCTIONS

Follow these steps to connect your keyboard to your computer:

1. **Unpack the Keyboard:** Carefully remove the keyboard from its packaging.
2. **Connect to Computer:** Locate an available USB port on your personal computer. Insert the USB connector of the Thunderobot KG3089C keyboard into the USB port.
3. **Driver Installation:** The keyboard is plug-and-play. Your operating system should automatically detect and install the necessary drivers. No additional software installation is typically required.
4. **Verification:** Once connected, the keyboard's backlighting should illuminate, indicating it is powered on and ready for use. Test by typing in a text editor.



Image 3.1: Angled view of the Thunderobot KG3089C keyboard, showing its compact design and the wired connection extending from the top.

4. OPERATING INSTRUCTIONS

4.1 Basic Keyboard Functions

The Thunderobot KG3089C functions as a standard QWERTY keyboard. All keys perform their labeled functions upon a single press.

4.2 Function (FN) Key Combinations

The **FN** key (Function key) allows access to secondary functions printed on certain keys. To activate these functions, press and hold the **FN** key, then press the desired function key.

- **FN + F1-F12:** These combinations typically control multimedia functions such as volume, media playback, and other system shortcuts. Refer to the specific legends on your keyboard's F-keys.
- **FN + Windows Key:** This combination often locks or unlocks the Windows key to prevent accidental presses during gaming.
- **FN + Specific Keys (e.g., INS, HOME, PGUP, PGDN, DEL, END):** These keys are commonly used to cycle through various backlighting effects and modes.
- **FN + Arrow Keys:** These combinations may adjust backlighting brightness or the speed/direction of lighting effects.

4.3 Backlighting Control

Your keyboard features customizable RGB backlighting. Use the **FN** key in combination with designated keys (often INS, HOME, PGUP, PGDN, DEL, END, and arrow keys) to:

- Change lighting modes (e.g., static, breathing, wave).
- Adjust brightness levels.
- Modify effect speed or direction.

Experiment with these combinations to find your preferred lighting setup.



Image 4.1: Angled view of the Thunderobot KG3089C keyboard, highlighting the RGB lighting strip along its side, which complements the key backlighting.

5. MAINTENANCE

Proper maintenance ensures the longevity and performance of your keyboard:

- **Cleaning:** Disconnect the keyboard from your computer before cleaning. Use a soft, dry cloth to wipe the surface. For dust and debris between keys, use compressed air. Avoid using liquid cleaners directly on the keyboard.
- **Storage:** When not in use for extended periods, store the keyboard in a dry, cool place away from direct sunlight and extreme temperatures.
- **Avoid Spills:** Liquids can severely damage the internal components. Exercise caution when consuming beverages near the keyboard.
- **Cable Care:** Do not bend or crimp the USB cable excessively. This can damage the internal wires and affect connectivity.

6. TROUBLESHOOTING

If you encounter issues with your Thunderobot KG3089C keyboard, refer to the following common solutions:

- **Keyboard Not Responding:**
 - Ensure the USB cable is securely plugged into both the keyboard and the computer.
 - Try connecting the keyboard to a different USB port on your computer.

- Test the keyboard on another computer to determine if the issue is with the keyboard or the computer's USB port.
- Restart your computer.
- **Backlighting Not Working or Incorrect:**
 - Check if the backlighting is turned off or set to the lowest brightness level using the FN key combinations.
 - Ensure the keyboard is properly connected and receiving power.
 - If a specific key's backlight is not working, it might indicate a hardware issue.
- **Keys Not Registering or Double-Typing:**
 - Ensure no debris is lodged under the keycap. Gently remove the keycap (if designed to be removable) and clean the switch area.
 - If the issue persists across multiple keys, consider updating your computer's USB drivers or testing on another system.

If these steps do not resolve the issue, please contact Thunderobot customer support for further assistance.

7. SPECIFICATIONS

Key technical specifications for the Thunderobot KG3089C Wired Mechanical Keyboard:


Feature	Specification
Brand	Thunderobot
Model Name	KG3089C
Product Identifier	JG080G004
Connectivity Technology	Wired (USB)
Keyboard Description	Mechanical
Switch Type	Click (Blue Switch)
Compatible Devices	Personal Computer
Material	Plastic
Color	Black
Weight	850 g
Power Source	Electric Cable


8. WARRANTY AND SUPPORT

Thunderobot products are designed and manufactured to the highest quality standards. For information regarding warranty coverage, terms, and conditions, please refer to the warranty card included with your product or visit the official Thunderobot website.

For technical support, product inquiries, or service requests, please contact Thunderobot customer support through their official channels. Details can typically be found on the product packaging or the company's


Related Documents - KG3089C

 <p>THUNDERROBOT KEYBOARD USER MANUAL 键盘 使用手册 ONCE81</p> <p>© 2024 Thunderobot. All rights reserved.</p>	<p>Thunderobot ONCE81 Keyboard User Manual</p> <p>User manual for the Thunderobot ONCE81 keyboard, detailing its features, setup, functions, and safety information in multiple languages.</p>
 <p>THUNDERROBOT</p> <p>Руководство пользователя Қолданушы нұсқасы</p> <p>Игровой контроллер Olayn kontrolleyeri G70</p>	<p>Thunderobot G70 Gaming Controller User Manual</p> <p>Comprehensive user manual for the Thunderobot G70 gaming controller, covering setup, features, connectivity options for PC, Android, iOS, and Nintendo Switch, and software customization with KeyLinker.</p>
 <p>THUNDERROBOT</p> <p>ML602</p>	<p>Thunderobot ML602 Gaming Mouse User Manual Setup and Features</p> <p>Official user manual for the Thunderobot ML602 gaming mouse by Qingdao Thunderobot Technology Co.,Ltd. Learn about setup, specifications, features, and usage for this high-performance gaming peripheral.</p>
 <p>THUNDERROBOT</p> <p>G80</p>	<p>Thunderobot G80 Gaming Controller User Manual</p> <p>Comprehensive user manual for the Thunderobot G80 gaming controller, covering setup, features, customization, and troubleshooting for PC, Switch, Android, and iOS devices.</p>
 <p>BOYI</p> <p>68</p>	<p>BOYI 68 Mini Keyboard User Manual: Features, Connectivity, and Specifications</p> <p>Comprehensive user manual for the BOYI 68 Mini Keyboard, detailing function key combinations, 2.4G and Bluetooth connectivity, backlit modes, compatibility, electrical specifications, and warranty information.</p>
 <p>THUNDERROBOT</p> <p>G45</p>	<p>Thunderobot G45 Pro Gaming Controller User Manual</p> <p>User manual for the Thunderobot G45 Pro gaming controller, detailing setup, connectivity options (wired, Bluetooth, 2.4G), button layout, and safety instructions for PC, Android, iOS, and Nintendo Switch.</p>



[\[pdf\]](#)

plpl Instrukcja obsługi pol Thunderobot KG3089C mechanikus billentyűzet Blue Switch fekeete 50399 33825 9fc299eaeab0dc44cd02238977663f8b puputeve hu media wysiwyg attachments ||| Klawiatura mechaniczna Thunderobot **KG3089C**, Blue Switch Instrukcja obsługi INFORMACJE DOTYCZCE BEZPIECZESTWA PRZED UYCIEM I OBSLUG URZDZENIA NALEY PRZECZYTA I POSTPOWA ZGODNIE Z PONISZYMI RODKAMI OSTRONOCI, ABY UNIKN NIEBEZPIECZNYCH LUB NIEZGODNYCH Z PRAWEM SYTUACJI. 1. Naley uywa urzdzenia w temp... lang:pl score:34 filesize: 2.98 M page_count: 6 document date: 2024-04-16



[\[pdf\]](#) User Manual Accessories

KG3089 10 2023 User manual eng Thunderobot KG3089C mechanikus billentyűzet Blue Switch fekeete 50400 33825 894fdf85e2e2787afde269ea31f1f8d7 puputeve hu media wysiwyg attachments ||| MECHANICAL KEYBOARD KG3089 USER MANUAL Please read the manual carefully before using this product and keep it for reference. SECURITY INFORMATION BEFORE USING AND OPERATING THE EQUIPMENT, PLEASE READ AND FOLLOW THE PRECAUTION BELOW TO ENSURE THAT THE EQUIPMENT IS PERFORMING BEST AND TO AVOID DANGER... lang:en score:20 filesize: 3.2 M page_count: 1 document date: 2024-04-16