Manuals+

Q & A | Deep Search | Upload

manuals.plus /

- BlitzWolf /
- > Blitzwolf BW-CML5 Monitor Light Bar User Manual

BlitzWolf BW-CML5

Blitzwolf BW-CML5 Monitor Light Bar User Manual

Model: BW-CML5

1. Introduction

This manual provides detailed instructions for the safe and efficient use of your Blitzwolf BW-CML5 Monitor Light Bar. Please read this manual thoroughly before operating the device and retain it for future reference.

2. PACKAGE CONTENTS

Please check the package contents upon opening to ensure all items are present and undamaged. If any items are missing or damaged, please contact customer support.

- Blitzwolf BW-CML5 Monitor Light Bar
- · Wireless Remote Control
- USB Power Cable
- · User Manual (this document)

3. SAFETY INSTRUCTIONS

To ensure safe operation and prevent damage, please observe the following safety precautions:

- Do not expose the device to water or excessive moisture.
- Avoid placing the device near heat sources or in direct sunlight.
- Do not attempt to disassemble or repair the device yourself. Refer all servicing to qualified personnel.
- Use only the provided USB power cable or a certified equivalent.
- · Keep out of reach of children.
- Ensure the light bar is securely attached to the monitor to prevent accidental falls.

4. SETUP AND INSTALLATION

Follow these steps to set up your monitor light bar:

1. **Attach the Light Bar:** Gently place the light bar on top of your monitor. The adjustable clip mechanism should securely grip the top edge of the monitor. Ensure the light source faces

downwards towards your desk.

- Connect Power: Connect the USB power cable to the light bar's power input port. Plug the other end
 of the USB cable into a USB port on your computer or a compatible USB power adapter (5V/1A
 recommended).
- 3. **Position the Remote Control:** Place the wireless remote control on your desk within easy reach. The remote operates wirelessly and does not require direct line of sight to the light bar.




Figure 1: The Blitzwolf BW-CML5 Monitor Light Bar attached to a monitor, with its wireless remote control placed on a desk. This image illustrates the typical setup of the product.

5. OPERATING INSTRUCTIONS

The Blitzwolf BW-CML5 is controlled via its wireless remote. Familiarize yourself with the remote's functions:



Figure 2: A close-up view of the wireless remote control for the Blitzwolf BW-CML5 Monitor Light Bar, showing the central rotary knob and three "DIY" preset buttons.

- Power On/Off: Press the central rotary knob once to turn the light bar on or off.
- Adjust Brightness: Rotate the central knob clockwise to increase brightness and counter-clockwise to decrease brightness.
- Adjust Color Temperature: Press and hold the central knob for approximately 2 seconds. While
 holding, rotate the knob to cycle through different color temperature settings (e.g., warm white,
 neutral white, cool white). Release the knob to set the desired temperature.
- **DIY Preset Buttons (DIY1, DIY2, DIY3):** These buttons allow you to save and recall your preferred brightness and color temperature settings.
 - a. **To Save a Preset:** Adjust the light bar to your desired brightness and color temperature. Then, press and hold one of the DIY buttons (DIY1, DIY2, or DIY3) for approximately 3 seconds until the light blinks, indicating the setting has been saved.
 - b. **To Recall a Preset:** Simply press the corresponding DIY button (DIY1, DIY2, or DIY3) once to activate the saved setting.

6. MAINTENANCE

Proper maintenance ensures the longevity of your device:

- Cleaning: Disconnect the power before cleaning. Use a soft, dry cloth to wipe the light bar and remote control. Do not use abrasive cleaners or solvents.
- **Storage:** When not in use for extended periods, store the device in a cool, dry place, away from direct sunlight and extreme temperatures.

7. TROUBLESHOOTING

If you encounter issues with your Blitzwolf BW-CML5, please refer to the following common problems and solutions:

| Problem | Possible Cause | Solution |
|--------------------------------------|---|--|
| Light bar does not turn on. | No power, loose connection, remote battery low. | Check USB power cable connection. Ensure USB power source is active. Replace remote control batteries if applicable (check remote manual for battery type). |
| Remote control is unresponsive. | Remote battery low, interference, not paired. | Replace remote control batteries. Move remote closer to the light bar. If issues persist, refer to the remote's specific pairing instructions (if any, usually automatic for these devices). |
| Light flickers or dims unexpectedly. | Insufficient power supply, faulty cable. | Ensure the USB power source provides sufficient power (5V/1A recommended). Try a different USB port or power adapter. Replace the USB cable if necessary. |

If the problem persists after trying these solutions, please contact Blitzwolf customer support for further assistance.

8. SPECIFICATIONS

| Model | BW-CML5 |
|--------------------------------|------------------|
| Brand | BlitzWolf |
| Product Dimensions (L x W x H) | 10 x 5 x 1.27 cm |
| Product Weight | 100 g |
| Input Voltage | 5V (via USB) |
| Color | Black |

9. WARRANTY AND SUPPORT

Blitzwolf products are designed and manufactured to the highest quality standards. For information regarding warranty coverage, technical support, or service inquiries, please refer to the warranty card included with your product or visit the official Blitzwolf website. Please have your model number (BW-CML5) and purchase information ready when contacting support.

For further assistance, you may contact Blitzwolf customer service through their official channels.

Related Documents - BW-CML5

