Baby Born 836392

BABY born Emma 43 cm Baby Doll Instruction Manual

Model: 836392

Introduction

Welcome to the world of BABY born Emma! This 43 cm baby doll offers 10 lifelike functions designed to provide an engaging and nurturing play experience for children aged 3 years and older. Emma operates completely without batteries, relying on mechanical and water-activated features. This manual provides detailed instructions for setting up, operating, and maintaining your BABY born Emma doll.



Image: BABY born Emma doll with her complete set of accessories, including a romper, hat, potty, nappy, plate, spoon, bottle, magic dummy, birth pass, and friendship bracelets.

What's Included

Your BABY born Emma doll comes with the following items:

- BABY born Emma 43 cm doll
- Romper
- Hat
- Potty
- Nappy
- Plate
- Spoon
- Bottle

- Magic Dummy
- Birth Pass
- Friendship Bracelets (one for child, one for doll)

Setup

BABY born Emma is designed to function without batteries. No battery installation is required for any of her features.

1. **Unpacking:** Carefully remove all items from the packaging. Dispose of packaging materials responsibly.
2. **Initial Cleaning:** Before first use, it is recommended to wipe the doll with a damp cloth. For detailed cleaning instructions, refer to the Maintenance section.
3. **Dressing Emma:** Dress Emma in her romper and hat. The clothes are designed for easy removal and dressing.

Operating Instructions

Emma features 10 interactive functions to enhance playtime:

1. Drinking

Fill Emma's bottle with fresh water. Place the bottle in her mouth and gently squeeze to allow her to drink. Ensure she is held in an upright position while drinking.



Image: A child holding Emma and feeding her water from the included bottle.

2. Crying

After Emma drinks water, she can cry real tears. Gently squeeze her upper body or head to make tears appear from her eyes. Comfort her with the magic dummy or a gentle hug.

3. Eating (Water Magic Plate)

Emma can 'eat' using her special water magic plate. Pour a small amount of water onto the designated area of the plate. Watch as a delicious meal with a cute face magically appears. Use the spoon to pretend-feed Emma.



Image: The water magic plate, demonstrating how a meal design appears when water is applied.

4. Potty Training

After Emma drinks or 'eats', place her on her potty. Gently press her stomach to simulate her 'small business' (wetting) or 'big business' (pooping), which will appear on the potty's surface thanks to the water magic feature.



Image: Emma's pink potty, illustrating the water magic feature that reveals a 'big business' design.

5. Nappy Use

Emma can wear her nappy. After using the potty or if she has 'wet' herself, you can change her nappy for a fresh one, just like a real baby.



Image: A child carefully changing the nappy of the BABY born Emma doll.

6. Sleeping (Magic Dummy)

Emma's eyes can open and close. Insert the magic dummy into her mouth. To close her eyes, turn the dummy 180 degrees. To open them, turn it back. When laid down without the dummy, Emma's eyes will also close naturally.



Image: Emma doll demonstrating the magic dummy feature, with her eyes shown both open and closed.

7. Bathing

Emma is fully bathable. You can take her into the bath for water play. Ensure all water is drained from her body after bathing to prevent mold or mildew. Refer to the Maintenance section for proper drainage.



Image: Emma doll enjoying a bath in a small, bubbly tub, highlighting her bathable feature.

8. Flexible Limbs

Emma's arms and legs are highly flexible, allowing for various poses and interactive play. Her knees are articulated, enabling her to sit comfortably or be posed in different positions.

Maintenance

Cleaning the Doll

To ensure Emma remains clean and hygienic:

- For general cleaning, wipe the doll's surface with a damp cloth and mild soap. Rinse thoroughly with clean water.
- After bathing, it is crucial to drain all water from the doll. To facilitate this, the doll's leg can be removed to create a larger opening for water drainage. Gently pull the leg to detach it, allow water to drain completely, then reattach the leg firmly.
- Allow the doll to air dry completely before storing or dressing.

Care of Accessories

Clean accessories (bottle, plate, spoon, potty) with warm soapy water and rinse thoroughly. Allow them to air dry. The romper and hat can be hand-washed with mild detergent and air-dried.

Storage

Store Emma and her accessories in a clean, dry place away from direct sunlight and extreme temperatures to prolong their lifespan.

Troubleshooting

If Emma's functions do not operate as expected, consider the following:

- **No Tears/Potty Function:** Ensure Emma has been given enough water to drink. The water magic features rely on sufficient water.
- **Eyes Not Closing/Opening:** Verify the magic dummy is correctly inserted and rotated 180 degrees. If laying her down, ensure she is on a flat surface.
- **Water Drainage Issues:** If water remains inside after bathing, ensure the leg is removed as described in the Maintenance section for thorough drainage.
- **General Malfunction:** Re-read the relevant operating instructions carefully. If issues persist, contact customer support.

Specifications

Attribute	Detail
Product Dimensions	7.09 x 13.78 x 4.72 inches
Item Weight	3.85 pounds
Model Number	836392
Manufacturer Recommended Age	36 months - 10 years
Power Source	No batteries required

Safety Information

Please note: Not suitable for children under 36 months, contains small parts that can be swallowed. Choking hazard.

Warranty and Support

For information regarding warranty, returns, or customer support, please refer to the product packaging or contact the manufacturer, BABY Born, directly through their official website or customer service channels. Keep your proof of purchase for any warranty claims.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question

and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question