

Visual Land Soundwave A1

Visual Land Soundwave A1 Active Noise Cancelling Earbuds User Manual

Model: Soundwave A1 (VLA1V2GEGRY)

INTRODUCTION

Thank you for choosing the Visual Land Soundwave A1 Active Noise Cancelling Earbuds. These earbuds are designed to provide a high-quality audio experience with advanced features such as active noise cancellation, long battery life, and a water-resistant design. This manual provides detailed instructions on how to set up, operate, and maintain your Soundwave A1 earbuds.

PACKAGE CONTENTS

Please check the package for the following items:

- Visual Land Soundwave A1 Earbuds (Left and Right)
- Charging Case
- USB-C Charging Cable
- Additional Ear Tip Sizes (Small, Medium, Large)
- User Manual (this document)

PRODUCT OVERVIEW



The Soundwave A1 earbuds stored in their charging case, with the lid closed. The case features indicator lights on the front.



The Soundwave A1 earbuds resting inside their open charging case, showing the charging contacts and indicator lights.



A side profile view of the Soundwave A1 earbuds, highlighting their ergonomic design and ear tip.



A rear view of the Soundwave A1 earbuds, showing the stem and microphone placement.



The Soundwave A1 charging case with the lid open, one earbud removed and placed beside it, illustrating the compact design.

SETUP

1. Charging the Earbuds and Case

Before first use, fully charge the earbuds and charging case. Place the earbuds into the charging case and close the lid. Connect the USB-C charging cable to the charging port on the case and plug the other end into a USB power adapter (not included).

- The indicator lights on the charging case will show the charging status.
- A full charge takes approximately 1.5 hours for the case and earbuds.
- **Fast Charging:** 15 minutes of charging provides up to 5 hours of playtime.
- Total playtime with the charging case is up to 40 hours.

2. Selecting Ear Tips

The Soundwave A1 earbuds come with three sizes of ear tips (Small, Medium, Large). Choose the size that provides the most secure and comfortable fit for optimal sound quality and noise cancellation performance.

- Gently pull off the pre-installed ear tips.
- Select a new pair of ear tips and push them onto the earbud nozzle until they are securely attached.

3. Pairing with a Bluetooth Device

The earbuds will automatically enter pairing mode when first removed from the charging case.

1. Open the charging case. The earbuds will power on and enter pairing mode (indicator lights will flash).
2. On your device (smartphone, tablet, etc.), go to the Bluetooth settings.
3. Search for available devices and select "Visual Land Soundwave A1".
4. Once connected, the earbud indicator lights will stop flashing, and you will hear a confirmation tone.
5. For subsequent use, the earbuds will automatically connect to the last paired device when removed from the case.

OPERATING INSTRUCTIONS

Power On/Off

- **Power On:** Open the charging case, or long-press the touch control area on both earbuds for 3 seconds.
- **Power Off:** Place the earbuds back into the charging case and close the lid, or long-press the touch control area on both earbuds for 5 seconds.

Active Noise Cancellation (ANC) Modes

The Soundwave A1 features 6-microphone Active Noise Cancellation with multiple modes:

- **ANC On:** Reduces ambient noise for an immersive listening experience.
- **Transparency Mode:** Allows you to hear your surroundings while still enjoying your audio, enhancing awareness.
- **ANC Off:** Standard audio mode without noise cancellation or transparency.

To switch modes: Tap and hold the touch control area on either earbud for 2 seconds to cycle through ANC On, Transparency Mode, and ANC Off.

Touch Controls

The touch-sensitive area on each earbud allows for easy control of music and calls.

Function	Action
Play/Pause Music	Single tap on either earbud
Next Track	Double tap on the right earbud
Previous Track	Double tap on the left earbud
Volume Up	Triple tap on the right earbud
Volume Down	Triple tap on the left earbud
Answer/End Call	Single tap on either earbud
Reject Call	Tap and hold on either earbud for 2 seconds
Activate Voice Assistant	Tap and hold on either earbud for 3 seconds (when not on a call)
Switch ANC Modes	Tap and hold on either earbud for 2 seconds

MAINTENANCE

- **Cleaning:** Regularly clean the earbuds and charging case with a soft, dry, lint-free cloth. Do not use harsh chemicals or abrasive materials.
- **Ear Tips:** Remove ear tips and clean them with water and mild soap if necessary. Ensure they are completely dry before reattaching.
- **Charging Contacts:** Ensure the charging contacts on both the earbuds and the case are clean and free of debris to ensure proper charging.
- **Water Resistance:** The earbuds are IPX5 water-resistant, meaning they can withstand splashes and sweat. Do not submerge them in water or expose them to strong jets of water. Dry them thoroughly after exposure to moisture.
- **Storage:** When not in use, store the earbuds in their charging case to protect them and keep them charged. Store in a cool, dry place away from extreme temperatures.

TROUBLESHOOTING

Problem	Possible Solution
---------	-------------------

Problem	Possible Solution
Earbuds not pairing	Ensure earbuds are charged. Turn off Bluetooth on your device and turn it back on. Forget "Visual Land Soundwave A1" in your device's Bluetooth settings and try pairing again. Place earbuds back in the case, close the lid, wait 10 seconds, then open to re-enter pairing mode.
No sound from one earbud	Ensure both earbuds are charged. Place both earbuds back in the charging case, close the lid, then take them out again. Try resetting the earbuds (refer to the full manual for specific reset instructions if available, otherwise contact support).
Charging case not charging	Check the USB-C cable and power adapter. Ensure the charging port on the case is clean and free of debris. Try a different USB-C cable and power adapter.
Poor sound quality or weak ANC	Ensure ear tips provide a secure seal in your ear canal. Try different sizes. Clean the earbud nozzles and ear tips. Ensure ANC mode is correctly activated.

SPECIFICATIONS

Feature	Detail
Model Name	SOUNDWAVE A1 V2
Connectivity Technology	Bluetooth 5.3, Wireless
Noise Control	Active Noise Cancellation (ANC)
Microphones	6-mic system
Water Resistance Level	IPX5 (Water Resistant)
Total Playtime (with case)	Up to 40 Hours
Fast Charging	15 minutes charge for up to 5 hours playtime
Control Method	Touch Controls
Ear Tip Sizes	Small, Medium, Large
Charging Port	USB-C
Carrying Case Battery Capacity	500 mAh
Item Weight	2 Ounces (total)
Material	Plastic
Compatible Devices	iOS and Android devices with Bluetooth support

SAFETY INFORMATION

Please read and follow these safety guidelines to ensure safe operation and prolong the lifespan of your earbuds:





- Do not expose earbuds to extreme temperatures, humidity, or corrosive environments.
- Avoid dropping, impacting, or disassembling the device.
- Do not use unauthorized chargers or cables.
- Avoid listening at high volumes for extended periods to prevent hearing damage.
- Use caution when using earbuds in situations requiring awareness of your surroundings (e.g., driving, cycling).
- Keep out of reach of children and pets.



WARRANTY AND SUPPORT

Visual Land products are designed for reliability and performance. For warranty information, technical support, or customer service inquiries, please refer to the official Visual Land website or contact their customer support directly. Please retain your proof of purchase for warranty claims.


For further assistance, visit: [Visual Land Store on Amazon](#)

Related Documents - Soundwave A1

	<p>Visual Land SOUNDWAVE A1 ANC Earbuds: Quick Start Guide and Warranty Information</p> <p>Get started with your Visual Land SOUNDWAVE A1 ANC Earbuds. This guide provides essential safety information, product operation instructions, smart touch controls, and details on the limited one-year warranty.</p>
	<p>Visual Land SOUNDWAVE A1 Essential Earbuds: Quick Start Guide, Warranty, and Safety Information</p> <p>Comprehensive guide for Visual Land SOUNDWAVE A1 Essential ANC earbuds, covering setup, operation, music/call controls, voice assistant, safety precautions, and the limited one-year warranty.</p>
	<p>Visual Land Prestige P10+ Limited Warranty and FCC Information</p> <p>Detailed limited warranty information for the Visual Land Prestige P10+ tablet, including coverage, limitations, user responsibilities, service options, and FCC compliance details.</p>
	<p>Visual Land Prestige Pro 7D Reset Button Replacement Guide</p> <p>Step-by-step instructions for replacing the reset button on a Visual Land Prestige Pro 7D tablet, including necessary tools and procedures for repair.</p>

	<p>Visual Land Prestige P10+/P11 Pro/10QH+ Kids K10+/K11 Pro Quick Start Guide and Warranty Information</p> <p>This document provides a quick start guide and warranty information for Visual Land Prestige P10+/P11 Pro/10QH+ and Kids K10+/K11 Pro tablets. It covers charging instructions, Google Kids Space setup, general setup procedures, troubleshooting, and FCC compliance.</p>
	<p>Visual Land Prestige Tablet Limited Warranty and Quick Start Information</p> <p>Detailed warranty information and quick start guide for Visual Land Prestige tablets, covering terms, conditions, user responsibilities, and regulatory compliance.</p>


Documents - Visual Land – Soundwave A1



[Visual Land SOUNDWAVE A1 ANC Earbuds: Quick Start Guide and Warranty Information](#)

Get started with your Visual Land SOUNDWAVE A1 ANC Earbuds. This guide provides essential safety information, product operation instructions, smart touch controls, and details on the limited one-year warranty.

lang:en score:30 filesize: 704.05 K page_count: 2 document date: 2021-12-09



[\[pdf\] User Manual Instructions Warranty](#)

Garner User manual VISUAL LAND INC SOUNDWAVEA1V2 SI9SOUNDWAVEA1V2 soundwavea1v2 SAFETY INFORMATION WARNING: Using earbuds at high volumes for extended periods of time will result i ... successor in title is the warrantor under this Warranty. Quick Start Guide Warranty Information **SOUNDWAVE A1** v2 ...

lang:en score:29 filesize: 203.52 K page_count: 2 document date: 2023-12-01



[Visual Land SOUNDWAVE A1 Essential Earbuds: Quick Start Guide, Warranty, and Safety Information](#)

Comprehensive guide for Visual Land SOUNDWAVE A1 Essential ANC earbuds, covering setup, operation, music/call controls, voice assistant, safety precautions, and the limited one-year warranty.


lang:en score:25 filesize: 1.49 M page_count: 2 document date: 2025-02-06



[\[pdf\] Agent Authorization](#)

PLEASE PRINT ON COMPANY LETTERHEAD MiCOM Labs Inc QMS Agent Authorization Rev 1 0 VISUAL LAND INC SOUNDWAVEA1 Bluetooth headset SI9SOUNDWAVEA1 soundwavea1 VISUAL LAND INC. Agent Authorization Company: VISUAL LAND INC. Address: 17785 Center Court Dr. Suite 670, Cerritos, CA 90703 United States Product Name: Bluetooth headset Trade Mark: VISUAL LAND Model Number: **SOUNDWAVE A1** FCC ID: SI9SOUNDWAVEA1 We authorize MiCOM Labs Inc., 575 Boulder Court, Pleasa...

lang:en score:21 filesize: 16.76 K page_count: 1 document date: 2021-12-03




[pdf] Test Report

Shenzhen Sunspring Electronics Co Ltd Keyboard OJWCG107C Violet Wang Test Report VISUAL LAND
INC SOUNDWAVEA1 Bluetooth headset SI9SOUNDWAVEA1 soundwavea1
Shenzhen LCS Compliance Testing Laboratory Ltd. FCC ID: SI9SOUNDWAVEA1
Report No.: LCS211122016AEA FCC TEST REPORT FOR VISUAL LAND INC.
Bluetooth headset Test Model: **SOUNDWAVE A1** Prepared for Address Prepared by
Address Tel Fax Web Mail Date of receipt of test sample Number of tested samples
Sampl...
lang:en score:18 filesize: 1.03 M page_count: 36 document date: 2021-12-03



[pdf] SAR Rating

tolsevers RF Exposure VISUAL LAND INC SOUNDWAVEA1 Bluetooth headset SI9SOUNDWAVEA1
soundwavea1
Shenzhen LCS Compliance Testing Laboratory Ltd. FCC ID: SI9SOUNDWAVEA1
FCC RF Exposure Evaluation ... ion Software Version Exposure category EUT Type
Device Type : SI9SOUNDWAVEA1 : Bluetooth headset : **SOUNDWAVE A1** Headset:
Input: DC 5V DC 3.7V by Li-ion Battery 30mAh : Charging box: Input: DC 5V DC ...
lang:en score:15 filesize: 476.24 K page_count: 3 document date: 2021-12-03



[pdf] Test Report

Tonscend Test Report VISUAL LAND INC SOUNDWAVEA1 Bluetooth headset SI9SOUNDWAVEA1
soundwavea1
Shenzhen LCS Compliance Testing Laboratory Ltd. FCC ID: SI9SOUNDWAVEA1
Report No.: LCS211122016AEA Appendix A RF Test Data for BT Conducted
Measurement Product Name: Bluetooth headset Test Model: **SOUNDWAVE A1**
Temperature: Relative Humidity: ATM Pressure: Test Engineer: Supervised by:
Environm...
lang:es score:14 filesize: 5.83 M page_count: 45 document date: 2021-12-03