

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Outsunny](#) /

› [Outsunny 3.7x3m Outdoor Gazebo with Double Roof and Mosquito Nets - Instruction Manual](#)

## Outsunny 84C-452V00BG

# Outsunny 3.7x3m Outdoor Gazebo with Double Roof and Mosquito Nets

Instruction Manual - Model: 84C-452V00BG

## 1. INTRODUCTION

---

Thank you for choosing the Outsunny 3.7x3m Outdoor Gazebo. This manual provides essential information for the safe assembly, operation, and maintenance of your new gazebo. Please read these instructions carefully before assembly and retain them for future reference.



Figure 1: Outsunny 3.7x3m Outdoor Gazebo in use.

## 2. SAFETY INFORMATION

To ensure safe use and prevent injury, please observe the following:

- **Two-Person Assembly:** It is highly recommended that assembly be performed by two people for safety and efficiency.
- **Secure Anchoring:** For increased stability, always secure the gazebo to the ground using the provided stakes or expansion screws. Failure to do so may result in the gazebo overturning in windy conditions.
- **Weather Conditions:** This gazebo is designed for general outdoor use. In severe weather conditions such as heavy rain, strong winds, or snow, disassemble the gazebo to prevent damage and ensure safety.
- **Clearance:** Ensure adequate clearance around the gazebo during assembly and use.
- **Supervision:** Keep children and pets away from the assembly area.
- **Regular Inspection:** Periodically check all connections and anchoring points to ensure they remain secure.

### 3. PACKAGE CONTENTS

---

Please refer to the packaging and the included parts list for a complete inventory of all components. Ensure all parts are present and undamaged before beginning assembly. If any parts are missing or damaged, contact customer support.

### 4. ASSEMBLY INSTRUCTIONS

---

Follow these steps for proper assembly of your Outsunny Gazebo. It is recommended to have two people for this process.

1. **Unpack Components:** Carefully unpack all parts and lay them out on a clean, flat surface. Verify against the parts list.
2. **Assemble Frame:** Connect the steel frame components according to the diagrams provided in your specific assembly guide. Ensure all connections are secure. The frame is constructed from powder-coated steel for durability.
3. **Install Roof Canopy:** Place the double-layer roof canopy onto the assembled frame. Ensure the canopy is correctly oriented. The double-layer design promotes air circulation and provides UV30+ protection.
4. **Attach Curtains and Mosquito Nets:** Hang the removable curtains and mosquito nets onto the designated tracks or hooks on the frame. The mosquito nets protect against insects, while the curtains offer privacy and sun protection.
5. **Secure to Ground:** Once the gazebo is fully assembled, use the provided ground stakes or expansion screws to firmly anchor each leg to the ground. This is crucial for stability, especially in outdoor environments.



Figure 2: Double roof design for enhanced air circulation.



Figure 3: Details on roof drainage, UV protection, and ground anchoring.

## 5. OPERATING INSTRUCTIONS

---

Your Outsunny Gazebo is designed for versatile outdoor use:

- **Double Roof System:** The double-layer roof with PA coating provides UV30+ protection and allows for better air circulation, keeping the gazebo cooler on hot days. Mesh on the roof vents prevents insects from entering.
- **Removable Curtains:** The gazebo features four removable curtains. These can be drawn to provide shade, reduce glare, and create a private space.
- **Integrated Mosquito Nets:** Four mosquito nets are integrated to protect your space from unwanted insects, allowing you to enjoy the outdoors without disturbance.



Figure 4: Gazebo with mosquito nets for insect protection.



Figure 5: Gazebo with curtains for privacy and sun protection.

## 6. MAINTENANCE

---

Proper maintenance will extend the life of your gazebo:

- **Cleaning:** Clean the canopy and curtains with mild soap and water. Do not use harsh chemicals or abrasive cleaners. Rinse thoroughly and allow to air dry completely before storage.
- **Frame Care:** Inspect the steel frame periodically for any signs of rust or damage. Clean and touch up any scratches on the powder coating to prevent rust.
- **Storage:** In off-season or during prolonged periods of non-use, disassemble the gazebo and store all components in a dry, protected area to prevent weather damage.
- **Fabric Care:** Ensure the fabric is completely dry before folding and storing to prevent mildew.

## 7. TROUBLESHOOTING

---

If you encounter issues with your gazebo, consider the following:

- **Instability:** Ensure all frame connections are tight and the gazebo is properly anchored to the ground

with stakes or expansion screws.

- **Water Accumulation on Roof:** The roof is designed with drainage holes. Ensure these are clear of debris. If water still pools, check the tension of the canopy.
- **Difficulty with Assembly:** Refer back to the assembly diagrams. Ensure you have all parts and are following the steps in the correct order. Two-person assembly is highly recommended.
- **Damaged Fabric:** For minor tears, repair kits may be available. For significant damage, contact customer support for replacement options.

## 8. SPECIFICATIONS

Feature	Detail
Model Number	84C-452V00BG
Overall Dimensions (L x W x H)	370 x 300 x 275 cm (3.7 x 3 x 2.75 meters)
Inner Dimensions (L x W)	324 x 259 cm
Eave Height	192 cm
Weight	42 kg
Frame Material	Powder-coated Steel Alloy
Canopy Material	Polyester with PA coating
UV Protection	UV30+
Water Resistance Level	Waterproof
Shape	Rectangular
Assembly Required	Yes



Figure 6: Detailed dimensions of the gazebo.

## 9. WARRANTY AND SUPPORT

For warranty information or if you require assistance with your Outsunny Gazebo, please contact Outsunny customer service. Keep your purchase receipt and model number (84C-452V00BG) handy for faster service. You can find contact details on the official Outsunny website or through your retailer.