Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Fanbulous Y24FSD0005

Fanbulous 62-Inch Black Ceiling Fan with Lights

Instruction Manual

Model: Y24FSD0005

Introduction

Thank you for choosing the Fanbulous 62-inch Black Ceiling Fan with Lights. This manual provides detailed instructions for the safe installation, efficient operation, and proper maintenance of your new ceiling fan. Please read this manual thoroughly before installation and retain it for future reference.

This ceiling fan features a quiet DC motor, integrated LED lighting with three color temperatures, 6 adjustable wind speeds, a reversible function for year-round use, and a convenient remote control with timer settings. Its dual-sided blades offer both black and walnut finishes to complement various interior styles.

Safety Information

To reduce the risk of electric shock, fire, or personal injury, always follow these basic safety precautions:

- Read all instructions carefully before beginning installation.
- Ensure the power is turned off at the circuit breaker before installation or servicing.
- All wiring must be in accordance with national and local electrical codes. If you are unfamiliar with wiring, consult a qualified electrician.
- The mounting structure must be capable of supporting the weight of the fan (approximately 24.1 pounds).
- Do not operate the fan with damaged blades or housing.
- Keep hands, tools, and other objects away from the fan blades when in operation.
- This fan is suitable for indoor use.

Package Contents

Verify that all components are present before beginning installation:

- Ceiling Fan Motor Housing
- Fan Blades (8 pieces, dual-sided black/walnut finish)
- Downrods (5-inch, 10-inch, 15-inch options)
- Mounting Bracket
- Canopy

- LED Light Kit
- Remote Control with Wall Cradle
- AAA Batteries (2 pieces)
- Hardware Pack (screws, washers, wire nuts)



Figure 1: Included components of the Fanbulous 62-inch ceiling fan.

Setup and Installation

1. Pre-Installation

- Turn off power at the main circuit breaker.
- Ensure the ceiling junction box is securely mounted and capable of supporting the fan's weight.
- Determine the appropriate downrod length (5", 10", or 15") based on your ceiling height. The fan can be installed on a 15° sloped ceiling.

2. Mounting Bracket Installation

1. Attach the mounting bracket to the ceiling junction box using the provided screws and washers. Ensure it is firmly secured.

3. Downrod and Fan Assembly

1. Feed the fan wires through the chosen downrod.
2. Secure the downrod to the fan motor housing.
3. Carefully lift the fan assembly and hang it on the mounting bracket hook.

4. Electrical Wiring

1. Connect the fan's electrical wires to the household wiring according to the wiring diagram in the separate installation guide (if provided) or standard electrical practices (Live to Live, Neutral to Neutral, Ground to Ground). Use the provided wire nuts.
2. Ensure all connections are secure.

5. Canopy and Blade Installation

1. Slide the canopy up and secure it to the mounting bracket, covering the wiring.
2. Attach the 8 fan blades to the motor housing using the provided screws. Choose either the black or walnut side of the blades to face downwards.

6. LED Light Kit Installation

1. Connect the LED light kit wires to the corresponding wires from the fan motor.
2. Secure the light kit to the bottom of the fan motor housing.



Figure 2: Fan dimensions and mounting options for various ceiling types.

Operating Instructions

Your Fanbulous ceiling fan is operated using the included remote control. Ensure the 2 AAA batteries are correctly installed in the remote.

Remote Control Functions:

- **ALL OFF:** Turns off both the fan and the light.
- **FAN ON/OFF:** Turns the fan on or off.
- **Fan Speed (1-6):** Adjusts the fan speed from 1 (lowest) to 6 (highest).
- **LIGHT ON/OFF:** Turns the LED light on or off.
- **Light Color Temperature (CCT):** Cycles through 3000K (Warm Light), 4000K (Neutral Light), and 6000K (Cold White Light).
- **Reverse (R):** Changes the direction of the fan blades for summer (downward airflow) or winter (upward airflow for warm air circulation).
- **Timer (1H/2H/4H):** Sets the fan to turn off automatically after 1, 2, or 4 hours.

Light Memory Function: If the light switch is toggled again after more than 10 seconds, the light color will not change. Quickly toggling the light switch can change the color temperature.




Figure 3: Remote control and key features of the Fanbulous ceiling fan.



Figure 4: LED light color temperature options.



Figure 5: Reversible motor for seasonal use.

Maintenance

Regular maintenance ensures optimal performance and extends the lifespan of your ceiling fan.

- **Cleaning:** To clean the fan, wipe with a soft, damp cloth. Do not use abrasive cleaners or solvents, as these may

damage the finish or electrical components. Ensure power is off before cleaning.

- **Blade Inspection:** Periodically check the fan blades for any signs of damage or imbalance. Ensure all blade screws are tight.
- **Light Cover:** The LED light cover can be gently wiped clean with a soft cloth.

Troubleshooting

If you experience issues with your fan, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Fan does not start	No power to the fan; Loose wire connections; Remote control not paired or batteries dead.	Check circuit breaker; Verify all wire connections are secure; Replace remote batteries or re-pair remote.
Light does not work	Loose wire connection to light kit; LED light kit failure; Remote control issue.	Check light kit wiring; Contact customer support for replacement if LED is faulty; Check remote batteries.
Fan is noisy	Loose screws on fan blades or motor housing; Unbalanced blades; Mounting bracket not secure.	Tighten all screws; Ensure blades are balanced (a balancing kit may be needed); Verify mounting bracket is secure.
Fan does not move enough air	Fan speed set too low; Incorrect fan direction for season.	Increase fan speed using the remote; Ensure fan is in summer mode (downward airflow) for cooling.
Light stays on dimly after turning off	Residual current or compatibility issue with wall switch.	This can sometimes occur with LED lights. Ensure the fan is fully powered off at the wall switch or circuit breaker if not in use. If persistent, contact customer support.

Specifications

Feature	Detail
Brand	Fanbulous
Model Name	Y24FSD0005
Size	62 inch
Color	Black
Product Dimensions	62"D x 62"W x 15"H
Power Source	AC 120V
Wattage (Light)	24 watts (1800LM)
Light Color Temperature	3000K (Warm), 4000K (Neutral), 6000K (Cold White)
Motor Type	DC Motor (Reversible)
Number of Power Levels	6 Fan Speeds

Feature	Detail
Control Method	Remote Control
Timer Settings	1H, 2H, 4H
Item Weight	24.1 pounds
Indoor/Outdoor Usage	Indoor

Warranty and Support

The Fanbulous 62-inch Ceiling Fan comes with a **2-year warranty** from the date of purchase. This warranty covers manufacturing defects and ensures your satisfaction with the product.

For technical assistance, troubleshooting beyond this manual, or warranty claims, please contact Fanbulous customer support. Please have your model number (Y24FSD0005) and purchase information ready when contacting support.

You can typically find support contact information on the Fanbulous official website or through your retailer's customer service portal.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CWTSWM6Z

More documents and user manuals: **https://manuals.plus/**