

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [RETEYUNG](#) /

› [RETEYUNG Sunrise Alarm Clock User Manual](#)

RETEYUNG AJ310

RETEYUNG Sunrise Alarm Clock User Manual

Model: AJ310

1. INTRODUCTION

Thank you for purchasing the RETEYUNG Sunrise Alarm Clock. This multi-functional device combines an alarm clock, sound machine, wake-up light, wireless charging station, and a touch-sensitive bedside lamp. Designed to enhance your sleep experience and simplify your morning routine, it aims to provide a calming and effective way to wake up and manage your daily schedule.

Package Contents:

- RETEYUNG Sunrise Alarm Clock (Main Unit)
- Power Cable
- User Manual



Image: The RETEYUNG Sunrise Alarm Clock, showcasing its integrated wireless charging pad and illuminated lamp.

2. SAFETY INFORMATION

Please read all safety instructions carefully before using this product. Failure to follow these instructions may result in electric shock, fire, or other hazards.


- Do not expose the device to water or excessive humidity.
- Use only the provided power adapter.
- Do not attempt to disassemble, repair, or modify the device. Contact qualified service personnel for assistance.
- Keep the device away from heat sources and direct sunlight.
- Ensure proper ventilation around the device, especially the wireless charging pad, to prevent overheating.
- This device requires continuous power via an adapter; it does not have a built-in battery.

3. SETUP

Product Assembly:

1. **Align the Connector:** Ensure the main body of the alarm clock and the wireless charging pad are side-aligned. Locate the connector on the main unit and the corresponding slot on the wireless charging pad.
2. **Insert the Connector:** Gently insert the connector from the main unit into the slot on the wireless charging pad.
3. **Secure Connection:** Push the main unit firmly in the direction indicated until it is fully seated and aligned with the wireless charging pad. A 'clicking sound' indicates successful installation.
4. **Power Connection:** Connect the provided power cable to the device and plug it into a power outlet.

PRODUCT ASSEMBLY INSTRUCTIONS



- 1.** Align the connector with the slot on the wireless charging pad.



- 2.** Insert the connector into the slot.



- 3.** Push hard in that direction. Until the body and the wireless charging pad are aligned.



- 4.** Product Assembly Instructions.

Image: Detailed assembly steps for connecting the main alarm clock unit to the wireless charging base.

Initial Power On:

Once connected to power, the clock display will illuminate. You may need to set the current time and date.

4. OPERATING INSTRUCTIONS

4.1 Dual Alarm Clock & Sound Machine:

- The device features two independent alarms (Alarm 1 and Alarm 2).
- **Alarm 1:** Offers 15 tones with adjustable volume levels (1-12).
- **Alarm 2:** Provides 15 tones with volume settings (0-12) and includes a wake-up light feature.
- Both alarms can be set to operate simultaneously.
- **Note on Alarm 2 Volume:** At volume 0, Alarm 2 will only use the wake-up light. Volumes 1-12 will combine both sound and light.

DUAL ALARM CLOCKS & WAKE UP LIGHT

Set two separate alarms & Meet your different habits
Wake-up light will get brighter and brighter until the alarm goes off.



AL1 6:30 AM



AL2 8:30 AM
With Wake-up Light
(Lights up 10min before the alarm goes off)

Image: Illustration of the dual alarm functionality, showing Alarm 1 as sound-only and Alarm 2 with a gradual wake-up light.

4.2 Gentle Wake-up Experience (Alarm 2 Only):

- The wake-up light for Alarm 2 gradually increases in brightness over 10 minutes before the set alarm time. This simulates a natural sunrise, providing a calming and less jarring awakening.
- This feature helps reduce morning grogginess and promotes a more refreshed feeling upon waking.

4.3 Wireless Charger for Phone and Headphones:

- The alarm clock features a built-in wireless charging pad on its base.
- Simply place your compatible smartphone or headphones on the charging pad to initiate charging.
- **Important Note:** If the wireless charger is not functioning, please ensure the main unit is fully and correctly connected to the charging pad as per the assembly instructions. An incomplete connection will prevent charging.

4.4 Touchable Desk Lamp:

- The lamp offers 3 distinct light levels: Dim (suitable for night light), Warm (ideal for work/study), and Bright (for general living room illumination).
- The lamp arm is touch-sensitive. Touch any position on the lamp arm to cycle through the 3 brightness levels.
- To turn off the light from any brightness level, long press the lamp arm for 2 seconds.
- The lamp dimensions are approximately 230mm x 215mm.



Image: Demonstrates the three adjustable brightness levels of the touch-sensitive lamp.

4.5 Sunlight Alarm Clock Function (Snooze & Timer):

- **Snooze Function:** After an alarm sounds, short press the snooze button position to activate a 10-minute snooze.
- **Cancel Alarm:** Long press the snooze button position to cancel the current day's alarm.
- **Time Display Brightness:** The snooze button position can also be used to adjust the brightness of the time display. In clock mode, short press the snooze button to cycle through 100% Screen Light, 60% Screen Light, 20% Screen Light, and Screen Light Off.
- **Countdown Timer:** The bedside lamp includes a countdown timer with options for 30, 60, or 90 minutes.

3 LEVEL-SCREEN BRIGHTNESS DIMMING

10 min Sooze, get a little nap for relaxing.
3 Lv Display Dimming, Choose the most comfortable brightness you like



Clock mode - Short press snooze adjust screen brightness

100% Screen Light

60% Screen Light

20% Screen Light

Screen Light Off




Image: Illustrates the snooze function and the four levels of screen brightness adjustment.

4.6 Alarm Setup Notes:

- **Time Format (12-hour):** When setting the time in 12-hour format, ensure the AM/PM indicator is correct. 00:00-12:00 corresponds to AM (when AM light is on), and 13:00-23:59 corresponds to PM.
- **Time Format (24-hour):** For 24-hour format, directly set the time from 00:00-23:59.
- **Turning Off Alarm:** To turn off an alarm, press the corresponding alarm button twice. The alarm indicator light will turn off.
- **Turning On Alarm:** To turn on an alarm, press the corresponding alarm button once. The alarm indicator

light will turn on.

- **Important:** Always select the clock mode before attempting to set or adjust alarms.

4.7 Soothing Nature Sounds:

- The device includes 10 soothing nature sounds to assist with relaxation and sleep. These include Bonfire, Summer, Thunder, Fan, Flowing Water, Rain, Ocean Wave, Music Box, Birdsong, and Clock Ticking.
- Use the dedicated sound button to cycle through and select your preferred sound.



SOOTHING SOUND & COUNTDOWN

10 Soothing Sound - Assisting it effectively easier to fall asleep
Auto-off Time with 30/60/90mins

Image: Visual representation of the 10 soothing nature sounds, including bonfire, summer, thunder, fan, flowing water, rain, ocean wave, music box, birdsong, and clock ticking.

5. MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the surface of the device. Do not use abrasive cleaners, waxes, or solvents.

- **Storage:** If storing the device for an extended period, disconnect it from power and keep it in a cool, dry place.
- **Avoid Liquids:** Do not spray cleaning liquids directly onto the device.

6. TROUBLESHOOTING

Problem	Possible Cause	Solution
Wireless charger not charging.	Main unit not fully connected to the charging pad.	Ensure the main unit is securely connected to the wireless charging pad until a 'clicking sound' is heard.
Alarm not sounding or light not activating.	Alarm is turned off or volume is set to 0 (for Alarm 2 light only).	Press the alarm button once to turn it on (indicator light will illuminate). Adjust volume if necessary.
Display is too bright/dim.	Display brightness setting needs adjustment.	In clock mode, short press the snooze button to cycle through display brightness levels.
Lamp not responding to touch.	Incorrect touch gesture or power issue.	Ensure you are touching the lamp arm. Check if the device is properly powered.

7. SPECIFICATIONS

Feature	Detail
Model Name	AJ310
Brand	RETEYUNG
Product Dimensions	9.06 x 8.26 x 3.94 inches (230 x 215 x 100 mm)
Item Weight	14.1 ounces (399.98 Grams)
Material	Aluminum (Lamp Arm), Plastic (Base), Acrylonitrile Butadiene Styrene (Shade)
Power Source	Corded Electric
Voltage	12 Volts
Wattage	4 watts
Light Source Type	LED
Color Temperature	4000 Kelvin

Feature	Detail
Control Method	Touch (Lamp), Push Button (Clock/Alarm)
Special Features	Dimmable, Energy Efficient, Memory Function, Timer, Wireless Charging
UPC	778365240378

8. WARRANTY & SUPPORT

RETEYUNG products are manufactured with high-quality standards. For any product-related inquiries, technical support, or warranty claims, please contact RETEYUNG customer service through the retailer where the product was purchased or visit the official RETEYUNG brand store online.

Please retain your proof of purchase for warranty purposes.

For more information, visit the [RETEYUNG Store on Amazon](#).