

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [YQSAVIOR](#) /

› [YQSAVIOR Kids Tablet YQQ1K User Manual](#)

## YQSAVIOR YQQ1K

# YQSAVIOR Kids Tablet User Manual

Model: YQQ1K

## 1. INTRODUCTION

Welcome to the YQSAVIOR Kids Tablet user manual. This guide provides essential information to help you set up, operate, and maintain your new tablet. Designed specifically for children, this tablet offers a safe and engaging platform for learning and entertainment, featuring robust parental controls and a durable design.

Please read this manual thoroughly before using the device to ensure proper functionality and safety.

## 2. WHAT'S IN THE BOX

- YQSAVIOR Kids Tablet (Model YQQ1K)
- Charging Cable

## 3. PRODUCT OVERVIEW

The YQSAVIOR Kids Tablet is equipped with features designed for young users, including a durable shockproof case and an adjustable stand for comfortable viewing.



Figure 3.1: Front view of the YQSAVIOR Kids Tablet with its protective case.



Figure 3.2: The tablet's adjustable stand for hands-free viewing.

## Key Components:

- **7-inch IPS HD Display:** Provides clear and bright visuals (1024x600 resolution).
- **Protective Silicone Case:** Designed to absorb shocks and prevent damage from drops.

- **Adjustable Stand:** Integrated into the case for convenient viewing angles.
- **Dual Cameras:** Front 2.0MP and Rear 5.0MP for photos and video calls.
- **3.5mm Headphone Jack:** For private listening.
- **Micro SD Card Slot:** Expandable storage up to 512GB.

## 4. SETUP

---

### 4.1 Initial Charging

Before first use, fully charge the tablet using the provided charging cable and a compatible power adapter (not included). The charging indicator will show progress.

### 4.2 Powering On/Off

- **To Power On:** Press and hold the Power button until the screen lights up.
- **To Power Off:** Press and hold the Power button, then select 'Power off' from the options that appear on the screen.

### 4.3 Initial Setup Wizard

Upon first power-on, the tablet will guide you through an initial setup process. This includes selecting your language, connecting to a Wi-Fi network, and setting up a Google account. A Google account is required to access the Google Play Store and other Google services.

### 4.4 Inserting a Micro SD Card

To expand storage, locate the Micro SD card slot on the side of the tablet. Gently insert a Micro SD card (up to 512GB) until it clicks into place. The tablet will recognize the new storage.

## 5. OPERATING INSTRUCTIONS

---

### 5.1 Parental Controls

The YQSAVIOR Kids Tablet features robust parental control options to ensure a safe digital environment for children. These controls allow you to manage screen time, filter content, and control app access.



Figure 5.1: Overview of parental control features.

Access the parental control settings through the dedicated app or system settings to:

- Set daily time limits for tablet usage.

- Approve or block specific applications.
- Filter websites and online content.
- Monitor activity logs.

## 5.2 App Management

The tablet comes with pre-installed educational and entertainment apps. You can download additional applications from the Google Play Store, thanks to its GMS certification.



Figure 5.2: The tablet's 'All Apps' screen.

## 5.3 Media Playback

The tablet supports various media formats and is compatible with streaming services like Netflix due to Widevine L1 support. The 1024x600 IPS HD display ensures a clear visual experience for videos and games.

Your browser does not support the video tag.

Video 5.3: An animated video showcasing the YQSAVIOR Kids Tablet's design, features like the protective case, adjustable stand, and dual cameras, along with its quad-core processor and various color options.

## 6. MAINTENANCE

## 6.1 Cleaning

Use a soft, lint-free cloth to clean the screen and the tablet's body. For stubborn smudges, slightly dampen the cloth with water. Avoid using harsh chemicals or abrasive materials.

## 6.2 Battery Care

- Avoid exposing the tablet to extreme temperatures (hot or cold).
- Do not leave the tablet charging for extended periods after it is fully charged.
- For long-term storage, charge the battery to about 50% and power off the device.

## 6.3 Software Updates

Periodically check for system updates in the tablet's settings to ensure optimal performance and access to the latest features and security patches.

# 7. TROUBLESHOOTING

## Common Issues and Solutions:

- **Tablet not turning on:** Ensure the tablet is charged. Connect it to a power source and try again.
- **Slow performance:** Close unused applications, clear app caches, or restart the tablet.
- **Wi-Fi connection issues:** Check if Wi-Fi is enabled, restart your router, or forget and reconnect to the network.
- **Apps crashing:** Ensure apps are updated. Try clearing the app's cache or reinstalling it.
- **Battery drains quickly:** Reduce screen brightness, close background apps, or disable unnecessary features like Bluetooth/GPS when not in use.

If issues persist, consider performing a factory reset (this will erase all data, so back up important files first) or contact customer support.

# 8. SPECIFICATIONS

Feature	Specification
Model Name	YQQ1K
Operating System	Android 12
Screen Size	7 Inches
Screen Resolution	1024x600 Pixels (IPS HD)
RAM	4GB (2GB+2GB)
Internal Storage (ROM)	32GB
Expandable Storage	Micro SD up to 512GB
Rear Camera	5 MP
Front Camera	2 MP

Wireless Type	802.11n (Wi-Fi)
Connectivity	Bluetooth
Battery	1 Lithium Ion (included)
Item Weight	1.21 pounds
Product Dimensions	7 x 0.3 x 3 inches

## 9. WARRANTY AND SUPPORT

---

For warranty information and customer support, please refer to the documentation included with your purchase or visit the official YQSAVIOR store on Amazon. You can find more information and contact details at:

[YQSAVIOR Amazon Store](#).