UGREEN W706

UGREEN Qi2 15W MagFlow Wireless Charger (Model W706) Instruction Manual

2-in-1 MagSafe Fast Charging Station for iPhone and AirPods

Introduction

This manual provides detailed instructions for the setup, operation, and maintenance of your UGREEN Qi2 15W MagFlow Wireless Charger, Model W706. Please read this manual thoroughly before using the product to ensure proper function and safety.

Package Contents

Verify that all items are present in the package:

- 1x UGREEN Qi2 15W MagFlow Wireless Charger (Model W706)
- 1x 3.3 ft (1 meter) USB-C to USB-C Charging Cable
- 1x Instruction Manual

Note: A USB-C wall adapter is not included and must be purchased separately. For optimal performance, a charger above 30W is recommended.



Image: Contents of the UGREEN Qi2 15W MagFlow Wireless Charger package.

Setup Instructions

1. **Connect the Charger:** Insert one end of the provided USB-C charging cable into the USB-C port on the UGREEN MagFlow Wireless Charger.
2. **Connect to Power Adapter:** Insert the other end of the USB-C cable into a compatible USB-C power adapter (not included). For optimal 15W fast charging, a power adapter with an output of 30W or higher is recommended.
3. **Power On:** Plug the power adapter into a wall outlet. The charger is now ready for use.



Image: Recommended input power for charging iPhone and AirPods.

Operating Instructions

Charging an iPhone

The UGREEN MagFlow Wireless Charger supports 15W fast charging for compatible iPhone models. Ensure your iPhone is running the required iOS version for 15W charging:

- For iPhone 13-15 series models, iOS 17.2 or higher is required.
- For iPhone 12 series models, iOS 17.4 or higher is required.

1. **Position the Charger:** Unfold the charger to your desired viewing angle (0-70 degrees). The magnetic charging pad will be elevated.
2. **Place iPhone:** Align your MagSafe-compatible iPhone (iPhone 12 series or newer) onto the magnetic charging pad. The magnets will secure the phone in place.
3. **Charging Confirmation:** A charging animation will appear on your iPhone screen, indicating that charging has begun.

Note: For optimal magnetic attachment and charging efficiency, it is recommended to use a MagSafe-compatible case or no case at all.



Image: iPhone 15W fast charging requirements and visual.



Image: Qi2 Magnetic Technology and case compatibility.

Charging AirPods

The charging base provides 5W wireless charging for compatible AirPods models.

1. **Place AirPods:** Place your AirPods (AirPods 2, AirPods 3rd Gen, AirPods Pro 2nd Gen, AirPods Pro) charging case onto the flat charging area at the base of the stand.
2. **Charging Confirmation:** The LED indicator on the charger will illuminate blue when AirPods are charging.

Note: This charger is not compatible with AirPods model A1602 (released in 2017) and model A2897 (released in 2022).



Image: Simultaneous charging of iPhone and AirPods.

LED Indicator Status

Working Status	LED Status
AirPods only / iPhone & AirPods charge at the same time	Blue light
iPhone only	Light off



Image: LED indicator guide for charging status.

Maintenance

- **Cleaning:** Disconnect the charger from the power source before cleaning. Use a soft, dry cloth to wipe the surface of the charger. Do not use liquid cleaners or aerosols.
- **Storage:** When not in use, store the charger in a cool, dry place away from direct sunlight and extreme temperatures. The foldable design allows for compact storage.
- **Handling:** Avoid dropping or subjecting the charger to strong impacts.

Troubleshooting

Issue: Device is not charging.

- Ensure the charger is properly connected to a working power outlet and a compatible USB-C power adapter (30W or higher recommended).
- Verify that your device is correctly aligned on the charging pad (for iPhone) or base (for AirPods).
- Check if your iPhone's iOS version meets the requirements for 15W fast charging (iOS 17.2+ for 13-15 series, iOS 17.4+ for 12 series).
- Remove any non-MagSafe compatible cases from your iPhone.
- Ensure your AirPods model is compatible with the charger.

Issue: Charging is slow.

- Confirm that you are using a power adapter with an output of 30W or higher. Lower wattage adapters may result in slower charging speeds.
- Ensure your iPhone's iOS version is up to date as specified for 15W charging.
- Check for any foreign objects between the device and the charging surface.

Issue: iPhone is not magnetically attaching securely.

- Ensure your iPhone is a MagSafe-compatible model (iPhone 12 series or newer).
- If using a case, ensure it is a MagSafe-compatible magnetic case. Non-magnetic cases may interfere with the magnetic connection.

Specifications

Model Number	W706
Brand	UGREEN
Product Dimensions	4.57 x 2.6 x 0.94 inches (Folded)
Item Weight	11.6 ounces
Input Voltage	12 Volts
Output Wattage	15W (iPhone), 5W (AirPods)
Connector Type	USB Type C
Special Features	Fast Charging, Foldable, Lightweight Design, Qi2 Certified
Color	Grey
Compatible iPhone Models	iPhone 17, 16, 15, 14, 13, 12 Series (including mini, Plus, Pro, Pro Max variants, with MagSafe cases)

Compatible AirPods Models	AirPods 2, AirPods 3rd Gen, AirPods Pro 2nd Gen, AirPods Pro (Excludes AirPods model A1602 and A2897)




Image: UGREEN MagFlow Wireless Charger Series comparison.

Warranty Information

UGREEN products typically come with a standard manufacturer's warranty. For specific warranty terms and conditions, please refer to the warranty card included in your product packaging or visit the official UGREEN website. Keep your purchase receipt as proof of purchase for warranty claims.

Customer Support

If you encounter any issues or have questions regarding your UGREEN Qi2 15W MagFlow Wireless Charger, please contact UGREEN customer support through their official website or the contact information provided in your product packaging.
For more information, visit the UGREEN Store on Amazon.

© 2025 UGREEN. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question