

Dreamaker B0CWV4PYPL

Dreamaker Electric Heated Throw Blanket User Manual

Model: B0CWV4PYPL

IMPORTANT SAFETY INFORMATION

Please read all instructions carefully before using your Dreamaker Electric Heated Throw Blanket. Retain this manual for future reference.

- Do not use if wet.
- Ensure the blanket is spread flat and not folded or bunched during operation to prevent overheating.
- Do not insert pins or other sharp objects into the blanket.
- Keep the controller away from water and moisture.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.
- The blanket features built-in overheat protection for your safety.
- Always disconnect the power cord from the outlet before cleaning or storing.

Safe & Energy Efficient


3 Hour Auto-Off Function

Overheat Protection



Image: The Dreamaker Electric Heated Throw Blanket is designed with high safety standards, including overheat protection, and meets Australian safety standards, as indicated by the SAA Approvals logo.

Safety Certified Design



TESTED TO
AU/NZ SAFETY
STANDARDS

Image: Detailed diagram illustrating the multi-layered safety design of the heating element, featuring double protection insulation and a temperature sensing wire to prevent overheating.

PRODUCT OVERVIEW

The Dreamaker Double-Sided Coral Fleece Electric Heated Throw Blanket provides luxurious warmth and comfort. Its soft coral fleece material offers a gentle, velvety texture, perfect for use on your bed, lounge, or as a standalone throw.

- Luxurious Double-Sided Coral Fleece:** Enjoy the soft, dense, and supple finish on both sides.
- User-Friendly Controller:** Features an LED display and simple buttons for easy operation.
- 9 Heat Settings:** Customize your warmth from a fast heat setting (indicated by 'H') to 8 adjustable levels.
- Overheat Protection:** Built-in safety features to prevent accidental overheating.
- 3-Hour Auto-Off Function:** Automatically turns off after three hours for safety and energy saving.
- Extra Long Cord:** A 2.3m cord provides flexibility in placement.
- Machine Washable:** Detachable controller allows for easy and safe cleaning.
- Energy Saving:** The double-layered coral fleece retains heat for longer.



Image: The Dreamaker Electric Heated Throw Blanket, shown rolled up, highlighting its soft coral fleece texture and the attached detachable controller.

Double the *Style*

Double sided - plush fleece on each side for warmth.




Image: The double-sided plush fleece blanket draped over a sofa, showcasing its aesthetic appeal and readiness for use in a home environment.

Plush Meets Lush

Super soft coral fleece

Image: A close-up of the super soft coral fleece, illustrating the plush and luxurious texture of the blanket material.

The Science of Warmth



200gsm
Coral fleece
for softness

Fast heating
insulated wires
warms evenly

200gsm
Coral fleece
for style

Image: An illustration detailing the "Science of Warmth" with layers of 200gsm coral fleece and insulated wires designed for fast and even heat distribution.

SETUP

- Unpack:** Carefully remove the heated throw blanket from its packaging.
- Inspect:** Before first use, inspect the blanket and controller for any signs of damage. Do not use if damaged.
- Connect Controller:** Ensure the detachable controller is securely plugged into the blanket's connector.
- Position:** Lay the blanket flat on a bed, sofa, or other desired surface. Ensure there are no folds, creases, or bunched areas that could trap heat.
- Plug In:** Insert the power plug into a suitable electrical outlet.

OPERATING INSTRUCTIONS

The Dreamaker Electric Heated Throw Blanket features a user-friendly controller with 9 heat settings.



Easy CONTROL

Extra long 2.3m cord

LED Display

Hold for 5 secs to
turn ON/OFF

1-8 Heat Settings
+ Fast Heat Mode

Image: The easy-to-use controller, featuring an LED display, ON/OFF button, and TEMP button for adjusting heat settings. The extra-long 2.3m cord is also visible.

9 Heat Settings

Customise your warmth



Image: A user demonstrating the comfortable use of the blanket and controller, highlighting the ease of customizing warmth with 9 heat settings.

1. **Turning On:** Press and hold the "ON/OFF" button for approximately 5 seconds. The LED display will illuminate, typically starting on the fast heat setting (indicated by "H").
2. **Adjusting Heat Settings:** Press the "TEMP" button to cycle through the heat settings from 1 to 8.
 - "H" (Fast Heat): Provides rapid warming.
 - "1-8": Gradual heat levels, with 8 being the warmest.Select your desired warmth level.
3. **Auto-Off Function:** The blanket is equipped with a 3-hour auto-off function for safety and energy conservation. After approximately 3 hours of continuous operation, the blanket will automatically turn off. To resume heating, simply turn the blanket off and then on again.
4. **Turning Off:** Press and hold the "ON/OFF" button for approximately 5 seconds until the LED display turns off. Unplug the blanket from the power outlet when not in use.

MAINTENANCE AND CARE

Proper care will extend the life of your Dreamaker Electric Heated Throw Blanket. Always follow these instructions carefully.

Machine Washable

Remove controller before washing.



Image: The heated blanket being prepared for washing, demonstrating that it is machine washable after detaching the controller.

Cleaning Instructions:

- Disconnect Power:** Ensure the blanket is unplugged from the wall outlet.
- Detach Controller:** Carefully detach the controller from the blanket. The controller is not washable.
- Washing:**
 - **Machine Wash:** Wash with like colors on a gentle cycle in cold water.
 - **Hand Wash:** For best results, hand wash in cold water.
- Drying:**
 - Line dry in shade.

- Do not spin/tumble dry.
- Do not dry clean or iron.

5. **Reassembly:** Ensure the blanket is completely dry before reattaching the controller and plugging it back into power.

Storage:

When not in use, store the blanket in a cool, dry place. Avoid placing heavy objects on top of the blanket during storage, as this may damage the internal heating elements.

TROUBLESHOOTING

If you experience issues with your Dreamaker Electric Heated Throw Blanket, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Blanket does not heat up.	Not plugged in correctly. Controller not connected securely. Power outlet issue. Overheat protection activated. Internal malfunction.	Ensure power cord is fully inserted into the outlet. Check that the controller is firmly connected to the blanket. Test the outlet with another appliance. Turn off the blanket, unplug it, wait 10-15 minutes, then plug back in and restart. If issues persist, contact customer support.
Blanket turns off unexpectedly.	3-hour auto-off function activated. Overheat protection activated due to folding/bunching.	This is normal operation. Turn the blanket off and then on again to resume heating. Ensure the blanket is spread flat. Turn off, unplug, wait, then restart.
Heat is uneven or localized.	Blanket is folded or bunched. Internal heating element issue.	Ensure the blanket is fully spread out and flat. If the problem persists after flattening, contact customer support.

If the problem cannot be resolved using the above steps, please contact Dreamaker customer support.

SPECIFICATIONS

Feature	Detail
Model	B0CWV4PYPL
Dimensions	200x180cm (for this specific variant)
Material	Double-Sided Coral Fleece
Color	Blue (for this specific variant)
Heat Settings	9 (Fast Heat 'H' + 8 adjustable levels)

Feature	Detail
Auto-Off Timer	3 Hours
Cord Length	2.3 meters (approx.)
Safety Features	Overheat Protection, SAA Approvals (Australian Safety Standards)
Care Instructions	Machine Wash (gentle cycle, cold water), Hand Wash. Detach controller before washing. Line dry in shade. Do not tumble dry, dry clean, or iron.
Item Weight	2.38 Kilograms

WARRANTY AND SUPPORT

Dreamaker products are manufactured to high-quality standards. For any warranty claims or technical support, please contact your retailer or Dreamaker customer service directly.

Please have your product model (B0CWV4PYPL) and purchase date available when contacting support.

For more information, visit the official Dreamaker store:[Dreamaker Store on Amazon AU](#)