

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Soundcore](#) /

› [Soundcore Life Note C Earbuds User Manual](#)

Soundcore A3943

Soundcore Life Note C True Wireless Headphones User Manual

Model: A3943 | Brand: Soundcore by Anker

Your guide to setting up, operating, and maintaining your Soundcore Life Note C Earbuds.



Image: Soundcore Life Note C True Wireless Earbuds, black, with their oval-shaped charging case. The earbuds are shown outside the case, highlighting their sleek design.

WHAT'S IN THE BOX

Ensure all components are present before proceeding with setup.

- Charging Case

- User Manual
- Charging Cable
- Ear Cushions (various sizes)

SETUP

1. Initial Charging

Before first use, fully charge the earbuds and the charging case.

- Place the earbuds into the charging case.
- Connect the charging case to a power source using the provided USB-C cable. The LED indicators on the case will illuminate to show charging status.
- A full charge typically takes approximately 2 hours for the case and earbuds.



Image: Soundcore Life Note C Earbuds placed inside their open charging case, showing the charging contacts and the LED indicators on the front of the case.

2. Pairing with Your Device

The earbuds will automatically enter pairing mode when removed from the charging case.

1. Open the charging case and remove both earbuds.
2. On your device (smartphone, tablet, etc.), enable Bluetooth.
3. Search for "Soundcore Life Note C" in the list of available Bluetooth devices and select it to connect.
4. Once connected, you will hear an audible confirmation, and the LED indicators on the earbuds will turn off.

Note: If pairing fails, place the earbuds back into the case, close the lid, and then reopen it to re-enter pairing mode. For single earbud use, simply remove one earbud from the case.

3. Wearing the Earbuds

For optimal sound quality and secure fit, choose the correct size ear tips and wear the earbuds correctly.

- Select the ear tips that provide the best seal and comfort. Different sizes are included.
- Insert the earbuds into your ear canal and gently twist them to secure their position.



Image: Soundcore Life Note C Earbuds, one removed from the charging case and the other still inside, illustrating the compact design and how they fit into the case.

OPERATING YOUR EARBUDS

The Soundcore Life Note C earbuds feature intuitive touch controls for various functions.

Power On/Off

- **Power On:** Open the charging case, and the earbuds will automatically power on.
- **Power Off:** Place the earbuds back into the charging case and close the lid. They will automatically power off and begin charging.

Music Controls

Function	Action
Play/Pause	Tap the touch control area on either earbud once.
Next Track	Double-tap the touch control area on the right earbud.
Previous Track	Double-tap the touch control area on the left earbud.

Call Controls

Function	Action
Answer/End Call	Tap the touch control area on either earbud once.
Reject Call	Press and hold the touch control area on either earbud for 2 seconds.

Voice Assistant

- **Activate Voice Assistant:** Triple-tap the touch control area on either earbud.

Water Resistance

The Soundcore Life Note C earbuds are water-resistant. This means they are protected against sweat and light splashes, making them suitable for workouts and outdoor activities. However, they are not designed for swimming or submersion in water.

MAINTENANCE

Proper maintenance ensures the longevity and optimal performance of your earbuds.

- **Cleaning:** Regularly clean the earbuds and charging contacts with a dry, soft, lint-free cloth. Do not use harsh chemicals or abrasive materials.
- **Ear Tips:** Remove and clean the ear tips with water and mild soap if necessary. Ensure they are completely dry before reattaching.
- **Storage:** When not in use, always store the earbuds in their charging case to protect them and keep them charged.
- **Battery Care:** To preserve battery life, avoid fully discharging the earbuds and charging case frequently. Charge them regularly, even if not in constant use.

TROUBLESHOOTING

If you encounter issues with your Soundcore Life Note C earbuds, try the following solutions:

- **Earbuds not pairing:**
 - Ensure both earbuds are fully charged.
 - Place both earbuds back into the charging case, close the lid, wait 5 seconds, then open the lid and remove them again.
 - On your device, forget "Soundcore Life Note C" from your Bluetooth settings and try pairing again.
- **Only one earbud playing sound:**
 - Ensure both earbuds are charged.
 - Place both earbuds back into the charging case, close the lid, and then reopen it.
 - Perform a factory reset (refer to the manufacturer's official support for specific reset instructions if needed, as this model might not have a public reset procedure).
- **Earbuds not charging:**
 - Ensure the charging cable is securely connected to both the case and the power source.
 - Clean the charging contacts on both the earbuds and inside the case with a dry cotton swab.

- Try a different charging cable and power adapter.

- **Poor sound quality:**

- Ensure the ear tips provide a good seal in your ear canal. Try different sizes.
- Clean any debris from the earbud nozzles.
- Move closer to your connected device to avoid Bluetooth interference.

SPECIFICATIONS

Feature	Detail
Model Name	A3943
Connectivity Technology	Wireless (Bluetooth 5.0)
Ear Placement	In Ear
Water Resistance Level	Water Resistant
Frequency Range	20 Hz - 20,000 Hz
Control Type	Media Control, Touch or Voice Control
Special Features	Fast Charging, Built-in Microphone, Sweatproof
Material	Plastic, Thermoplastic Elastomer (TPE)
Item Weight	3.84 ounces
Manufacturer	Anker

50%
MORE BASS



Image: A close-up of an earbud speaker driver with a graphic overlay stating "50% MORE BASS", highlighting the audio capabilities of the Soundcore Life Note C earbuds.

WARRANTY AND SUPPORT

For warranty information and technical support, please refer to the official Soundcore by Anker website or contact their customer service directly. Keep your proof of purchase for warranty claims.

Official Soundcore Support: <https://us.soundcore.com/pages/contact-us>

© 2024 Soundcore by Anker. All rights reserved.

This manual is for informational purposes only. Specifications are subject to change without notice.