

[Manuals.plus](#) /

› [Select Sound](#) /

› Select Sound Beatmix TWS Wireless Earbuds User Manual

Select Sound DW-02

Select Sound Beatmix TWS Wireless Earbuds User Manual

Model: DW-02

Brand: Select Sound

INTRODUCTION

Thank you for choosing the Select Sound Beatmix TWS Wireless Earbuds. These earbuds are designed to provide a superior audio experience with advanced technology, comfort, and convenience. Enjoy true wireless freedom with stable Bluetooth connectivity, clear sound, and intuitive touch controls. This manual will guide you through the setup, operation, and maintenance of your new earbuds.



Image: The Select Sound Beatmix TWS Wireless Earbuds, black, resting inside their matching black charging case. The earbuds are visible, showcasing their in-ear design and sleek appearance.

PACKAGE CONTENTS

Before you begin, please ensure all items are present in the package:

- Select Sound Beatmix TWS Wireless Earbuds (Left and Right)
- Charging Case
- USB Charging Cable
- User Manual (this document)

SETUP

1. Charging the Earbuds and Case

For first-time use, fully charge the earbuds and the charging case. The charging case provides multiple recharges for the

earbuds, extending their usage time.

1. Place the earbuds into the charging case, ensuring they are correctly seated in their respective slots.
2. Connect the USB charging cable to the charging port on the case and the other end to a USB power source (e.g., computer, wall adapter).
3. The indicator light on the charging case will show the charging status. Once fully charged, the light will change or turn off.

A full charge provides approximately 5 hours of playback time for the earbuds. The charging case has capacity for 4 recharges.



Image: Top view of the black charging case for the Select Sound Beatmix TWS earbuds, showing the lid and the charging indicator light.

2. Bluetooth Pairing

Pair your earbuds with your device (smartphone, tablet, laptop) to begin listening.

1. Ensure the earbuds are charged and inside the charging case.
2. Open the charging case lid. The earbuds will automatically enter pairing mode, indicated by a flashing light on the earbuds.
3. On your device, go to Bluetooth settings and turn Bluetooth on.
4. Search for available devices. You should see "Beatmix" or "Select Sound Beatmix" in the list.
5. Select "Beatmix" to connect. Once connected, the earbud indicator lights will stop flashing.
6. If prompted for a passcode, enter "0000" (four zeros).

The earbuds will automatically reconnect to the last paired device when taken out of the case, if Bluetooth is enabled on

the device.

OPERATING INSTRUCTIONS

Wearing the Earbuds

The ergonomic in-ear design ensures a comfortable and secure fit. Gently insert each earbud into your ear canal and rotate slightly until it feels snug and stable. This provides optimal sound quality and passive noise isolation.



Image: A woman wearing the black Select Sound Beatmix TWS Wireless Earbuds, demonstrating their comfortable and discreet fit during outdoor use.

Touch Controls

The Beatmix earbuds feature intuitive touch controls on each earbud for easy management of music and calls.



Image: A close-up view of the Select Sound Beatmix TWS earbuds, highlighting the touch-sensitive area on the side of each earbud, indicated by a fingerprint icon.

Action	Control
Play/Pause Music	Single tap on either earbud
Next Track	Double tap on the Right earbud
Previous Track	Double tap on the Left earbud
Answer/End Call	Single tap on either earbud
Reject Call	Press and hold either earbud for 2 seconds
Activate Voice Assistant	Triple tap on either earbud

MAINTENANCE

Proper care will extend the life of your earbuds.

- **Cleaning:** Regularly clean the earbuds, especially the ear tips and charging contacts, with a soft, dry, lint-free cloth. Do not use harsh chemicals or abrasive materials.
- **Storage:** When not in use, store the earbuds in their charging case to protect them from dust and damage.
- **Battery Care:** Avoid fully discharging the battery frequently. Charge the earbuds and case regularly, even if not in constant use, to maintain battery health.
- **Avoid Water:** These earbuds are not waterproof. Avoid exposure to water, moisture, or extreme temperatures.

TROUBLESHOOTING

If you encounter any issues, try the following solutions:

Problem	Solution
Earbuds not pairing with device	◦ Ensure earbuds are charged and out of the case. ◦ Turn off and on Bluetooth on your device. ◦ Forget "Beatmix" from your device's Bluetooth list and try pairing again. ◦ Ensure earbuds are within 10 meters of your device.
No sound from earbuds	◦ Check the volume level on your device. ◦ Ensure earbuds are properly connected to your device. ◦ Try playing different audio. ◦ Recharge the earbuds.
Earbuds not charging	◦ Ensure the charging cable is securely connected to both the case and the power source. ◦ Check if the charging contacts on the earbuds and inside the case are clean and free of debris. ◦ Try a different USB cable or power adapter.
Connection drops frequently	◦ Ensure there are no major obstructions between the earbuds and your device. ◦ Stay within the 10-meter Bluetooth range. ◦ Avoid strong electromagnetic interference.

SPECIFICATIONS

Detailed technical specifications for your Select Sound Beatmix TWS Wireless Earbuds:

Feature	Detail
Model Name	Beatmix
Model Number	DW-02
Connectivity Technology	Bluetooth, Wireless

Feature	Detail
Wireless Communication Technology	Bluetooth
Bluetooth Range	Up to 10 meters (33 feet)
Included Components	Charging Case
Control Type	Touch Control
Ear Placement	In-Ear
Form Factor	In-Ear
Impedance	32 Ohm
Noise Control	None (Passive noise isolation from in-ear design)
Average Battery Life (Earbuds)	5 Hours per charge
Charging Case Capacity	Provides capacity for 4 recharges
Special Features	Lightweight, Hands-Free Function
Package Dimensions	17.1 x 10.5 x 3.7 cm; 150 g



Image: The black charging case for the Select Sound Beatmix TWS earbuds, with overlaid measurements indicating its dimensions: 5.7 cm width, 4.4 cm height, and 2.2 cm depth.

WARRANTY AND SUPPORT

While specific warranty details are not provided in this manual, please retain your proof of purchase for any warranty claims. For product support, technical assistance, or further inquiries, please visit the official Select Sound brand store or contact their customer service.

You can visit the [Select Sound Store on Amazon](#) for more information and support.