

Umarex 2251391

Umarex UX Emerge .22 Wood Air Rifle

Model: 2251391 - Instruction Manual

1. IMPORTANT SAFETY INFORMATION

WARNING: This air rifle is not a toy. Misuse may cause serious injury or death. Read this manual completely before use.

- Always treat every air rifle as if it were loaded.
- Keep the muzzle pointed in a safe direction at all times.
- Keep your finger off the trigger until you are ready to shoot.
- Be sure of your target and what is beyond it.
- Always wear appropriate eye protection when handling or shooting an air rifle.
- Store the air rifle unloaded and separate from ammunition, in a secure location inaccessible to children and unauthorized users.
- Never shoot at hard surfaces or water, as pellets can ricochet.
- Do not alter or modify the air rifle.

2. PRODUCT OVERVIEW

The Umarex UX Emerge .22 Wood (Model 2251391) is a .22 caliber multi-shot break barrel air rifle designed for recreational shooting. It features a durable wood stock, a multi-shot auto-indexing magazine system, and comes equipped with a 4x32 scope for enhanced accuracy.



Image: The Umarex UX Emerge .22 Wood air rifle, showcasing its full profile with the mounted 4x32 scope and classic wood stock.

Key Features:

- .22 Caliber Pellet
- Multi-Shot Break Barrel Action
- 12-Shot Auto-Indexing Magazine System
- Included 4x32 Scope
- Wood Stock

3. SETUP AND ASSEMBLY

3.1 Unpacking

Carefully remove all components from the packaging. Verify that all parts are present: air rifle, 4x32 scope, scope rings, and instruction manual. Inspect the air rifle for any signs of damage during shipping.

3.2 Scope Mounting

1. Attach the scope rings to the dovetail rail on top of the air rifle receiver. Ensure they are securely tightened.
2. Place the 4x32 scope into the rings. Adjust the scope's position for comfortable eye relief when shouldering the rifle.
3. Ensure the scope's reticle is level, then tighten the top halves of the scope rings evenly to secure the scope. Do not overtighten.



Image: A close-up view of the Umarex 4x32 scope, showing its branding and objective lens.



Image: Detail of the air rifle's trigger guard and the scope mounting rail, illustrating the attachment points for the scope.

3.3 Loading the Magazine

The UX Emerge features a 12-shot auto-indexing magazine. To load:

1. Remove the magazine from the breech area.
2. Insert .22 caliber pellets into each chamber of the magazine, ensuring the skirt of the pellet is flush with the magazine surface.
3. Reinsert the loaded magazine into the breech, ensuring it clicks securely into place.



Image: A detailed view of the 12-shot auto-indexing magazine, showing the pellet chambers.



Image: The breech area of the air rifle with the multi-shot magazine correctly inserted, ready for operation.

4. OPERATING INSTRUCTIONS

4.1 Cocking the Air Rifle

1. Ensure the safety is engaged.
2. Firmly grasp the barrel and strike it downwards near the muzzle to break the barrel open.
3. Continue to pull the barrel down and back until the internal spring mechanism cocks and locks into place. You will hear a distinct click.
4. Return the barrel to its original position, ensuring it locks securely. The auto-indexing magazine will rotate to the next pellet.

4.2 Firing the Air Rifle

1. With the air rifle cocked and loaded, ensure the muzzle is pointed in a safe direction.
2. Disengage the safety.
3. Align your target using the scope.
4. Place your finger on the trigger and apply steady pressure until the shot fires.
5. After firing, re-engage the safety immediately.

4.3 Safety Features

The Umarex UX Emerge .22 Wood is equipped with a manual safety mechanism. Always engage the safety when the air rifle is cocked and not ready to fire. Familiarize yourself with its operation before use.

5. MAINTENANCE AND CARE

5.1 Cleaning the Barrel

Regular cleaning of the barrel is essential for maintaining accuracy. Use a .22 caliber cleaning kit with appropriate cleaning pellets or a cleaning rod and patches. Follow the cleaning kit instructions.

5.2 General Care

- Wipe down the exterior of the air rifle with a clean, dry cloth after each use to remove moisture and debris.
- Apply a thin coat of silicone-based gun oil to metal surfaces to prevent rust. Avoid getting oil into the barrel or trigger mechanism.
- Inspect the stock for any cracks or damage.

5.3 Storage

Store the air rifle in a cool, dry place, unloaded and uncocked. Keep it in a gun case or cabinet to protect it from dust, moisture, and unauthorized access. Store pellets separately.

6. TROUBLESHOOTING

Problem	Possible Cause	Solution
Pellet not firing	Air rifle not cocked; no pellet in chamber; safety engaged.	Ensure rifle is fully cocked; check magazine for pellets; disengage safety.
Poor accuracy	Loose scope; dirty barrel; inconsistent pellets; improper shooting technique.	Check scope mounts; clean barrel; try different pellets; practice shooting fundamentals.
Barrel not locking	Not fully cocked; obstruction.	Ensure barrel is pulled down completely until it clicks; check for debris in the breech area.

7. SPECIFICATIONS

Feature	Detail
Model Name	UX Emerge .22 Wood
Model Number	2251391
Caliber	.22 (5.5mm)
Ammunition Type	Pellets
Magazine Capacity	12 Rounds
Action	Break Barrel

Feature	Detail
Included Scope	4x32
Weight	5 Pounds (approx. 2.27 kg)
UPC	723364513916



Image: The product packaging displaying the item number 2251391 and UPC 723364513916.

8. WARRANTY INFORMATION

Umarex products are typically covered by a manufacturer's warranty against defects in materials and workmanship. Specific warranty terms, duration, and registration requirements may vary. Please refer to the warranty card included with your product or visit the official Umarex USA website for detailed information.

9. CUSTOMER SUPPORT

For technical assistance, parts, or service inquiries regarding your Umarex UX Emerge .22 Wood air rifle, please contact Umarex USA customer support. Contact information can typically be found on the manufacturer's website or on the product packaging.

Umarex USA, Inc.
7700 Chad Colley Boulevard
Fort Smith, AR 72916
Website: UmarexUSA.info

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question