

[Manuals.plus](#) /

- › [Supreme Trimmer](#) /
- › Supreme Trimmer Vader 2-in-1 Cordless Clipper and Trimmer Kit User Manual

Supreme Trimmer Vader 2-in-1 Clipper & Trimmer Kit

Supreme Trimmer Vader 2-in-1 Cordless Clipper and Trimmer Kit

Model: Vader 2-in-1 Clipper & Trimmer Kit

Brand: Supreme Trimmer

PRODUCT OVERVIEW

The Supreme Trimmer Vader 2-in-1 Cordless Clipper and Trimmer Kit is designed for professional and home grooming. This kit includes both a powerful clipper and a precise trimmer, each equipped with Diamond-Like Carbon (DLC) coated blades for enhanced durability and performance. Both devices offer cordless operation and convenient charging options.



Image: The Supreme Trimmer Vader 2-in-1 Cordless Clipper and Trimmer Kit, highlighting its key features including a 3.5-hour battery, DLC blades, and an LED battery indicator.

KEY FEATURES

- **STC5098 Vader Clipper:** Offers 210 minutes of cordless run-time with USB charging (100-240V). Features a 7500 RPM motor and an LED display for battery status.
- **ST3778 Vader Trimmer:** Provides 210 minutes of continuous use on a single charge. Designed for portability and professional-grade trimming. Cord/Cordless operation with 220V compatibility.
- **DLC Coated Blades:** Both the clipper and trimmer are equipped with Diamond-Like Carbon (DLC) coated blades for precise cutting, reduced heat, and rust resistance.
- **Complete Barber Set:** Includes all necessary accessories and chargers for a full haircut experience.

DIAMOND LIKE CARBON BLADES



Image: A detailed view of the DLC coated blades on the Vader Trimmer, emphasizing their precision, anti-rust properties, and heat reduction capabilities.

WHAT'S IN THE BOX

Your Supreme Trimmer Vader 2-in-1 Kit includes:

- 1 x STC5098 Vader Clipper
- 1 x ST3778 Vader Trimmer
- 1 x Two-prong charger for Vader Clipper
- 1 x Charging stand for Vader Clipper
- 1 x Wall charger for Vader Clipper
- 1 x Type-C charger for Vader Trimmer
- 1 x Charging stand for Vader Trimmer
- 1 x Wall charger for Vader Trimmer
- Multiple guide combs for clipper



Image: The Vader Clipper and Vader Trimmer displayed alongside their complete set of charging accessories, including various chargers and charging stands.

SAFETY INFORMATION

Please read all instructions carefully before using the device. Keep this manual for future reference.

- Do not immerse the device in water or other liquids.
- Keep the device away from children.
- Ensure the device is fully charged before first use.
- Do not use the device if the blades are damaged, as this may cause injury.
- Only use the provided chargers and accessories.
- Unplug the device before cleaning.

SETUP AND CHARGING

Initial Charge

Before first use, fully charge both the Vader Clipper and Vader Trimmer. The LED indicator will show charging status.

- **Vader Clipper:** Connect the two-prong charger to the clipper and a suitable power outlet (100-240V). The LED display will indicate battery level.
- **Vader Trimmer:** Connect the Type-C charger to the trimmer and a suitable power outlet (220V). The LED indicator will show charging status.

A full charge provides approximately 210 minutes of cordless run-time for both devices.

Attaching Guide Combs

To attach a guide comb, align the comb with the blade and push firmly until it clicks into place. To remove, gently pull the comb away from the blade.



Image: The Vader Clipper and Trimmer resting on their charging stands, with a selection of guide combs visible, illustrating the complete grooming setup.

OPERATING INSTRUCTIONS

Using the Vader Clipper

The Vader Clipper is designed for general hair cutting and fading. Select the desired guide comb for your preferred hair length. Turn on the clipper using the power switch. Move the clipper against the direction of hair

growth for an even cut. The DLC blades ensure smooth operation and reduced heat.

Using the Vader Trimmer

The Vader Trimmer is ideal for detailing, outlining, and close shaving. Use it without a guide comb for precise lines and sharp edges. Turn on the trimmer and gently guide the blade along the desired areas. The DLC blades provide a clean and comfortable trim.

Your browser does not support the video tag.

Video: A barber demonstrates the precise use of the Vader Trimmer for detailing and creating clean lines on a client's hair.

Your browser does not support the video tag.

Video: A barber showcases the versatility of the Vader Clipper and a foil shaver for a complete haircut and clean finish.

MAINTENANCE

Cleaning the Blades

After each use, turn off the device and remove any attached guide combs. Use the provided cleaning brush to remove loose hairs from the blades. For a more thorough cleaning, you may carefully detach the blade set and rinse it under running water. Ensure the blade set is completely dry before reattaching.

Lubrication

Regularly oil the blades to maintain optimal performance and extend their lifespan. Apply a few drops of clipper oil (not included) to the blades after cleaning, then run the device for a few seconds to distribute the oil evenly.

Storage

Store the clipper and trimmer in a dry, cool place, away from direct sunlight and moisture. Ensure both devices are turned off before storage.



Image: A close-up view of the Vader Trimmer's DLC blade, held in hand, emphasizing its sharp and durable cutting surface.

TROUBLESHOOTING

- **Device not turning on:** Ensure the device is fully charged. Check if the power switch is in the ON position.
- **Poor cutting performance:** Clean the blades to remove any trapped hair. Lubricate the blades with clipper oil. Ensure the blades are properly aligned.
- **Device not charging:** Verify that the charger is correctly connected to both the device and the power outlet. Check if the power outlet is functional.

- **Excessive heat:** Ensure blades are clean and lubricated. If heat persists, discontinue use and contact customer support.

SPECIFICATIONS

Feature	Detail
Recommended Uses	Head, Neck
Color	Acid
Brand	Supreme Trimmer
Power Source	Battery Powered; Corded/Cordless
Material	Acrylonitrile Butadiene Styrene

WARRANTY AND SUPPORT

Our team is based in the USA and is available to answer all customer questions. We are happy to assist you between Monday and Friday, 8 AM to 3 PM PST.

Contact Information:

- Phone: +1 (818) 626-8065

For further assistance or warranty claims, please refer to your purchase documentation or contact us directly.