Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Irene House 9188

Irene House 9188 Dual Motor Lift Recliner Instruction Manual

Model: 9188

Product Overview

The Irene House 9188 is a medium-sized dual motor lift recliner designed for comfort and ease of use, particularly for elderly individuals or those with mobility challenges. It features independent control of the backrest and footrest, allowing for an infinite range of positions, including a full 180-degree lay-flat recline. Additional features include a four-point vibration massage system and lumbar heating for enhanced relaxation and therapeutic benefits. The chair is upholstered in durable faux leather and constructed with a sturdy metal frame and CARB P2 certified wood, supporting up to 300 lbs.



Figure 1: The Irene House 9188 Dual Motor Lift Recliner in black faux leather, showcasing its design and integrated remote control.

Setup and Assembly

The Irene House 9188 recliner is designed for quick and easy assembly, typically taking about 15 minutes. The chair is

shipped in two boxes, which may arrive separately. Ensure both boxes are received before beginning assembly.

Package Contents:

- Box 1: Chair base and arms.
- Box 2: Backrest and accessories. The accessory box is typically located at the bottom of the chair base.




Figure 2: The recliner is shipped in two separate boxes, which may arrive at different times.

Assembly Steps:

1. **Unpack Components:** Carefully remove all parts from the packaging.
2. **Attach Backrest:** Slide the backrest onto the chair base until it clicks securely into place.
3. **Attach Arms:** Identify the left side facing (LSF) and right side facing (RSF) arms. Attach them to the corresponding sides of the chair base. Ensure they fit correctly.
4. **Connect Power Cords:** All power connections are color-coded for easy identification. Match the colors to connect the motor, remote controls, and power adapter.
5. **Secure Wires:** Use the provided Velcro strips to secure any exposed wires beneath the chair. This enhances safety and prevents damage or compression of the wiring.



Figure 3: Secure exposed wires using Velcro straps to prevent damage and ensure a tidy appearance.

Operating Instructions

The Irene House 9188 recliner features a dual-motor system and multiple comfort functions controlled by two separate remotes.

Reclining and Lift Functions:

The main remote controls the dual motors, allowing independent adjustment of the backrest and footrest. This enables an infinite number of positions, including a full 180-degree lay-flat recline.

- **Recline Backrest:** Use the designated button on the main remote to recline the backrest backward.
- **Extend Footrest:** Use the designated button on the main remote to extend the footrest forward.
- **Lift Function:** To assist with standing, use the lift button on the main remote. The chair will gently tilt forward and lift, helping the user to a standing position.
- **Lay-Flat Position:** Continue to recline the backrest and extend the footrest until the chair reaches a full 180-degree flat position, ideal for sleeping or extended relaxation.



Figure 4: The dual motor system allows independent adjustment of the backrest and footrest for optimal positioning.



Figure 5: The chair can recline to a full 180-degree lay-flat position for maximum comfort.

Massage and Heating Functions:

A separate remote controls the massage and lumbar heating features. These functions are designed to provide relaxation and relief.

- **Massage:** The chair features a four-point vibration massage system in the backrest. You can select from 3 vibration intensities and 8 adjustable modes.
- **Lumbar Heating:** Activate the lumbar heating function to provide warmth to the lower back area.
- **Timer Settings:** Both massage and heat functions have adjustable timer settings and will automatically turn off after 15 minutes for user safety.



Figure 6: The massage and heating remote allows control over vibration intensity, modes, and lumbar heat.

Maintenance

Proper maintenance will ensure the longevity and continued performance of your Irene House 9188 recliner.

- **Cleaning:** The faux leather upholstery is easy to clean. Simply wipe clean with a damp cloth. Avoid harsh chemicals or abrasive cleaners, as these can damage the material.
- **Spills:** In case of spills, blot immediately with a clean, dry cloth. Do not rub.
- **General Care:** Regularly inspect all connections and moving parts to ensure they are secure and functioning correctly. Keep the chair away from direct sunlight and heat sources to prevent material degradation.

Troubleshooting

This section addresses common issues you might encounter with your recliner.

Problem	Possible Cause	Solution
Chair does not recline/lift.	Power cord disconnected; remote wiring issue; motor malfunction.	Ensure all power cords are securely connected and color-coded connections are matched. Check if the power outlet is functional. Inspect remote control wiring for any disconnections or damage. If issues persist, contact customer support.
Massage/Heat functions not working.	Separate remote issue; automatic shut-off activated.	Ensure the massage/heat remote is properly connected. Note that these functions automatically turn off after 15 minutes; reactivate if needed. Verify the remote's battery (if applicable, though typically wired).
Gap between seat and back when fully reclined.	Design characteristic; padding shift.	This can be a design characteristic. Consider using a small pillow for additional lumbar support if desired.
Footrest does not extend high enough.	Design characteristic.	The footrest extension is optimized for the lay-flat position. Its height in other reclined positions is part of the chair's design.

Specifications

Feature	Detail
Brand	Irene House
Model Name	9188
Color	Black Fauxleather
Product Dimensions (D x W x H)	38.5"D x 33"W x 42.5"H
Seat Depth	20.4 inches
Size	Medium
Special Features	Dual Motor, Infinite Position, Heat Massage, Side Pocket
Product Care Instructions	Wipe Clean
Recommended Uses	Reading, Sleeping
Fill Material	Sponge
Weight Capacity	300 lbs
Frame Material	Reinforced Metal Frame, CARB P2 Certified Solid Wood




Figure 7: Detailed dimensions of the Irene House 9188 recliner.

Warranty and Support

Irene House stands behind the quality of its products. Your 9188 recliner comes with a comprehensive warranty and dedicated customer support.

Warranty Information:

The Irene House 9188 recliner is backed by a**2-year warranty**. This warranty covers:

- Motor components
- Chair frame
- Electrical components

During the warranty period, in-home repair service may be provided without you having to leave your home.

Return Policy:

You are allowed to return or exchange the furniture within **30 days** of receiving it.

Contact Us:

For any questions, support, or warranty claims, please contact Irene House customer service:

- **Email:** service@irenehouse.com
- **Phone:** 800-622-8287

Alternatively, you can contact the seller through your Amazon account:

1. Login to your Amazon Account.
2. Choose "Your Orders".
3. Find the Order ID for your purchase.
4. Click "Contact Seller".



Figure 8: Irene House contact information and support details.

© 2024 Irene House. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CWZZY4JP

More documents and user manuals: **https://manuals.plus/**