



Manuals.plus /

› BESNOOW /

› BESNOOW I53 Wireless Earbuds Instruction Manual

## BESNOOW I53

# BESNOOW I53 Wireless Earbuds Instruction Manual

Model: I53

[Overview](#)   [Setup](#)   [Introduction](#)   [What's in the Box](#)   [Product](#)  
[Operating](#)   [Maintenance](#)   [Troubleshooting](#)   [Specifications](#)   [Warranty & Support](#)

## 1. INTRODUCTION

---

Thank you for choosing the BESNOOW I53 Wireless Earbuds. These earbuds are designed to provide a superior audio experience with advanced Bluetooth 5.3 technology, HiFi stereo sound, ENC noise cancellation, and IP7 waterproof rating. This manual will guide you through the setup, operation, and maintenance of your new earbuds to ensure optimal performance and longevity.



Image: The BESNOOW I53 Wireless Earbuds in their rose gold charging case, displaying the LED battery indicator.

## 2. WHAT'S IN THE BOX

---

Please check the package contents to ensure all items are present:

- 2 x BESNOOW in-Ear Bluetooth Earbuds (Left and Right)
- 1 x Fast Charging Case
- 1 x USB-C Charging Cable
- 3 x Pairs of Earplugs (S, M, L)

- 1 x Instruction Manual




Image: A visual representation of all items included in the BESNOOW I53 earbud package, including the earbuds, charging case, USB-C cable, and ear tips.

### 3. PRODUCT OVERVIEW

---

Familiarize yourself with the main components of your BESNOOW I53 Wireless Earbuds.

#### Earbuds

- **Touch Control Area:** Located on the outer surface of each earbud for various functions.
- **Microphone:** Integrated for calls and voice assistant.
- **Charging Contacts:** Located at the bottom of the earbud stem for charging in the case.
- **Ear Tip:** Replaceable silicone tips for comfortable fit and sound isolation.

#### Charging Case

- **LED Power Display:** Shows battery percentage of the case and individual earbud charge status.
- **USB-C Charging Port:** Located at the back or bottom for charging the case.
- **Earbud Charging Slots:** Magnetic slots inside the case to hold and charge the earbuds.





Image: A close-up of the BESNOOW I53 charging case, showing the USB-C charging port.

## 4.2 Pairing with Your Device

The earbuds feature a built-in hall effect switch for effortless pairing.

1. Open the charging case. The earbuds will automatically power on and enter pairing mode.
2. On your device (smartphone, tablet, computer), enable Bluetooth.
3. Search for "I53" in the list of available Bluetooth devices and select it to connect.
4. Once connected, the earbuds will automatically pair with the last used device when the case is opened.



Image: An illustration showing the BESNOOW I53 earbuds connecting to a smartphone via Bluetooth, with the device name 'I53' visible on the screen.

## 4.3 Wearing the Earbuds

For optimal sound quality and comfort, choose the correct ear tip size and ensure a secure fit.

1. Select the ear tips (S, M, L) that best fit your ear canal.
2. Gently insert each earbud into your ear canal.

3. Rotate the earbud slightly until it feels secure and comfortable, forming a good seal.



Image: A step-by-step diagram illustrating how to select ear tip size, insert the earbud into the ear canal, and adjust for a secure and comfortable fit.

## 5. OPERATING INSTRUCTIONS

The BESNOOW I53 earbuds feature intuitive touch controls for various functions.



Image: A visual guide detailing the touch control functions for the BESNOOW I53 earbuds, including playback, volume, calls, and voice assistant.

### 5.1 Music Playback

Action	Function
Single tap (L/R)	Play/Pause
Double tap (L)	Previous Song
Double tap (R)	Next Song
Tap and hold 1s (L)	Volume Down
Tap and hold 1s (R)	Volume Up

## 5.2 Phone Calls

Action	Function
Single tap (L/R)	Answer Call
Tap and hold 2s (L/R)	Reject Call / End Call

## 5.3 Voice Assistant

Action	Function
Triple tap (L/R)	Activate Voice Assistant (Siri, Google Assistant, etc.)

## 5.4 Power On/Off

Action	Function
Open charging case	Auto Power On
Place earbuds in case and close lid	Auto Power Off
Tap and hold 5s (L/R)	Manual Power On/Off

# 6. MAINTENANCE

---

## 6.1 Cleaning

Regular cleaning helps maintain sound quality and hygiene.

- Use a soft, dry, lint-free cloth to wipe the earbuds and charging case.
- For ear tips, remove them from the earbuds and clean with mild soap and water. Ensure they are completely dry before reattaching.
- Gently clean the charging contacts on the earbuds and inside the case with a dry cotton swab.
- Do not use abrasive cleaners, alcohol, or chemical solvents.

## 6.2 Storage

When not in use, store the earbuds in their charging case to protect them and keep them charged.

- Store in a cool, dry place away from direct sunlight and extreme temperatures.
- Avoid storing in dusty or dirty environments.

### 6.3 Waterproof Rating (IP7)

The earbuds are IP7 waterproof, meaning they are protected against immersion in water up to 1 meter for up to 30 minutes. They are resistant to sweat, light rain, and accidental splashes.

- Do not intentionally submerge the charging case in water, as it is not waterproof.
- Ensure earbuds are dry before placing them back into the charging case to prevent damage.



Image: The BESNOOW I53 earbuds and charging case shown with water droplets, illustrating their IP7 waterproof and dustproof capabilities against light rain, splashes, and sweat.

## 7. TROUBLESHOOTING

If you encounter any issues, please refer to the following common solutions:

Problem	Possible Solution
Earbuds not pairing/connecting	<ul style="list-style-type: none"> <li>◦ Ensure earbuds are charged.</li> <li>◦ Turn off Bluetooth on your device and turn it back on.</li> <li>◦ Forget "I53" from your device's Bluetooth list and re-pair.</li> <li>◦ Place earbuds back in the case, close the lid, wait 5 seconds, then open again.</li> </ul>
Only one earbud working	<ul style="list-style-type: none"> <li>◦ Ensure both earbuds are charged.</li> <li>◦ Place both earbuds back in the charging case, close the lid, and then open it again to reset the connection.</li> <li>◦ Clean the charging contacts on both earbuds and inside the case.</li> </ul>
Low volume or poor sound quality	<ul style="list-style-type: none"> <li>◦ Adjust the volume on both your device and the earbuds.</li> <li>◦ Ensure ear tips are clean and properly sealed in your ear canal.</li> <li>◦ Try different sized ear tips for a better fit.</li> <li>◦ Clean any debris from the earbud nozzles.</li> </ul>
Charging case not charging	<ul style="list-style-type: none"> <li>◦ Ensure the USB-C cable is securely connected to both the case and the power source.</li> <li>◦ Try a different USB-C cable or power adapter.</li> <li>◦ Check if the charging port on the case is free of debris.</li> </ul>
Touch controls not responding	<ul style="list-style-type: none"> <li>◦ Ensure your fingers are clean and dry when touching the control area.</li> <li>◦ Restart the earbuds by placing them in the case and taking them out.</li> </ul>

## 8. SPECIFICATIONS

---

Feature	Detail
Model Name	I53
Connectivity Technology	Wireless (Bluetooth)
Wireless Communication Technology	Bluetooth 5.3
Bluetooth Range	Up to 30 feet (10 meters)
Audio Driver Type	Dynamic Driver
Audio Driver Size	14.2 mm
Noise Control	ENC Noise Cancellation (for calls)
Battery Life (Earbuds)	Up to 8 hours (single charge)
Total Playtime (with Charging Case)	Up to 40 hours
Charging Time	Approx. 1.5 hours (earbuds & case)
Charging Port	USB-C
Water Resistance Level	IP7 Waterproof
Control Type	Touch Control
Compatible Devices	iOS, Android, and all Bluetooth-enabled devices
Item Weight	3.2 ounces
Manufacturer	BESNOOW

## 9. WARRANTY & SUPPORT

---

### 9.1 Warranty Information

Please refer to the product packaging or the official BESNOOW website for specific warranty details. Typically, products come with a limited warranty covering manufacturing defects.

### 9.2 Customer Support

If you have any questions, concerns, or require technical assistance, please contact BESNOOW customer support through the following channels:

- **Email:** Refer to the contact information provided on the product packaging or the official BESNOOW website.
- **Online Support:** Visit the [BESNOOW Store on Amazon](#) for FAQs and support resources.

When contacting support, please have your product model (I53) and purchase information ready.