Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

HOMCOM ES837-327V00AK0731

HOMCOM Oak Wooden Shoe Cabinet

Model: ES837-327V00AK0731
Brand: HOMCOM

Introduction

This manual provides detailed instructions for the assembly, operation, and maintenance of your HOMCOM Oak Wooden Shoe Cabinet. Please read this manual thoroughly before assembly and use to ensure proper function and safety. Keep this manual for future reference.

Safety Information

WARNING: To prevent serious injury, always follow these safety guidelines.

- For enhanced stability and safety, especially in households with children and pets, it is essential to secure the furniture to the wall using the provided anti-tip kit.
- Do not place heavy objects on the top shelves to prevent the furniture from tipping over.
- Keep the area around the furniture clean and free of obstacles to prevent injuries.
- Ensure all screws and fittings are securely tightened during assembly. Periodically check and re-tighten if necessary.
- Do not stand or climb on the cabinet.

Package Contents

Before beginning assembly, verify that all parts and hardware are present. Refer to the assembly diagram for a complete list of components.



Image: Overview of all components and hardware required for assembly.

Assembly Instructions

Follow these step-by-step instructions for assembling your shoe cabinet. It is recommended to assemble the unit on a soft, clean surface to prevent scratches.

Assembly Video Guide

Your browser does not support the video tag.

Video: Detailed assembly instructions for the shoe cabinet, demonstrating each step from unboxing to final setup. This video is provided by Electroactiva (Seller).

Step-by-Step Assembly

Refer to the diagrams below for visual guidance during assembly.



Image: Assembly diagram for connecting the base and side panels.



Image: Illustration of the anti-tip mechanism, showing how to secure the cabinet to the wall. This step is crucial for safety.

Operation

Your HOMCOM shoe cabinet is designed for practical and compact shoe storage, along with additional space for small items.

Product Overview Video

Your browser does not support the video tag.

Video: Overview of the HOMCOM shoe cabinet's features and functionality. This video is provided by Spanish Aosom, S.L. (EU) (Seller).

Shoe Storage

The cabinet features two tilt-out compartments, each with two levels. These compartments can hold up to 12 pairs of shoes (maximum EU size 44). The internal shelves are adjustable to accommodate different shoe sizes and types, including boots and high heels by removing the internal shelf.



Image: Interior view of the shoe cabinet, highlighting the two tilt-out compartments for shoe storage.



Image: Adjustable shelf positions for various shoe types.



Image: Removable shelf for storing boots and high heels.

Drawer Use

The two top drawers provide additional storage for small items such as keys, wallets, or decorative objects. The wide countertop can also be used for display or quick access items.



Image: Close-up of an open drawer, demonstrating storage for small items.



Image: Top surface of the cabinet, suitable for small items or decoration.

Maintenance

- **Cleaning:** Wipe the cabinet with a damp cloth. Avoid using harsh chemicals or abrasive cleaners, as these can damage the melamine wood finish.
- **Inspection:** Periodically check all screws and fittings to ensure they remain tight. Re-tighten if necessary to maintain stability.
- **Placement:** Avoid placing the cabinet in direct sunlight or near heat sources to prevent material degradation or discoloration.

Troubleshooting

Cabinet Instability

- **Issue:** The cabinet feels wobbly or unstable.
- **Solution:** Ensure all assembly screws are fully tightened. Verify that the anti-tip device is correctly installed

and secured to a solid wall. Check that the cabinet is placed on a level surface.

Drawers or Doors Not Operating Smoothly

- **Issue:** Drawers stick or tilt-out doors do not open/close easily.
- **Solution:** Check for any obstructions in the drawer slides or tilt mechanisms. Ensure all hardware related to the drawers and doors is correctly installed and tightened. Lightly lubricate moving parts if necessary.

Shoe Fit Issues

- **Issue:** Certain shoe sizes or types do not fit in the compartments.
- **Solution:** Adjust the internal shelves to a different height. For boots or high heels, remove the internal shelf completely to create more vertical space. Note that the maximum recommended shoe size is EU 44.

Specifications

Feature	Detail
Brand	HOMCOM
Model Number	ES837-327V00AK0731
Color	Oak
Material	Engineered Wood (Melamine)
Overall Dimensions (L x W x H)	80 cm x 30 cm x 91.5 cm
Max. Weight Capacity (Total)	60 kg
Max. Weight Capacity (Each Drawer/Level)	5 kg
Shoe Capacity	Up to 12 pairs (Max. EU size 44)
Features	Space-saving, Modern style, Robust structure, Large storage capacity, Practical, Anti-tip design
Assembly Required	Yes




Image: Detailed dimensions of the shoe cabinet.

Warranty and Support

For warranty information or technical support, please contact HOMCOM customer service. Refer to your purchase documentation for specific warranty terms and contact details.

Customer Service: For assistance, please visit the HOMCOM Store on Amazon or refer to the contact information provided with your product packaging.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CX471TVK

More documents and user manuals: **https://manuals.plus/**