

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [KODAK](#) /

› [KODAK Digital Photo Frame with WiFi, 9.7 inch 2048x1536 IPS 2K Touch Screen, 32GB Storage, Auto-Rotate Motion Sensor, Share Photos and Videos, Christmas Birthday Gifts for Women 978P Black](#)

KODAK 978P Black

KODAK Digital Photo Frame with WiFi

MODEL: 978P BLACK USER MANUAL

Introduction

This manual provides comprehensive instructions for setting up, operating, maintaining, and troubleshooting your KODAK Digital Photo Frame with WiFi. Designed for ease of use, this frame allows you to effortlessly share and display your cherished photos and videos.

Key features include a 9.7-inch 2K IPS touch screen, 32GB of built-in storage, automatic rotation, and seamless sharing via the KODAK app.



KODAK Advance Photo Frame 9.7 Inch
HDPF-978P

2K
1536*1048
RESOLUTION



The KODAK Digital Photo Frame, showcasing its display and connectivity with a smartphone.

Setup Guide

Follow these steps to set up your KODAK Digital Photo Frame:

1. **Unpack the Box:** Carefully remove all components from the packaging. Ensure you have the digital photo frame, AC adapter, stand, and data cable.
2. **Connect Power:** Plug the AC adapter into the power interface on the back of the frame and then into a wall outlet. The frame will power on automatically.
3. **Attach Stand:** Securely attach the included stand to the back of the frame for desktop placement.
4. **Initial Setup:** Follow the on-screen prompts to select your language, connect to a Wi-Fi network, and set the date and time.
5. **Download KODAK App:** For seamless photo and video sharing, download the official KODAK app on your smartphone or tablet. Search for "KODAK" in your device's app store.
6. **Pair Device:** Open the KODAK app and follow the instructions to pair it with your digital photo frame. This typically involves scanning a QR code displayed on the frame's screen.



What's in the Box?

1. An Exquisite Gift Box
2. A Digital Picture Frame
3. An AC Adapter
4. A Stand
5. A User Manual
6. Data Cable



What's included in the box: Digital Photo Frame, AC Adapter, Stand, User Manual, and Data Cable.

Operating Instructions

Sharing Photos and Videos

- **Via KODAK App:** Once paired, use the KODAK app on your smartphone to select and send photos and videos directly to your frame. The app allows for instant and wireless sharing.
- **Via SD Card:** Insert an SD card (up to 32GB, not included) into the SD card slot on the side of the frame. The frame will automatically detect and display media from the card.
- **Via USB Drive:** Connect a USB drive to the USB port on the side of the frame to display media.
- **Via Type-C Connection:** Connect the frame to a computer using a Type-C cable to export received pictures and videos.

Instant & Wireless Sharing

Share Your Picture And Video With KODAK App



Share your memories instantly and wirelessly using the KODAK app.

Auto-Rotate Function

The frame features an auto-rotate function that automatically adjusts the orientation of your pictures to display them correctly, whether the frame is placed horizontally or vertically. You can also mount the frame on a wall using the integrated wall hanging hole.

Auto-Rotate Function and Wall Mount

Automatically Adjust The Orientation of Your Photo To Display It Perfectly



Support Frame



Wall Hanging Hole



The frame supports auto-rotation and can be wall-mounted for flexible display options.

Multi-User Connection

Multiple users can connect to a single frame, allowing family and friends to share photos and videos from different locations. Each user can send media directly to the frame via the KODAK app.

Multi Users Connection

Built-in 32GB Storage & Expansion MicroSD card (up to 32GB)



Connect multiple users to share memories with your KODAK Digital Photo Frame.

Touch Screen Operation

Navigate the frame's intuitive interface using the touch screen. Swipe to browse photos, tap to select options, and pinch to zoom. The 9.7-inch IPS display provides a clear and vibrant viewing experience.

9.7"

IPS full-view
ultra-clear screen



Slideshow



Built-in 32GB memory



Alarm clock



touchscreens



2408*1536 2K



Video



Music



Calendar



Timer

The 9.7-inch IPS touch screen offers a clear display and access to multiple functions.

Maintenance

- **Cleaning the Screen:** Use a soft, lint-free cloth to gently wipe the screen. For stubborn smudges, slightly dampen the cloth with water or a screen-cleaning solution. Avoid harsh chemicals or abrasive materials.
- **Cleaning the Frame:** Wipe the frame's exterior with a dry, soft cloth.
- **Storage:** When not in use for extended periods, store the frame in a cool, dry place away from direct sunlight and extreme temperatures.
- **Software Updates:** Periodically check for software updates through the frame's settings menu to ensure optimal performance and access to new features.

Troubleshooting

Problem	Possible Cause / Solution
Frame does not power on.	Ensure the AC adapter is securely connected to the frame and a working power outlet. Try a different outlet.
Cannot connect to Wi-Fi.	Check your Wi-Fi password. Ensure the frame is within range of your router. Restart your router and the frame.
Photos/Videos not appearing.	Verify that media has been successfully uploaded via the KODAK app. If using an SD card or USB drive, ensure it is properly inserted and contains compatible file formats. Check storage space.
Screen is unresponsive.	Restart the frame by unplugging and re-plugging the power adapter. Ensure the screen is clean and free of debris.
Images are rotated incorrectly.	The frame has an auto-rotate function. Ensure the frame is placed on a stable, level surface. If issues persist, check settings for manual rotation options if available.

If you encounter issues not listed here, please refer to the Warranty & Support section for assistance.

Specifications

Feature	Detail
Model	978P Black
Screen Size	9.7 Inches
Resolution	2048*1536 UHD (2K)
Display Type	IPS Touch Screen
Internal Storage	32GB (supports over 10,000 photos)
External Storage	SD Card (up to 32GB), USB Drive
Connectivity	WiFi, Type-C
Product Dimensions	8.3 x 1.7 x 0.99 inches
Item Weight	2.55 pounds
Manufacturer	KODAK



The best gift choice

Surprise Your Loved ones With A Meaningful Gift Personalized With Their Favorite Photos or Videos
Feel Close With Them Anytime And Anywhere.



Detailed view of the frame's dimensions and available ports.

Warranty & Support

KODAK provides a **12-month warranty** for this digital photo frame, covering manufacturing defects and malfunctions under normal use. Additionally, lifetime friendly support is available to assist you with any questions or issues you may encounter.

For technical assistance, troubleshooting, or warranty claims, please contact KODAK customer support through the official KODAK website or the contact information provided in your product packaging. You can also visit the [KODAK Store on Amazon](#) for more information and resources.

Please have your product model number (978P Black) and purchase details ready when contacting support.

