

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [Yaheetech](#) /

› [Yaheetech Zero Gravity Chair Instruction Manual](#)

Yaheetech YTtv380002001

Yaheetech Zero Gravity Chair Instruction Manual

Model: YTtv380002001

PRODUCT OVERVIEW

The Yaheetech 29-inch Zero Gravity Chair is an adjustable, padded anti-gravity recliner designed for outdoor use. It features a foldable structure, a cup holder tray, a canopy shade, and a headrest, making it suitable for various outdoor activities such as beach trips, camping, and patio relaxation. This chair is engineered for comfort and durability, supporting up to 400 lbs.



Figure 1: The Yaheetech Zero Gravity Chair in Gray/Black, showcasing its overall design and features.

KEY FEATURES

- **Adaptive Reclining System:** Allows adjustment of the backrest angle for upright sitting or lying down. The 600x300D Oxford fabric with elastic straps conforms to the body for comfortable support.
- **Professional Outdoor Material:** Constructed from durable 600x300D Oxford cloth, known for its lightweight, high durability, and wear-resistance, ensuring long-term outdoor service.

- **Safe, Stable Construction:** Features a high-hardness, lightweight painted steel frame designed with a triangle structure, capable of supporting up to 182 kg (400 lb) for enhanced safety and stability.
- **Buckle & Strap for Carry Out:** Easily folds and secures with a locking buckle, and includes a strap for convenient shoulder carrying.
- **Sunscreening Cool Design:** Equipped with an adjustable sunshade, a breathable mesh backrest, and beech wood armrests to provide cool relaxation, especially on hot days. The sunshade angle can be adjusted to block direct sunlight.
- **Removable Cup Holder Tray:** A convenient side tray with cup holders and slots for a mobile phone or tablet keeps essentials within reach.
- **Removable Headrest:** Provides additional comfort and support for the head and neck.



Figure 2: Illustration of the chair's 3-way reclining application and premium material composition.

SAFETY INFORMATION


Always use the reclining mechanism carefully and ensure the chair is stable before use. Do not exceed the maximum weight capacity of 182 kg (400 lb). Ensure all locking mechanisms are engaged when adjusting the chair to a desired position.

SETUP

The Yaheetech Zero Gravity Chair comes pre-assembled and is ready to use directly out of the box. No complex assembly is required.

1. **Unfolding:** Carefully unfold the chair by pulling the frame apart until it fully extends.
2. **Securing:** Once unfolded, ensure the chair is stable on a flat surface.
3. **Attaching Accessories:** Attach the removable cup holder tray to the designated slot on the side armrest. Position the headrest pillow for optimal comfort.

ASSEMBLY-FREE READY TO USE



WHY CHOOSE US



Figure 3: Visual guide for the assembly-free setup of the chair, including unfolding and attaching the cup holder.

OPERATING INSTRUCTIONS

- **Reclining:** To recline, gently push back on the chair while lifting your feet. The chair will smoothly transition into a reclined position. To lock the position, locate the round-head locking pin on the back leg and insert it into the corresponding hole. To unlock, remove the pin.
- **Adjusting Sunshade:** The canopy shade can be adjusted flexibly to block direct sun exposure. Simply pivot the shade to your desired angle. When not in use, the sunshade can be folded back behind the chair.
- **Using Cup Holder Tray:** The removable tray provides two cup holders and slots for holding a mobile phone or tablet, keeping your items secure and accessible.

ADJUSTABLE SUNSHADE

Adjust the sunshade flexibly according to the angle of the sunlight to avoid direct sun exposure



ROUND-HEAD LOCKING PIN

In order to *keep the recliner stable*, please insert the round-head locking pin into the corresponding hole on the back leg after unfolding and adjusting the chair to the required angle



Figure 4: Details on adjusting the sunshade and using the round-head locking pin for reclining positions.

MAINTENANCE

- **Cleaning:** Wipe down the fabric and frame with a damp cloth and mild soap. Avoid harsh chemicals that may damage the material. Allow to air dry completely before folding or storing.
- **Storage:** When not in use, especially during inclement weather or off-season, fold the chair flat and store it in a dry, protected area to prolong its lifespan. The included strap facilitates easy transport and storage.
- **Inspection:** Periodically inspect the frame, fabric, and elastic cords for any signs of wear or damage. Ensure all bolts and connections are secure.

FOLDABLE STRUCTURE

Provided with locking buckle and shoulder strap, easy to carry.



Poolside



Camping



Beach



Garden



Caravanning

Figure 5: The chair's foldable structure and shoulder strap for convenient carrying and storage.

TROUBLESHOOTING

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Chair does not recline smoothly or lock into position.	Locking mechanism is obstructed or not fully engaged.	Ensure no debris is blocking the locking mechanism. Fully engage the round-head locking pin into the desired position.
Chair feels unstable or wobbly.	Not fully unfolded or placed on an uneven surface.	Ensure the chair is fully unfolded and all frame components are securely in place. Move the chair to a flat, stable surface.
Difficulty folding the chair.	Locking buckle not disengaged or frame components are misaligned.	Ensure the locking buckle is released. Gently manipulate the frame to align components for smooth folding.
Armrests or frame have sharp edges/protrusions.	Manufacturing defect or shipping damage.	Inspect the chair upon receipt. If sharp edges or protrusions are present, discontinue use and contact customer support for assistance.

SPECIFICATIONS

Attribute	Detail
Brand	Yaheetech
Model Name	Zero Gravity Recliner
Item Model Number	YTtv380002001
Color	Gray/Black
Product Dimensions (D x W x H)	36"D x 29.5"W x 45"H
Maximum Weight Recommendation	400 Pounds (182 kg)
Item Weight	22.8 Pounds (10.3 kg)
Fill Material	Oxford Fabric
Back Style	Adjustable
Arm Style	Wooden
Indoor/Outdoor Usage	Outdoor
Included Components	Cupholder, Headrest, Canopy Shade
Form Factor	Foldable



Figure 6: Detailed dimensions of the Yaheetech Zero Gravity Chair in both unfolded and folded states.

WARRANTY AND SUPPORT

For warranty information or product support, please refer to the documentation included with your purchase or visit the official Yaheetech website. You may also contact Yaheetech customer service directly for assistance with any issues or inquiries.

Typical return policy allows for returns within 30 days for refund/replacement, subject to seller's terms.

For additional support, visit the [Yaheetech Store on Amazon](#).

