

[Manuals.plus](#) /

> [HOOBRO](#) /

> HOOBRO Bar Table with Charging Station, Model BG90UBT01 Instruction Manual

HOOBRO BG90UBT01

HOOBRO Bar Table with Charging Station

Model: BG90UBT01

Brand: HOOBRO

INTRODUCTION

This manual provides instructions for the assembly, setup, operation, and maintenance of your HOOBRO Bar Table with Charging Station, Model BG90UBT01. This versatile table is designed to function as a console table, coffee bar, or workspace, featuring an integrated charging station for convenience.



Image: The HOOBRO Bar Table with Charging Station, Model BG90UBT01, shown in a kitchen environment with two bar stools, highlighting its compact design and integrated charging capabilities.

SAFETY INFORMATION

- Ensure the table is placed on a stable, level surface to prevent tipping.
- Do not exceed the maximum weight capacity of **88 pounds (40 kg)** on the tabletop to avoid damage or instability.
- Always connect the charging station's power cord to a properly grounded electrical outlet.
- Keep liquids away from the charging station to prevent electrical hazards.
- Periodically check all screws and connections to ensure they remain tight.

PACKAGE CONTENTS

Before beginning assembly, verify that all components are present and undamaged. If any parts are missing or damaged, please contact customer support.

- Tabletop (Greige)
- Metal Frame Components (Legs, Crossbar, Stable Supports)
- Charging Station Unit with Power Cord
- Adjustable Feet
- Assembly Guide
- Installation Tool (Screwdriver)
- Fasteners and Hardware (Screws, etc.)

ASSEMBLY INSTRUCTIONS

Assembly of the HOOBRO Bar Table is designed to be straightforward and can typically be completed by one person. Follow the detailed instructions provided in the included assembly guide. All necessary tools are supplied.


1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out on a clean, soft surface to prevent scratches.
2. **Assemble Frame:** Attach the metal frame components (legs, crossbar, stable supports) according to the diagrams in the assembly guide. Ensure all screws are finger-tightened initially.
3. **Attach Tabletop:** Secure the tabletop to the assembled frame using the provided hardware.
4. **Install Charging Station:** Carefully insert the charging station unit into the designated cutout on the tabletop and secure it with screws.
5. **Tighten All Screws:** Once all components are in place, fully tighten all screws using the provided installation tool. Do not overtighten.
6. **Attach Adjustable Feet:** Screw the adjustable feet into the bottom of the table legs.



Image: A diagram illustrating the dimensions of the HOOBRO Bar Table, including length (90cm/35.4"), width (40cm/15.7"), and height (90.5cm/35.6"), along with the power cord length (84cm/33").

Vintage Elegance

The greige top matches any home decor.



Cross Bar



Stable Support

Image: Detailed view of the table's structural elements, including the bottom crossbar for enhanced stability and the triangular stable supports connecting the tabletop to the legs.



Image: A close-up showing the adjustable foot at the base of a table leg, designed to provide stability on uneven surfaces.

SETUP AND OPERATING INSTRUCTIONS

Table Placement

Position the bar table in your desired location, ensuring it is on a flat, stable surface. Adjust the leveling feet as needed to eliminate any wobble.

Charging Station Setup


1. Locate the power cord extending from the charging station unit.
2. Plug the power cord into a standard 120V AC wall outlet. The power cord length is approximately 4.9 feet (1.5 meters).
3. Ensure the connection is secure.

Using the Charging Station

The integrated charging station provides convenient power access for your electronic devices.

- **AC Outlets:** The station includes two 120V/12A AC outlets. Plug in small appliances or chargers as needed.
- **USB Ports:** One standard USB port (5V/2A) is available for charging compatible devices.
- **Type-C Port:** One Type-C port (5V/2A) is available for charging compatible devices.

Simply connect your device's charging cable to the appropriate port. The charging station is ready for use once plugged into a power source.



- 1 AC Outlet -
120V/12A



1 Type-C/1 USB



- Power Cord -
4.9 - Foot




Image: A detailed view of the built-in charging station on the HOOBRO Bar Table, showing two AC outlets, one USB port, and one Type-C port, along with their electrical specifications.

Your browser does not support the video tag.

Video: An official HOOBRO video demonstrating the features and usage of the Bar Table with Charging Station, including its design and integrated power options.

MAINTENANCE

- **Cleaning:** Wipe the table surfaces with a soft, damp cloth. Avoid using abrasive cleaners or harsh chemicals, as these may damage the finish.
- **Electrical Components:** Keep the charging station clean and free of dust. Do not attempt to disassemble or repair the electrical components yourself.
- **Hardware Check:** Periodically inspect all screws and connections to ensure they are tight. Retighten if necessary to maintain stability.

TROUBLESHOOTING

Table Wobbles After Assembly

- **Check Connections:** Ensure all screws are fully tightened. Loose connections are a common cause of instability.
- **Adjust Feet:** Use the adjustable feet at the bottom of the legs to level the table on uneven floors. Rotate them clockwise or counter-clockwise until the table is stable.
- **Re-assemble:** If wobbling persists, disassemble the table and carefully re-assemble, ensuring all parts are correctly aligned according to the instructions.

Charging Station Not Functioning

- **Power Connection:** Verify that the power cord is securely plugged into both the table's charging unit and a live wall outlet.
- **Wall Outlet:** Test the wall outlet with another device to ensure it is providing power.
- **Overload:** Ensure the charging station is not overloaded beyond its specified capacity (120V/12A for AC outlets, 5V/2A for USB/Type-C).
- **Contact Support:** If the charging station still does not work, contact HOOBRO customer support for assistance. Do not attempt electrical repairs yourself.

SPECIFICATIONS

| | |
|---------------------------------------|----------------------------------------------|
| Brand | HOOBRO |
| Model Number | BG90UBT01 |
| Product Dimensions (L x W x H) | 35.4" x 15.7" x 35.6" (90cm x 40cm x 90.5cm) |
| Item Weight | 17.1 Pounds (7.76 kg) |
| Maximum Weight Recommendation | 88 Pounds (40 kg) |
| Frame Material | Metal |

| | |
|----------------------------------------|--------------------------------------------------------------------|
| Top Material Type | Engineered Wood |
| Color | Greige + Black |
| Charging Station | 2 AC Outlets (120V/12A), 1 USB Port (5V/2A), 1 Type-C Port (5V/2A) |
| Power Cord Length | 4.9 Feet (1.5 meters) |
| Assembly Required | Yes |
| Recommended People for Assembly | 1 |
| Product Care Instructions | Wipe with Damp Cloth |

WARRANTY AND SUPPORT

For specific warranty details, product support, or to inquire about replacement parts, please refer to the contact information provided with your purchase or visit the official HOOBRO website. Keep your purchase receipt for warranty claims.

You can also visit the [HOOBRO Store on Amazon](#) for additional information and support resources.